

Motor controller SFC-DC



FESTO

Manual

Function block S7
for motor controller
type SFC-DC

Manual

700 332
en 0604NH

Original de
Edition en 0604NH
Designation P.BE-SFC-DC-PB-S7-EN
Order no. 700 332

© (Festo AG & Co. KG, D-73726 Esslingen, 2006)
Internet: <http://www.festo.com>
E-Mail: service_international@festo.com

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility module or design.

PROFIBUS® is a registered trade name of PROFIBUS International (P.I.)

SIMATIC® is a registered trade name of Siemens AG

Contents

Designated use	VII
Basic principles of programmed software	VIII
Safety instructions	IX
Target group	X
Service	X
Important user instructions	XI
Manuals on motor controller type SFC-DC	XIII
Information on the versions	XV
Product-specific terms and abbreviations	XVI
PROFIBUS-specific terms and abbreviations	XVIII
1. Overview	1-1
1.1 General description	1-3
1.2 The blocks at a glance	1-4
1.3 Festo Profile for Handling and Positioning (FHPP)	1-5
2. Installation and overview of the projects	2-1
2.1 Configuration	2-3
2.1.1 Install device master file (GSD file) and icon files	2-3
2.1.2 I/O configuration	2-4
2.1.3 Configuration with STEP 7	2-5
2.2 Deactivating the example project	2-10
2.3 Overview of project	2-12
2.3.1 Folder “_CTRL” – control functions	2-12
2.3.2 Folder “_PRM_FPC” – parametrizing via FPC	2-13
2.3.3 Folder “PRM_DPV1_SFB” – parametrizing via DPV1	2-14
2.3.4 Folder “PRM_DPV1_SFC” – parametrizing via DPV1	2-15
2.3.5 Folder “PRM_UP-DOWNLOAD” – transmitting several parameters	2-16

3.	Control block	3-1
3.1	Function block “SFC_DC_CTRL”	3-3
3.1.1	Description of method of operation	3-4
3.1.2	Input parameters	3-6
3.1.3	Output parameters	3-8
3.1.4	Fault information	3-10
4.	Parametrizing blocks	4-1
4.1	Overview of parametrizing blocks	4-3
4.1.1	Control and parametrizing methods	4-4
4.1.2	Method of operation of the modules	4-4
4.1.3	Converting the measuring units	4-5
4.2	Block PRM_FPC	4-6
4.2.1	Input parameters	4-7
4.2.2	Output parameter	4-7
4.3	Blocks PRM_DPV1_SFB / PRM_DPV1_SFC	4-8
4.3.1	Input parameters	4-9
4.3.2	Output parameters	4-9
4.4	Block PRM_DB-FILE	4-10
4.4.1	Description of method of operation	4-11
4.4.2	Input parameters	4-13
4.4.3	Output parameters	4-14
4.4.4	Implementation	4-15
4.4.5	Restriction	4-15
4.5	Fault information	4-16
5.	Examples	5-1
5.1	Examples with the control block	5-3
5.1.1	Enable controller	5-4
5.1.2	Selecting the operating mode	5-5
5.1.3	Starting a positioning task in direct mode	5-5
5.1.4	Starting a positioning task in Record Select mode	5-7
5.2	Downloading a parameter list	5-8

A.	Technical appendix	A-1
A.1	Festo profile for handling and positioning (FHPP)	A-3
A.1.1	Supported operating modes	A-3
A.2	Drive functions	A-5
A.2.1	Reference system for electric drives	A-5
A.2.2	Reference travel	A-7
A.2.3	Jogging	A-9
A.2.4	Teaching via field bus	A-11
A.2.5	Carry out record (Record Select)	A-13
A.2.6	Specifying a position directly (Direct mode)	A-18
A.2.7	Standstill monitoring	A-21
A.3	Fault messages	A-23
A.4	Diagnostic memory	A-25
A.5	Diagnosis via PROFIBUS-DP	A-27
A.5.1	Structure of the DP diagnosis	A-27
B.	Supplementary information	B-1
B.1	Parameters of the SFC-DC	B-3
B.1.1	General parameter structure	B-3
B.1.2	Overview of parameters	B-4
C.	Index	C-1

Designated use

The function blocks (FB) described serve for controlling and parametrizing motor controllers type SFC-DC-...-PB via PROFIBUS-DP in a SIMATIC-S7 controller with integrated DP master module (e.g. CPU315-2DP).

With the blocks the many functions of the motor controller can be comfortably incorporated in the program.

The blocks can be parametrized and are capable of many instances. They are linked into the user program for each motor controller (each axis) from where they can be accessed cyclically with a separate instance data block or multi-instance block. Simultaneous use of other function blocks for controlling the same controller is not permitted.

The motor controller (Single Field Controller, single axis field controller) type SFC-DC-... serves as a position controller and position servo for the electric mini slide type SLTE-... with control via the PROFIBUS field bus.

It is absolutely necessary to observe the “Safety instructions” as well as the designated use of the relevant components and modules listed in the manual for the SFC-DC. Please observe also the safety instructions in the operating instructions for the components used.

If additional commercially-available components such as sensors and actuators are connected, the specified limits for pressures, temperatures, electrical data, torques, etc. must not be exceeded.

Note also the Siemens specifications regarding the use of their PLC Simatic S7.

Basic principles of programmed software

Please note that it is not possible with the present state of technology to create programmed software which functions without problems and is compatible with all applications and combinations intended by the user.

As a rule the software must therefore be used in the designated manner as specified in the program description and in the user instructions.

At the moment when the software is transferred or made available, it is in a state in which it will function under normal operating and application conditions.

Festo does not guarantee that the software will suffice for all applications and purposes intended by the user, or that it will function without problems when used with other programs, or that it is compatible with these programs. The responsibility for the correct selection and the consequences of using the software within the scope of use defined by the user, as well as for the intended and achieved results therefore lies with the user. The same applies to the written material supplied with the software.

The use of the programmed software does not exempt you as customer from your duties and responsibility for observing and adhering to technical machine and safety regulations as well as for a comprehensive functional check.

Safety instructions

When commissioning and programming positioning systems, you must observe the safety regulations in this manual as well as those in the operating instructions for the other components used.

The user must make sure that nobody is in the operating range of the connected actuators or axis system. Access to the possible danger area must be prevented by suitable measures such as protective screens and warning signs.



Warning

Electric axes can move suddenly with high force and at high speed. Collisions can lead to serious injury to human beings and damage to components.

Make sure that nobody can gain access to the operating range of the axes or other connected actuators and that no objects lie in the positioning range while the system is still connected to a power supply.



Warning

Faults in parametrization can cause injury to people and damage to property.

Enable the controller only if the axis system is correctly installed and parametrized.

Target group

This manual is intended exclusively for technicians trained in control and automation technology, who have experience in installing, commissioning, programming and diagnosing positioning systems and PROFIBUS-DP slaves.

Service

Please consult your local Festo repair service or write to the following e-mail address if you have any technical problems:

service_international@festo.com



The function blocks described here as well as software complementary to the product (e.g. GSD/GSG files) can be found on the Festo Internet pages under the address: www.festo.com [Industrie-Automation/Service & Support/Download Area/Software].

Important user instructions

Danger categories

This manual contains instructions on the possible dangers which may occur if the product is not used correctly. These instructions are marked (Warning, Caution, etc.), printed on a shaded background and marked additionally with a pictogram. A distinction is made between the following danger warnings:



Warning

This means that failure to observe this instruction may result in serious personal injury or damage to property.



Caution

This means that failure to observe this instruction may result in personal injury or damage to property.



Please note

This means that failure to observe this instruction may result in damage to property.



The following pictogram marks passages in the text which describe activities with electrostatically sensitive components.

Electrostatically sensitive components may be damaged if they are not handled correctly.

Marking special information

The following pictograms mark passages in the text containing special information.

Pictograms



Information:
Recommendations, tips and references to other sources of information.



Accessories:
Information on necessary or sensible accessories for the Festo product.



Environment:
Information on environment-friendly use of Festo products.

Text markings

- The bullet indicates activities which may be carried out in any order.
- 1. Figures denote activities which must be carried out in the numerical order specified.
- Hyphens indicate general activities.

Manuals on motor controller type SFC-DC

This manual contains information on the S7 blocks for motor controller type SFC-DC-...-PB with PROFIBUS field bus interface.

The following manual is also required for understanding the function blocks:

- Manual for motor controller type SFC-DC with PROFIBUS interface, type P.BE-SFC-DC-PB-...

This manual on the S7 blocks contains all necessary information for commissioning the blocks. In addition, the most important extracts from the manual for motor controller type SFC-DC are also reproduced.

However this does not replace in any way the manual for motor controller type SFC-DC. The guidelines and safety regulations listed therein must be observed at all costs in order to guarantee correct and reliable functioning. Note also the section “Designated use”.

Information on components, such as the electric slide type SLTE-... or the reference switch can be found in the operating instructions supplied with the relevant product.

Siemens

When reference is made in this manual to documents from Siemens, this always means the Step 7 version 5.3 (service pack 1). Other versions of Step 7 may differ from that described in this manual.

Overview of documentation on the SFC-DC

Design	Designation	Contents
Docu package with brief description + manuals on CD ROM	P.BE-SFC-DC-UDOK	Brief description: Important instructions on commissioning and preliminary information. Manuals: Contents as described below.
Manual	Motor controller type SFC-DC with PROFIBUS interface P.BE-SFC-DC-PB-...	Installation, commissioning and diagnosis of electric axes with motor controller type SFC-DC with communication via PROFIBUS.
Help system for software	Festo Configuration Tool help (contained in FCT software)	Function description of the Festo Configuration Tool configuration software.
Operating instructions	Mini slide type SLTE-...	Fitting and commissioning the electric mini slide as a drive element.
Manual for S7 block	S7 block for the SFC-DC P.BE-SFC-DC-PB-S7-...	Using the S7 block for motor controller type SFC-DC with PROFIBUS interface.

Tab. 0/1: Documentation on the SFC-DC

Information on the versions

The function blocks for the SFC-DC require the following versions:

- motor controller type SFC-DC-...-PB with firmware version as from V1.10
- GSD/GSG file as from revised version 14.12.2005

The firmware version specifies the version status of the operating system of the SFC-DC.

You can find the specifications on the version status as follows:

- in the Festo Configuration Tool with active device connection to the SFC-DC under “Device data”
- on the control panel under [Diagnostic] [Software information].

Product-specific terms and abbreviations

The following product-specific terms and abbreviations are used in this manual:

Field bus specific abbreviations see following Tab. 0/3.

Term/abbreviation	Meaning
0-signal	0 V present at input or output (positive logic, corresponds to LOW).
1-signal	24 V present at input or output (positive logic, corresponds to HIGH).
Axis	Complete actuator, consisting of motor, encoder and drive, optional with gear, if applicable with controller.
Axis zero point (AZ)	Measuring basis point for the project zero point and the software end positions. The basis point for the axis zero point is the reference point.
Controller	Control electronics which evaluate the control signals and provide the power supply for the motor via the power electronics (power electronics + controller + position controller).
Drive	Mechanical component of an axis which transfers the drive power for the movement, defines the guide for the positioning movement, and enables the work load and the reference switch to be fitted. The electric mini slide type SLTE is an integrated unit consisting of a motor, encoder, gear unit and drive.
Encoder	With the SLTE: magnetic pulse generator (rotor position transducer). The electric signals generated are sent to the controller, which then calculates the position and speed on the basis of the signals received.
E O I/O	Input Output Input and/or output
Festo Handling und Positioning Profile (FHPP)	Uniform field bus data profile for positioning controllers from Festo.
Festo Parameter Channel (FPC)	FHPP-specific PKW design (see “PROFIBUS-specific terms and abbreviations”, Tab. 0/3).
log mode	Manual positioning in positive or negative direction (only on field bus variants of the SFC-DC via the field bus or only with FCT or control panel).

Term/abbreviation	Meaning
Operating mode	Type of controller or internal operating mode of the controller. – Type of control: Record Select, Direct mode – Operating mode of the controller: Position profile mode, Homing mode, Demo mode, ...
PLC	Programmable logic controller; in brief: controller (also IPC: industrial PC).
Positioning mode (Profile position mode)	Operating mode for processing a position set or a direct positioning task.
Position set	Positioning command defined in the position set table, consisting of target position, positioning mode, positioning speed and accelerations.
Project zero point (PZ)	Measuring reference point for all positions in positioning tasks (Project zero point). The project zero point forms the basis for all absolute position specifications (e.g. in the position set table or with direct control via the controller interface or diagnostic interface). The basis point for the project zero point is the axis zero point.
Reference point (REF)	Basis point for the incremental measuring system. The reference point defines a known orientation or position within the positioning path of the drive.
Reference switch	External sensor (e. g. type SMT-10) which serves for ascertaining the reference position and is connected directly to the controller.
Reference travel	The reference position and therefore the source of the measuring reference system of the axis will be defined by the reference travel.
Referencing (Homing mode)	Operating mode in which reference travel is carried out.
Referencing method	Method for defining the reference position: against a fixed stop (overcurrent/speed evaluation) or with reference switch.
SLTE...	Type designation, electric slide.

Term/abbreviation	Meaning
Software end position	Programmable stroke limitation (basis point = axis zero point) Software end position, positive: max. limit position in positive direction (away from the motor); must not be exceeded during positioning. Software end position, negative: min. limit position in negative direction (towards the motor); must not be exceeded during positioning.
Teach mode	Operating mode for setting positions by moving to the target position e.g. when creating position sets.

Tab. 0/2: Index of terms and abbreviations for the SFC-DC

PROFIBUS-specific terms and abbreviations

Term/abbreviation	Meaning
0x1234 or 1234h	Hexadecimal numbers are marked by a prefixed "0x" or by a suffixed "h".
AK	See under response identifier or task identifier
BCD	Binary coded decimal
Consistency	A data range, which is defined as consistent, is transmitted complete, i.e. in a bus cycle.
GSD file	Device master file in which all specific features of the slave are saved (e.g. number of I/Os, number of diagnostic bytes etc.).
LSB	Least significant bit (lower-value bit)
MSB	Most significant bit (higher-value bit)
Octet	Byte (8 bits); basis type for PROFIBUS telegrams
Parameter channel (PKW)	Telegram part used for transmitting parameters (PKW = parameter identifier value) See also "Festo Parameter Channel (FPC)" under "Product-specific abbreviations" (Tab. 0/2).
Parameter identifier (PKE)	Integral part of the parameter channel (PKW) which contains the task and reply identifiers (AK) and the parameter number (PNU).

Term/abbreviation	Meaning
Parameter number (PNU)	Parameters which can be transmitted via the parameter channel are addressed with the parameter number (PNU). The parameter number is an integral part of the parameter identifier (PKE) and serves for identifying or addressing the individual parameter.
PKE	See under parameter identifier
PKW	See under parameter channel
PNU	See under parameter number
Reply telegram	Telegram sent from the slave to the master (slave reply)
Response identifier (AK)	Integral part of the parameter channel in reply telegrams specifying the type of reply of a parameter processing.
PROFIBUS	PROcess Field BUS; German processing and field bus standard defined in IEC 61158 type 3.
PROFIBUS address	Serves for clear identification of a bus slave on the PROFIBUS
Subindex (IND)	Integral part of the parameter channel (PKW) which addresses an element of an array parameter (sub-parameter number)
Task identifier (AK)	Integral part of the parameter channel in task telegrams specifying the type of task of a parameter processing.
Task telegram	Telegram sent from the master to the slave (task of master)
Terminating resistor	Resistor for minimizing signal reflections. Terminating resistors must be installed or switched in at the end of bus segment cables.
Work data	Telegram data without protocol frame data The length of the work data is defined in the configuration of the field bus slave.

Tab. 0/3: Index of terms and abbreviations for PROFIBUS

Overview

Chapter 1

Contents

1. Overview 1-1

1.1 General description 1-3

1.2 The blocks at a glance 1-4

1.3 Festo Profile for Handling and Positioning (FHPP) 1-5

1. Overview

1.1 General description

In order to facilitate commissioning of the motor controller type SFC-DC, Festo has made available a SIMATIC STEP 7 Project. The STEP 7 Project contains function and data blocks for controlling motor controller type SFC-DC via PROFIBUS-DP with a SIMATIC-S7 controller.

The blocks for the SFC-DC will support you in programming the PROFIBUS communication between the Siemens PLC SIMATIC S7 and motor controller type SFC-DC.

The blocks are available with full access rights. This offers the possibility of adapting the blocks individually to the project. However no guarantee can be given that open blocks will function.

1.2 The blocks at a glance

With the blocks you can incorporate the functions of the SFC-DC directly in your programs. Normally you would require three blocks for the various functions.

The blocks have been purposely split into groups, so that you can decide yourself which functions you require for your application. In this way, e.g. parametrizing functions can be implemented in a separate project.

The example project contains the following special blocks:

- SFC_DC_CTRL (example project: FB10)
- PRM_FPC (example project: FB20)
- PRM_DPV1_SFB (example project: FB21)
- PRM_DPV1_SFC (example project: FB22)
- PRM_DB-FILE (example project: FB23)



A complete overview of the contents of the example project can be found in chapter 2.3.

1.3 Festo Profile for Handling and Positioning (FHPP)

Festo has developed an optimized data profile especially tailored to the target applications for handling and positioning tasks, the “Festo Handling and Positioning Profile (FHPP)”.

The FHPP enables uniform control and programming for the various field bus systems and controllers from Festo.

In addition it defines the following for the user:

- the operating modes
- the I/O data structure
- the parameter objects
- the sequence control.




Fig. 1/1: The FHPP principle



Detailed information on the FHPP can be found in appendix A.1.

Control and status bytes

Control via the field bus is made via 8 bits of I/O data. Functions and status messages required in operation can be controlled directly – mostly with single-bit operations.

Record Select

Saved position sets can be processed in the Record Select mode.

For this purpose, up to 31 position sets are parametrized with the Festo Configuration Tool or taught via the control panel during commissioning.

Direct mode

In the Direct operating mode the important positioning data are transferred directly via the control bytes.

- Target positions and speeds can be ascertained and specified by the controller during running time, depending on the operating status.
- No limitations due to the number of saved position sets.

In both operating modes values can be taught/parametrized via the PLC.

Parameter channel

By means of the parameter channel, the controller can access all parameter values of the controller via the field bus. A further 8 bytes of I/O data are used for this purpose.

Installation and project overview

Chapter 2

Contents

2. **Installation and project overview 2-1**

2.1 Configuration 2-3

 2.1.1 Install device master file (GSD file) and icon files 2-3

 2.1.2 I/O configuration 2-4

 2.1.3 Configuration with STEP 7 2-5

2.2 Deactivating the example project 2-10

2.3 Overview of project 2-12

 2.3.1 Folder “_CTRL” – control functions 2-12

 2.3.2 Folder “_PRM_FPC” – parametrizing via FPC 2-13

 2.3.3 Folder “PRM_DPV1_SFB” – parametrizing via DPV1 2-14

 2.3.4 Folder “PRM_DPV1_SFC” – parametrizing via DPV1 2-15

 2.3.5 Folder “PRM_UP-DOWNLOAD” –
 transmitting several parameters 2-16

2. Installation and project overview

2.1 Configuration

2.1.1 Install device master file (GSD file) and icon files

If a new hitherto unknown device is to be incorporated in a configuration program when a PROFIBUS-DP system is to be configured, an appropriate device master file (GSD file) must be installed for this device. The device master file contains all the necessary information for the configuration program. You will require the appropriate icon files for representing the device graphically.

Obtainable

This documentation CD of the SFC-DC contains GSD files and icon files for the SFC-DC in the folder "PROFIBUS". Current GSD files and icon files can be found on the Festo Internet pages under:

- www.festo.com/fieldbus

GSD file


You will require one of the following GSD files for the SFC-DC:

- SFC_0973.gsd – English
SFC_0973.gsg – German
(with support DPV0 and DPV1)
- SFC00973.gsd – English
SFC00973.gsg – German
(only for older controllers/without DPV1)

Icon files

In order to represent the SFC-DC in your configuration software use the following icon files:

2. Installation and project overview

Normal operating status	Diagnostic case	Special operating status
		
File: sfc-dc_n.dib or sfc-dc_n.bmp	File: sfc-dc_d.dib or sfc-dc_d.bmp	File: sfc-dc_s.dib or sfc-dc_s.bmp

Tab. 2/1: Icon files

2.1.2 I/O configuration

Two configurations are supported by the GSD files:

- “Festo handling and positioning profile standard”
GSD entry as “FHPP Standard”,
8 bytes of I/O data, consistent transmission
- “Festo handling and positioning profile with parameter channel”
GSD entry as “FHPP Standard + FPC”,
2 x 8 bytes of I/O data, consistent transmission

2. Installation and project overview

2.1.3 Configuration with STEP 7

General instructions

The software package SIMATIC Manager serves for project planning and commissioning in conjunction with PROFIBUS masters from Siemens or compatible masters. In order to understand this chapter, you should be sure of how to handle your configuration program. If necessary, refer to the documentation for the SIMATIC Manager. This manual refers to software version V 5.3.



An appropriate device master file (GSD file) for the SFC-DC must be installed for configuration.

With the STEP 7 Hardware Configurator you can load the files via the menu command [Options][Install GSD file] in the dialogue window “HW Config”.

Configuration program	File type	Directory
STEP 7 Hardware Configurator ¹⁾	GSD file	...\STEP7\S7DATA\GSD
	Bitmap files	...\STEP7\S7DATA\NSBMP
¹⁾ If you copy the GSD files when the SIMATIC Manager has already been started, you can update the hardware catalogue with the command [Options][Update Catalog].		

Tab. 2/2: Folder for GSD and icon files STEP 7

Insert SFC-DC as slave

The hardware configuration window represents graphically the structure of the master system. When the GSD file has been installed, the SFC-DC can be selected in the hardware catalogue. It can be found in the group [PROFIBUS-DP] [Additional Field Devices] [Drives] [Festo], (see Fig. 2/1).

In order to insert the SFC-DC:

1. Drag the station type “Festo SFC-DC” or “Festo SFC-DC DP-V0” (3), see section 2.1.1) from the hardware catalogue onto the PROFIBUS line (1) of the DP master system (Drag & Drop).
2. Enter the PROFIBUS address, which you have set with the Festo Configuration Tool or on the control panel in the dialogue window “Properties PROFIBUS interface...” and confirm with OK.
3. If necessary, enter other settings in the dialogue window “Properties DP slave” (e.g. the response monitoring or the startup parametrizing) and confirm with OK. The icon of the SFC-DC is displayed on the line of the DP master system (2).

2. Installation and project overview




Fig. 2/1: Station selection STEP 7

Configuring the slave features

After clicking the icon for the SFC-DC, you can configure the “Slave properties” in the lower part of the screen. Here you can determine the number and size of the I/O ranges of the slave and assign them with address ranges of the master.

In order to configure the slave properties of the SFC-DC:

1. Open the available modules (configurations) in the hardware catalogue under [Festo SFC-DC ...].
2. Then drag the desired configuration (see section 2.1.2) with the mouse into the appropriate line under Component/DP identifier.

With STEP 7 a “Universal module” is also offered for compatibility reasons. This must not be used.

The SFC-DC is a modular slave, but with only **one permitted** module. The configuration is defined only by the master.



2. Installation and project overview




Fig. 2/2: Configuring the slave features

When the configuration is concluded, transfer the data to the master.

2. Installation and project overview

2.2 Dearchiving the example project

The example project will be made available as project archive.

Procedure for dearchiving

1. Open the dialogue “Retrieving – Select an archive” with the command [File][Retrieve] ([File][Dearchive]).




Fig. 2/3: Dearchive project

2. Select the archive file of the example project (e.g. “SFC-DC.zip”).
3. Select the desired destination path in the dialogue “Select destination directory”.
If the option “Scan destination directory when dearchivating” is switched off in the basic settings of the SIMATIC Manager, the preset path will be used directly as the destination path during dearchivation.
4. The unpacking of the project will be shown in a DOS or console window. The project will then be opened in the SIMATIC Manager:

2. Installation and project overview




Fig. 2/4: Folder “S7 program” of the example project

The example project does not contain any hardware. You can use this in your controller in one of the following ways:

- Drag the modules required into your own control project.
- Add the relevant hardware to the example project. Delete non-required “S7 program” folders.

In each case adapt the addresses to your controller.

2.3 Overview of project

The following sections contain an overview of the “S7 program” folders of the example project.

2.3.1 Folder “_CTRL” – control functions

The most important blocks in the folder “_CTRL” for controlling the controller are listed in Tab. 2/3. Additional blocks, e.g. for fault treatment or data blocks, etc. are not listed.

Block	Name	Purpose	Description	Access	Function
OB1	Main	Cyclic program access	Main program routine	FB10	Example project
FB10	SFC_DC_CTRL	Control	FB for controlling the drive	SFC14/15	Festo control block
DB90	GV-SFC	Control	Contains the global control variables for FB10	–	Example project
SFC_CTRL-DRIVE		Control	Variable table for control	–	Example project

Tab. 2/3: Overview of the most important blocks of the folder “_CTRL”

Block FB10 for controlling the SFC-DC is implemented in OB1. The global variables for controlling the controller are saved in DB90. With the aid of the variable table SFC_DC-CTRL the drive can be positioned via PROFIBUS.

2. Installation and project overview

2.3.2 Folder “_PRM_FPC” – parametrizing via FPC

The most important blocks in the folder “_PRM_FPC” for parametrizing the controller via the Festo Parameter Channel (DPV0) are listed in Tab. 2/4.

Additional blocks, e.g. for fault treatment or data blocks, etc. are not listed.

Block	Name	Purpose	Description	Access	Function
OB1	Main	Cyclic program access	Main program routine	FB20	Example project
FB20	PRM_FPC	Parametrizing (DPV0)	FB for parametrizing via FPC	SFC14/15	Festo control block
DB91	GV-PRM	Parametrizing	Contains the global control variables for parametrizing	–	Example project
PARAMETERIZE-DRIVE		Parametrizing	Variable table for parametrizing	–	Example project

Tab. 2/4: Overview of the most important blocks of the folder “_PRM_FPC”

Block FB20 for parametrizing the SFC-DC via DPV0 is implemented in OB1. The global variables for parametrizing are saved in DB91. With the aid of the variable table PARAMETERIZE-DRIVE the controller can be parametrized via PROFIBUS.

2. Installation and project overview

2.3.3 Folder “PRM_DPV1_SFB” – parametrizing via DPV1

The most important blocks in the folder “PRM_DPV1_SFB” for parametrizing the controller via DPV1 are listed in Tab. 2/5. Additional blocks, e.g. for fault treatment or data blocks, etc. are not listed.

Block	Name	Purpose	Description	Access	Function
OB1	Main	Cyclic program access	Main program routine	FB21	Example project
FB21	PRM_DPV1_SFB	Parametrizing (DPV1)	FB for parametrizing via DPV1 using SFB52/53	SFB52/53	Festo control block
DB91	GV-PRM	Parametrizing	Contains the global control variables for parametrizing	–	Example project
PARAMETERIZE-DRIVE		Parametrizing	Variable table for parametrizing	–	Example project

Tab. 2/5: Overview of the most important blocks of the folder “PRM_DPV1_SFB”

Block FB21 for parametrizing the SFC-DC via DPV1 is implemented in OB1. The global variables for parametrizing are saved in DB91. With the aid of the variable table PARAMETERIZE-DRIVE the controller can be parametrized via PROFIBUS.

2. Installation and project overview

2.3.4 Folder “PRM_DPV1_SFC” – parametrizing via DPV1

The most important blocks in the folder “PRM_DPV1_SFC” for parametrizing the controller via DPV1 are listed in Tab. 2/6. Additional blocks, e.g. for fault treatment or data blocks, etc. are not listed.

Block	Name	Purpose	Description	Access	Function
OB1	Main	Cyclic program access	Main program routine	FB22	Example project
FB22	PRM_DPV1_SFB	Parametrizing (DPV1)	FB for parametrizing via DPV1 using SFC58/59	SFC58/59	Festo control block
DB91	GV-PRM	Parametrizing	Contains the global control variables for parametrizing	–	Example project
PARAMETERIZE-DRIVE		Parametrizing	Variable table for parametrizing	–	Example project

Tab. 2/6: Overview of the most important blocks of the folder “PRM_DPV1_SFC”

Block FB22 for parametrizing the SFC-DC via DPV1 is implemented in OB1. The global variables for parametrizing are saved in DB91. With the aid of the variable table PARAMETERIZE-DRIVE the controller can be parametrized via PROFIBUS.

2. Installation and project overview

2.3.5 Folder “PRM_UP-DOWNLOAD” – transmitting several parameters

The most important blocks in the folder “UP-DOWNLOAD” for transmitting several parameters are listed in Tab. 2/6. Additional blocks, e.g. for fault treatment or data blocks, etc. are not listed.

Block	Name	Purpose	Description	Access	Function
OB1	Main	Cyclic program access	Main program routine	FB1	Example project
FB1	UP-DOWN	Parametrizing	Function block contains examples of routines for exchanging parameter sets	FB20, FB23	Example project
FB20	PRM_FPC	Parametrizing (DPV0)	FB for parametrizing via FPC	SFC14/15	Festo control block
FB23	PRM_DB-FILE	Parametrizing (DPV0/DPV1)	FB controls the upload/download of parameter sets from a global DB via one of the three transmission paths	SFC24	Festo control block
DB91	GV-PRM	Parametrizing	Contains the global control variables for parametrizing	–	Example project
DIAGNOSTIC BUFFER		Parametrizing	Variable table for reading out the diagn. memory	–	Example project
PARAMETERIZE-DRIVE		Parametrizing	Variable table for parametrizing	–	Example project

Tab. 2/7: Overview of the most important blocks of the folder “PRM_DPV1_SFC”

Block FB1 is implemented in OB1. Block FB23 for transmitting parameter sets as well as block FB20 for parametrizing the SFC-DC via the Festo Parameter Channel (DPV0) are implemented in FB1. This is also possible via the blocks FB21 or FB22.

The global variables for parametrizing are saved in DB91. With the aid of the variable table PARAMETERIZE-DRIVE the controller can be parametrized via PROFIBUS. The diagnostic memory can be read out with the variable table DIAGNOSTIC BUFFER.

Control block

Chapter 3

Contents

3. Control block 3-1

3.1 Function block “SFC_DC_CTRL” 3-3

3.1.1 Description of method of operation 3-4

3.1.2 Input parameters 3-6

3.1.3 Output parameters 3-8

3.1.4 Fault information 3-10

3. Control block

3.1 Function block “SFC_DC_CTRL”

The SFC-DC is controlled with block SFC_DC_CTRL.




Fig. 3/1: SFC-DC control block

3. Control block

3.1.1 Description of method of operation

The block enables the drive functions of the SFC-DC to be controlled by the field bus. It enables comfortable access to the control bits.

System functions used

For data exchange the block uses internally the system functions SFC14/SFC15.

The correct logical input and output addresses of the slave projected in the Hardware Manager must be entered for the data exchange.

Position factor

All position specifications are always saved internally in increments in the SFC-DC.

In the control block the conversion between increments and the desired measuring system takes place via a position factor. The position factor is defined by a counter and a denominator value.

Unit of length	Parameter	SLTE-10	SLTE-16
Increments	Pos_Faktor_nummerator: Pos_Faktor_denumerator:	1 000 000 1 000 000	1 000 000 1 000 000
µm	Pos_Faktor_nummerator: Pos_Faktor_denumerator:	1 795 938 (default) 1 000 000	2 338 461 1 000 000
µInch	Pos_Faktor_nummerator: Pos_Faktor_denumerator:	45 616 836 1 000 000	59 396 923 1 000 000

Tab. 3/1: SFC-DC position factors with the electric mini-slide type SLTE

3. Control block



If both factors are 1, the current position and the nominal value for the position will be specified in increments.

The values for specifying the positions in μm are saved in the SFC-DC and can be downloaded (PNU 1004, subindex 0 and 1).

Device control

In order that the drive can be controlled via the PLC, the device control via the PROFIBUS interface must be active. Control via the FCT or the control panel must be deactivated (Reurn message-Bit Drive_Control_FCT_HMI = 0).

The drive is ready to operate when the bits Stop, Halt and Enable_Drive = 1 and the Fault bit = 0. This is shown with the bits Drive_Enabled and Ready = 1.

3. Control block

3.1.2 Input parameters

Parameter	Declaration	Data type	Description
I_ADDRESS	INPUT	WORD	Address of the logical inputs of the slave.
O_ADDRESS	INPUT	WORD	Address of the logical outputs of the slave.
Pos_Factor_numerator	INPUT	INT	Counter of the position factor (default 1)
Pos_Factor_denominator	INPUT	INT	Denominator of the position factor (default 1)
HMI_Access_Locked	INPUT	BOOL	Controls access to the local (integrated) diagnostic interface of the drive. TRUE: MMI and FCT may only observe the drive, the device control (HMI control) cannot be taken over by MMI and FCT. FALSE: MMI or FCT may take over the device control (in order to modify parameters or to control inputs)
Reset_Fault	INPUT	BOOL	With a rising edge a fault is quitted and the fault number is deleted.
Halt	INPUT	BOOL	Halt drive. TRUE: Halt is not active. FALSE: Halt activated (do not cancel braking ramp + positioning task). The axis stops with a defined braking ramp, the positioning task remains active (the remaining path can be deleted with "Clear_remaining_Position").
Stop	INPUT	BOOL	Stop / enable operation. TRUE: Enable operation. FALSE: Stop active (cancel emergency ramp + positioning task). The axis stops with maximum braking ramp, the positioning task is reset.
Enable_Drive	INPUT	BOOL	Enable drive. TRUE: Enable drive (controller). Faults will be deleted. FALSE: Drive (controller) blocked.
Start_Homing	INPUT	BOOL	Start reference travel With a rising edge reference travel with the set parameters is started.

3. Control block

Parameter	Declaration	Data type	Description
Start_Task	INPUT	BOOL	Start current task. With a rising edge the current nominal values will be transferred and positioning started (record 0 = reference travel).
Operation_Mode	INPUT	BOOL	Selecting the operating mode FALSE: Record Select TRUE: Direct mode
Absolute_Relative	INPUT	BOOL	Positioning mode FALSE: Nominal value is absolute. TRUE: Nominal value is relative to last nominal value
Clear_Remaining_Position	INPUT	BOOL	Deletes the unfinished positioning task after a stop. In the "Halt" status, a positive signal edge causes the positioning task to be deleted and transfer to the "Ready" status.
Jog_pos	INPUT	BOOL	Jogging positive The drive moves at the specified speed in the direction of larger actual values, providing the bit is set. The movement begins with the rising edge and ends with the falling edge.
Jog_neg	INPUT	BOOL	Jogging negative The drive moves at the specified speed in the direction of smaller actual values, see "Jog_neg".
Teach_Actual_Value	INPUT	BOOL	Teach the current position, see appendix A.2.4. The Teach target is defined with PNU 520.
Record_No	INPUT	INT	Preselect of record number for Record Select (1 ... 31, 0 = reference travel).
Set_Value_Velocity	INPUT	INT	Preselect of speed for direct mode (in % of the maximum speed)
Set_Value_Position	INPUT	DINT	Preselect of position for direct mode: – position in measured unit, depends on position factor.

Tab. 3/2: Input parameter "SFC_DC_CTRL"

3. Control block

3.1.3 Output parameters

Parameter	Declaration	Data type	Description
Control_FCT_HMI	OUTPUT	BOOL	Control sovereignty PLC or MMI/FCT. FALSE: Control sovereignty PLC TRUE: Control sovereignty MMI/FCT (PLC control is Locked).
Drive_enabled	OUTPUT	BOOL	Drive enabled. FALSE: Drive blocked, controller not active. TRUE: Drive (controller) enabled.
Supply_Voltage_Ok	OUTPUT	BOOL	Load voltage FALSE: No load voltage TRUE: Load voltage applied
Warning	OUTPUT	BOOL	Warning. FALSE: Warning not applied TRUE: Warning applied
Fault	OUTPUT	BOOL	Fault FALSE: No fault TRUE: There is a fault or reaction to fault is active. Fault number in diagnostic memory
Ready	OUTPUT	BOOL	Quit stop, if "Drive_enable" = 1
State_Operation_Mode	OUTPUT	BOOL	Reply message operating mode FALSE: Record Select (standard) TRUE: Direct mode
Ack_Start	OUTPUT	BOOL	Quit Start FALSE: Ready for start (reference, jog) TRUE: Start carried out (reference, jog)
Ack_Teach	OUTPUT	BOOL	Quit Teach positive edge: Ready for teaching negative edge: Teaching carried out Actual value is transferred.

3. Control block

Parameter	Declaration	Data type	Description
MC	OUTPUT	BOOL	Motion Complete FALSE: Positioning task active TRUE: Positioning task completed, if applicable with fault Note: MC is set after device is switched on (status "Drive blocked")
Drive_is_moving	OUTPUT	BOOL	Axis moves FALSE: Speed of the axis < Limit value TRUE: Speed of the axis > = limit value
Halt_Not_Active	OUTPUT	BOOL	Reply message Halt FALSE: Halt is active, at start last positioning task will be continued. TRUE: Halt is not active, axis can be moved.
Drag_Error	OUTPUT	BOOL	Drag error FALSE: No drag error. TRUE: Drag error active.
Standstill_Control	OUTPUT	BOOL	Standstill monitoring FALSE: After MC axis remains in tolerance window. TRUE: Achse steht nach MC außerhalb Toleranzfenster.
Drive_is_referenced	OUTPUT	BOOL	Axis referenced. FALSE: Referencing must be carried out. TRUE: Reference information exists, reference travel must not be carried out.
Actual_Record_No	OUTPUT	INT	Reply message of record number for Record Select (1...31, 0 = reference travel).
Actual_Velocity	OUTPUT	BYTE	Reply message of speed for Direct mode (in % of the maximum speed)
Actual_Position	OUTPUT	DINT	Reply message of the position. – Position, depends on position factor (see Tab. 3/1).
RET_VAL	OUTPUT	INT	Reply value of the function block.

Tab. 3/3: Output parameter "SFC_DC_CTRL"

3. Control block

3.1.4 Fault information

The fault output of the block distinguishes between faults in the SFC-DC and faults in the block. Faults in the SFC-DC are shown with the Fault bit, more precise details of the fault must be downloaded in the diagnostic buffer of the SFC-DC. Block faults are output at the output RET_VAL. If the block is processed incorrectly, the ENO bit will be set to 0.

Block-internal faults are triggered by a position factor denominator with value 0, or by system functions (e.g. SFC14/SFC15, ...).



The fault codes are defined by the transmission blocks, see help for STEP 7.

The evaluation of the fault can take place with the value RET_VAL and the help for the relevant transmission blocks (SFC14/SFC15, SFB52/SFB53, SFC58/SFC59).

Parametrizing blocks

Chapter 4

Contents

4. Parametrizing blocks 4-1

4.1 Overview of parametrizing blocks 4-3

4.1.1 Control and parametrizing methods 4-4

4.1.2 Method of operation of the blocks 4-4

4.1.3 Converting the measuring units 4-5

4.2 Block PRM_FPC 4-6

4.2.1 Input parameters 4-7

4.2.2 Output parameter 4-7

4.3 Blocks PRM_DPV1_SFB / PRM_DPV1_SFC 4-8

4.3.1 Input parameters 4-9

4.3.2 Output parameters 4-9

4.4 Block PRM_DB-FILE 4-10

4.4.1 Description of method of operation 4-11

4.4.2 Input parameters 4-13

4.4.3 Output parameters 4-14

4.4.4 Implementation 4-15

4.4.5 Restriction 4-15

4.5 Fault information 4-16

4.1 Overview of parametrizing blocks

For parametrizing the SFC-DC, different methods can be used depending on the blocks:

- parametrizing with the block PRM_FPC via the cyclic data (DPV0)
- parametrizing with the block PRM_DPV1_SFB using the system function blocks SFB52/SFB53 (DPV1)
- parametrizing with the block PRM_DPV1_SFC using the system functions SFC58/SFC59 (DPV1)
- automatic transfer of several parameters with the block “PRM_DB-FILE” and one of the parametrizing blocks.

The choice of transfer method depends primarily on the controller used. Transfer via the cyclic data is possible with any DP controller, but requires memory space in the logical address range, which can cause problems under certain circumstances with many slaves on the bus.

In the case of transfer via DPV1 with the system function modules SFB52/SFB53 from Siemens, you must make sure that this transfer procedure is supported by the controller. With the system functions SFC58/SFC59 for older controllers, Siemens therefore offers the possibility of transferring parameters DV1-conform to the controller.

For compatibility reasons the block interfaces of all transfer types are identical.



Please note

All blocks address parameters with subindices as per DPV1. This means that the subindices must be transferred from 0 ... n-1.

4. Parametrizing blocks

4.1.1 Control and parametrizing methods

DPV0	Parametrizing with the DPV0 is carried out via the Festo parameter channel (FPC, further 8 I/O bytes), see manual for the SFC-DC-...-PB.
DPV1	Die Parametrizing with the DPV1 is carried out via the parameter channel as per PROFIdrive V3.1. This protocol is a compatible extension of the PKW protocol within the DPV1 work data. This means that the parameters can be addressed with PNU, subindex etc.

4.1.2 Method of operation of the blocks

With all blocks a parameter is clearly defined by the PNU (parameter number), the subindex and the length in bytes.

With the blocks named under 4.1 only one parameter can be transferred in each case. With the bit RD_WR you can define whether the parameter is to be read or written. When the parameters are transferred, a distinction is made between three data types: Byte, Word, Double word or length 1, 2, 4. How the parameter is to be interpreted can be found in the description of the relevant parameter, see manual for the controller used.

An overview of the parameters can be found in appendix B.1. It is not necessary to specify the length of the parameter in order that it can be read.

A positive edge at the start input triggers the transfer. When the transfer is completed, this will be shown at the output Done. The result of the transfer is shown all the time the start bit is set to 1.

The reply to an incorrect parameter entry depends on the transmission method.

4. Parametrizing blocks

4.1.3 Converting the measuring units

In the SFC-DC all parameters are always saved in increment specifications (inc, inc/s, inc/s²). Conversion is carried out via the parameters:

- Feed constant, depending on the drive
- Gear reduction
- Encoder resolution = physical measuring steps per motor revolution. With the SFC-DC: pulse quadruplication by digital interpolation.

Parameters		SLTE-10	SLTE-16
feed	Feed constant ¹⁾	SLTE-...-BS5.0: 5000 [μm/rev]	SLTE-...-LS7.5: 7500 [μm/rev]
gear	Gear ratio ²⁾	SLTE-...-G04 (57:13)	
enc	Encoder resolution ³⁾	512 x 4 = 2048 [incr/rev]	1000 x 4 = 4000 [incr/rev]
¹⁾ Depending on drive, here type SLTE-... ²⁾ Specification in 2 natural numbers for counter or denominator of the fraction ³⁾ With the SFC-DC: pulse quadruplication by digital interpolation			

Tab. 4/1: Basis parameter for the measuring system



The values for specifying the positions in μm are saved in the SFC-DC and can be downloaded (PNU 1004, subindex 0 and 1).

Special conversion factors for the SFC-DC

Length unit	SLTE-10	SLTE-16
Increments → millimetres	Increments / 1795.938	Increments / 2338.461
Millimetre → increments	Millimetres * 1795.938	Millimetres * 2338.461
Increments → inch	Increments / 45616.836	Increments / 59396.923
Inch → increments	Inch * 45616.836	Inch * 59396.923

Tab. 4/2: Conversion factors for SLTE measuring system

4. Parametrizing blocks

4.2 Block PRM_FPC

The block transfers the parameters internally to the FPC (Festo Parameter Channel).




Fig. 4/1: Parametrizing via the cyclic data

Fault treatment



Transmission faults are displayed with the Fault bit, the parameter Length_RD then contains value 2. The cause of the fault will be output at Value_RD. Information on faults can be found in section 4.5.

4. Parametrizing blocks

4.2.1 Input parameters

Parameters	Declaration	Data type	Description
I_ADDRESS	INPUT	WORD	Logical input address of the FPC (PKW) specifications
O_ADDRESS	INPUT	WORD	Logical output address of the FPC (PKW) specifications
RD_WR	INPUT	BOOL	FALSE: Read TRUE: Write
Start	INPUT	BOOL	Starts write or read procedure
PNU	INPUT	WORD	Parameter number of the current parameter
Subindex	INPUT	BYTE	Subindex of the current parameter
Length	INPUT	INT	Length of the parameter to be written in bytes
Param_Value_WR	INPUT	DWORD	Parameter value when writing a parameter

Tab. 4/3: Input parameter PRM_FPC

4.2.2 Output parameter

Parameters	Declaration	Data type	Description
Done	OUTPUT	BOOL	FALSE: Transfer completed TRUE: Write
Value_RD	OUTPUT	DWORD	Value of parameter to be read
Length_RD	OUTPUT	INT	Length of parameter to be transferred
Fault	OUTPUT	BOOL	FALSE: No fault TRUE: Fault
RET_VAL	OUTPUT	INT	Return value after incorrect processing of the block

Tab. 4/4: Output parameter PRM_FPC

4.3 Blocks PRM_DPV1_SFB / PRM_DPV1_SFC

The blocks PRM_DPV1_SFC and PRM_DPV1_SFB enable transfer of parameters via DPV1.
The differences with the transfer via DPV1 are not recognizable externally or functionally. However, block PRM_DPV1_SFC offers older controllers the possibility of transferring parameters acyclically.




Fig. 4/2: Parametrizing block with SFB52 / SFB53




Fig. 4/3: Parametrizing block with SFC58 / SFC59

Fault treatment



Transmission faults are displayed with the Fault bit, the parameter Length_RD then contains value 0x44 (68). The fault number can be read at Value_RD. Information on faults can be found in section 4.5.

4. Parametrizing blocks

4.3.1 Input parameters

Parameters	Declaration	Data type	Description
I_O_ADDRESS	INPUT	WORD	Logical address of the DP slave module Example: I-address 256, O-address 264 --> W#16#100 The smaller of the two addresses must be specified.
RD_WR	INPUT	BOOL	0 = read 1 = write
Start	INPUT	BOOL	Starts write or read procedure
PNU	INPUT	WORD	Parameter number of the current parameter
Subindex	INPUT	BYTE	Subindex of the current parameter
Length_WR	INPUT	INT	Length of the parameter to be written in bytes
Value_WR	INPUT	DWORD	Parameter value when writing

Tab. 4/5: Input parameters PRM_DPV1_SFB / PRM_DPV1_SFC

4.3.2 Output parameters

Parameters	Declaration	Data type	Description
Done	OUTPUT	BOOL	Transfer completed
Value_RD	OUTPUT	DWORD	Value of parameter to be read
Length_RD	OUTPUT	INT	Length of parameter to be transferred
Fault	OUTPUT	BOOL	Fault bit
RET_VAL	OUTPUT	INT	Return value after incorrect processing of the block

Tab. 4/6: Output parameters PRM_DPV1_SFB / PRM_DPV1_SFC

4.4 Block PRM_DB-FILE

In order to automate the transfer of several parameters, block PRM_DB-FILE offers the possibility of transferring parameter sets from a global DB to the controller or of receiving parameter sets. The block uses one of the three transfer blocks FB20, FB21 or FB22 for the transfer.




Fig. 4/4: System overview upload/download

4. Parametrizing blocks

4.4.1 Description of method of operation

A list of the desired parameters must be saved in a global DB, a parameter must be composed as follows:

```
Parameter : STRUCT
    PNU          : INT;
    Subindex     : BYTE;
    Accessrights  : BYTE;
    Length       : INT;
    Parametervalue : DINT;
```

Fig. 4/5: Composition of a parameter

The byte “Accessrights” is a reserve byte for additional implementations, e.g. parameters with a certain identification could be omitted from write-read authorization during parametrizing.

The data block must correspond to an array of this structure (n*10BYTE). A source and a target DB, which must be of the same length (n*10BYTE), must be specified for the transfer. From the source DB you can read the parameters which are to be read or written. In the case of reading, the read parameters will then be transferred to the target DB. The same DB can be specified for source and target. Only the parameter values will be transferred.

The data type for the parameter value always has the length of a double word. It is therefore independent of the parameter to be transferred. It occupies memory space but reduces the problem in handling. If a parameter with length 1 is transferred, the above-named three bytes will be ignored. Vice-versa when reading the above-named three bytes will be assigned with zeros. How the parameter value is to be interpreted can be found in the description of the parameter.

The transmission is started with the bit Start_RxTx. The progress of the transmission will be shown in % at the “Progress” output. The transmission is completed when the bit Done_RxTx supplies TRUE.

4. Parametrizing blocks

If the parameter is faulty, the transmission will be aborted.
The fault can be identified by means of the incorrect
parameter values which are still present in the block.




Fig. 4/6: Block for transferring a parameter list

Fault treatment



Transmission faults are shown with the Fault bit. The parameter which caused the fault can be read with the last transferred parameter values.
Information on faults can be found in section 4.5.

4. Parametrizing blocks

4.4.2 Input parameters

Parameters	Declaration	Data type	Description
Start_RxTx	INPUT	BOOL	Start transmission
Rx_Tx	INPUT	BOOL	Read DB / write DB
DB_Source	INPUT	INT	Source DB
DB_Target	INPUT	INT	Target DB
_Done_RD_WR	INPUT	BOOL	Transmission of individual parameters is concluded
_Fault_RD_WR	INPUT	BOOL	Faults in the transmission of individual parameters
_Length_RD	INPUT	INT	Length of the read parameter in BYTE
_Value_RD	INPUT	DWORD	Parameter value of the current parameter when reading

Tab. 4/7: Input parameter PRM_DB-FILE

4. Parametrizing blocks

4.4.3 Output parameters

Parameters	Decla- ration	Data type	Description
_Start_R_WR	OUTPUT	BOOL	Start transfer of individual parameters
_RD_WR	OUTPUT	BOOL	Read/write individual parameter
_PNU	OUTPUT	INT	PNU of the current parameter
_Subindex	OUTPUT	BOOL	Subindex of the current parameter
_Length_WR	OUTPUT	INT	Length of the current parameter in BYTE
_Value_WR	OUTPUT	DWORD	Current parameter value to be written
Done_RxTx	OUTPUT	BOOL	Read DB / write DB completed
Progress	OUTPUT	INT	Progress of transmission in %
Fault_RxTx	OUTPUT	BOOL	Fault with Read DB / write DB
RET_VALUE	OUTPUT	INT	Return value after incorrect processing of the block

Tab. 4/8: Output parameter PRM_DB-FILE

The block is ready to operate when the Done bit supplies TRUE and there are no faults. Transmission is started with a positive edge; the progress of the transmission is shown in percent at the “Progress” output. During transmission the Done bit is set to FALSE.

4. Parametrizing blocks

4.4.4 Implementation

The block PRM_DB-FILE cannot function on its own, only in combination with one of the transfer blocks can it transfer a list of parameters. Some of the inputs or outputs must therefore be linked directly with each other.

RD_WR_DB-FILE		↔	PRM_...	
_PNU	OUTPUT	-->	_PNU	INPUT
_Subindex	OUTPUT	-->	_Subindex	INPUT
_Length_RD	OUTPUT	-->	_Length	INPUT
_Value_WR	OUTPUT	-->	_Value_WR	INPUT
_Done_RD_WR	INPUT	<--	_Done_RD_WR	OUTPUT
_Fault_RD_WR	INPUT	<--	_Fault_RD_WR	OUTPUT
_Value_RD	INPUT	<--	_Value_RD	OUTPUT

Tab. 4/9: Wiring table

4.4.5 Restriction

Function block RD_WR_DB-File uses internally the system function SFC24. With this function the source and target DB can be tested and their length defined. However, this function is not implemented in controllers of an earlier date. The block cannot therefore be used there in this form.

4.5 Fault information

A distinction is always made between two types of faults: block faults and transmission faults.

Block faults (e.g. incorrect logic address, incorrect hardware configuration, etc.) are caused by the relevant system function blocks used SFC14/SFC15, SFC58/SFC59, SFB52/SFB53 or SFC24 and shown at the output RET_VALUE. The fault code can be found in the STEP 7 help. If a block fault occurs, the block will be exited with the ENO bit = 0.

Transmission faults arise as a result of incorrect parameter data (e.g. non-existent PNU, incorrect parameter length when writing, non-existent subindex, etc.).

Transmission faults are shown with the bit Fault.

With the aid of the value of Value_RD the fault can be evaluated accordingly Tab. 4/10.

Fault numbers		Description
0	0x00	Non-permitted PNU The parameter does not exist.
1	0x01	Parameter value cannot be modified (read only)
(2)	0x02	– (reserved – lower or upper limit value exceeded) ¹⁾
3	0x03	Faulty subindex
4	0x04	No array
5	0x05	Incorrect data type
(6)	0x06	– (reserved – setting not permitted – can only be reset) ¹⁾
(7)	0x07	– (reserved – describing element cannot be modified) ¹⁾
(8)	0x08	– (reserved – PPO-Write requested in IR does not exist) ¹⁾
9	0x09	Description data do not exist
(10)	0x10	– (reserved – access group incorrect) ¹⁾
11	0x0A	No control sovereignty
(12)	0x0B	– (reserved – password incorrect) ¹⁾
¹⁾ These fault numbers are not used		

4. Parametrizing blocks

Fault numbers		Description
13	0x0C	Text not legible in cyclic exchange
(14)	0x0D	– (reserved – name not legible in cyclic exchange) ¹⁾
(15)	0x0E	– (reserved – text array does not exist) ¹⁾
(16)	0x10	– (reserved – PPO-Write missing) ¹⁾
(17)	0x11	– (reserved – order cannot be processed because of operating status) ¹⁾
(18)	0x12	– (reserved – other faults) ¹⁾
(19)	0x13	– (reserved – date not legible in cyclic exchange) ¹⁾
(20)	0x14	– (reserved – non-permitted value) ¹⁾
(21)	0x15	– (reserved – reply too long) ¹⁾
22	0x16	Non-permitted: Attributes, number of elements, PNU or IND
(23)	0x17	– (reserved – Write request: non-permitted format) ¹⁾
24	0x18	Write request: Number of values not permitted
(...99)	0x64	– (reserved – PROFIBUS)
100	0x65	– (reserved – Festo: ReqID is not supported) ¹⁾
(...255)	0xFF	– (reserved – Festo)
¹⁾ These fault numbers are not used		

Tab. 4/10: Fault information

4. Parametrizing blocks

Examples

Chapter 5

Contents

5. Examples 5-1

5.1 Examples with the control block 5-3

5.1.1 Enable controller 5-4

5.1.2 Selecting the operating mode 5-5

5.1.3 Starting a positioning task in direct mode 5-5

5.1.4 Starting a positioning task in Record Select mode 5-7

5.2 Downloading a parameter list 5-8

5. Examples


5.1 Examples with the control block

In the following sections the variable table shows the values which must be set in order to control certain functions of the SFC-DC.

5. Examples

5.1.1 Enable controller

With the bits Halt, Stop and Enable_Drive the readiness of the controller to operate will be restored.



	Operand	Symbol	Anzahl	Statuswert	Steuerwert
2	//>>>>>>	CONTROL DRIVE <<<<<<<			
3	//-----				
4	DB90.DBX 0.0	"GV-SFC".HMI_Access_locked	BOOL	false	
5	DB90.DBX 2.5	"GV-SFC".Control_FCT_HMI	BOOL	false	
6	//---- Modis -----				
7	DB90.DBX 0.7	"GV-SFC".Operation_Mode	BOOL	false	
8	DB90.DBX 3.7	"GV-SFC".State_Operation_Mode	BOOL	false	
9	//---- Enable -----				
10	DB90.DBX 1.6	"GV-SFC".Clear	BOOL	false	
11	DB90.DBX 0.1	"GV-SFC".Reset_Fault	BOOL	false	
12	DB90.DBX 0.2	"GV-SFC".Halt	BOOL	true	
13	DB90.DBX 0.3	"GV-SFC".Stop	BOOL	true	
14	DB90.DBX 0.4	"GV-SFC".Enable_Drive	BOOL	true	
15	//---- Execute -----				
16	DB90.DBX 1.5	"GV-SFC".Absolute_Relative	BOOL	false	
17	DB90.DBX 0.6	"GV-SFC".Start_Task	BOOL	false	
18	DB90.DBX 0.5	"GV-SFC".Start_Homing	BOOL	false	
19	DB90.DBX 2.0	"GV-SFC".Jog_pos	BOOL	false	
20	DB90.DBX 1.7	"GV-SFC".Jog_neg	BOOL	false	
21	DB90.DBX 2.1	"GV-SFC".Teach_Actual_Value	BOOL	false	
22	//---- Set-Values -----				
23	DB90.DBW 10	"GV-SFC".Record_No	DEZ	0	3
24	DB90.DBW 8	"GV-SFC".Set_Value_Velocity	DEZ	0	0
25	DB90.DBW 16	"GV-SFC".Set_Value_Position	DEZ	L#0	L#0
26	//-----				
27	//>>>>>>	OBSERVE DRIVE <<<<<<<			
28	//-----				
29	//---- Enable -----				
30	DB90.DBX 3.4	"GV-SFC".Supply_Voltage_Ok	BOOL	true	
31	DB90.DBX 2.7	"GV-SFC".Drive_Enabled	BOOL	true	
32	DB90.DBX 3.2	"GV-SFC".Ready	BOOL	true	
33	DB90.DBX 2.4	"GV-SFC".Halt_Not_Active	BOOL	true	
34	DB90.DBX 3.6	"GV-SFC".Warning	BOOL	false	
35	DB90.DBX 3.0	"GV-SFC".Fault	BOOL	false	
36	DB90.DBX 2.6	"GV-SFC".Drag_Error	BOOL	false	
37	//---- Status -----				


Fig. 5/1: Enable controller

The readiness to operate will be shown with appropriate return values.

5. Examples

5.1.2 Selecting the operating mode

You can switch between the operating modes Record Select and Direct mode via the bit Operation_Mode.



	Operand	Symbol	Anzei	Statuswert	Steuerwert
2	//>>>>>>	CONTROL DRIVE	<<<<<<<		
3	//-----				
4	DB90.DBX 0.0	"GV-SFC".HMI_Access_locked	BOOL	false	
5	DB90.DBX 2.5	"GV-SFC".Control_FCT_HMI	BOOL	false	
6	//-----	Modis			
7	DB90.DBX 0.7	"GV-SFC".Operation_Mode	BOOL	false	
8	DB90.DBX 3.7	"GV-SFC".State_Operation_Mode	BOOL	false	
9	//-----	Enable			

Fig. 5/2: Setting the operating mode

5.1.3 Starting a positioning task in direct mode

In order to start a positioning task you must carry out reference travel when the SFC-DC has been switched on. If reference travel is successful, it will be shown with the bit Drive_is_Referenced.

When the Direct mode has been set with the bit Operation_Mode, the desired nominal position and nominal speed must be set with Set_Value_Position and Set_Value_Velocity.

5. Examples

SFC_CTRL-DRIVE -- @WORK-S7\SIMATIC 300-Station\CPU 315-2 DP_CTRL ONLINE					
	Operand	Symbol	Anzei	Statuswert	Steuerwert
2	//>>>>>>	CONTROL DRIVE <<<<<<<			
3	//				
4	DB90.DBX 0.0	"GV-SFC".HMI_Access_locked	BOOL	false	
5	DB90.DBX 2.5	"GV-SFC".Control_FCT_HMI	BOOL	false	
6	//----- Modis -----				
7	DB90.DBX 0.7	"GV-SFC".Operation_Mode	BOOL	true	
8	DB90.DBX 3.7	"GV-SFC".State_Operation_Mode	BOOL	true	
9	//----- Enable -----				
10	DB90.DBX 1.6	"GV-SFC".Clear	BOOL	false	
11	DB90.DBX 0.1	"GV-SFC".Reset_Fault	BOOL	false	
12	DB90.DBX 0.2	"GV-SFC".Halt	BOOL	true	
13	DB90.DBX 0.3	"GV-SFC".Stop	BOOL	true	
14	DB90.DBX 0.4	"GV-SFC".Enable_Drive	BOOL	true	
15	//----- Execute -----				
16	DB90.DBX 1.5	"GV-SFC".Absolute_Relative	BOOL	false	
17	DB90.DBX 0.6	"GV-SFC".Start_Task	BOOL	false	
18	DB90.DBX 0.5	"GV-SFC".Start_Homing	BOOL	false	
19	DB90.DBX 2.0	"GV-SFC".Jog_pos	BOOL	false	
20	DB90.DBX 1.7	"GV-SFC".Jog_neg	BOOL	false	
21	DB90.DBX 2.1	"GV-SFC".Teach_Actual_Value	BOOL	false	
22	//----- Set-Values -----				
23	DB90.DBW 10	"GV-SFC".Record_No	DEZ	0	
24	DB90.DBW 8	"GV-SFC".Set_Value_Velocity	DEZ	50	50
25	DB90.DBW 16	"GV-SFC".Set_Value_Position	DEZ	L#2000	L#2000
26	//				
27	//>>>>>>	OBSERVE DRIVE <<<<<<<			
28	//				
29	//----- Enable -----				
30	DB90.DBX 3.4	"GV-SFC".Supply_Voltage_Ok	BOOL	true	
31	DB90.DBX 2.7	"GV-SFC".Drive_Enabled	BOOL	true	
32	DB90.DBX 3.2	"GV-SFC".Ready	BOOL	true	
33	DB90.DBX 2.4	"GV-SFC".Halt_Not_Active	BOOL	true	
34	DB90.DBX 3.6	"GV-SFC".Warning	BOOL	false	
35	DB90.DBX 3.0	"GV-SFC".Fault	BOOL	false	
36	DB90.DBX 2.6	"GV-SFC".Drag_Error	BOOL	false	
37	//----- Status -----				
38	DB90.DBX 2.2	"GV-SFC".Ack_Start	BOOL	false	
39	DB90.DBX 4.0	"GV-SFC".Ack_Teach	BOOL	false	
40	DB90.DBX 3.1	"GV-SFC".MC	BOOL	true	
41	DB90.DBX 4.1	"GV-SFC".Drive_is_Moving	BOOL	false	
42	DB90.DBX 3.3	"GV-SFC".Standstill_Control	BOOL	false	
43	DB90.DBX 3.5	"GV-SFC".Drive_is_Referenced	BOOL	true	
44	DB90.DBW 20	"GV-SFC".Actual_Position	DEZ	L#71	
45	DB90.DBW 12	"GV-SFC".Actual_Record_No	DEZ	0	
46	DB90.DBW 6	"GV-SFC".Actual_Velocity	DEZ	0	


Fig. 5/3: Positioning task in Direct mode

The positioning task is started with the bit Start_Task.

5. Examples

5.1.4 Starting a positioning task in Record Select mode

When the Record Select mode has been set with the bit Operation_Mode, the positioning record saved in the SFC-DC must be set with the value Record_No.



	Operand	Symbol	Anzei	Statuswert	Steuerwert
2	//>>>>>>	CONTROL DRIVE <<<<<<<			
3	//-----				
4	DB90.DBX 0.0	"GV-SFC".HMI_Access_locked	BOOL	false	
5	DB90.DBX 2.5	"GV-SFC".Control_FCT_HMI	BOOL	false	
6	//----- Modis -----				
7	DB90.DBX 0.7	"GV-SFC".Operation_Mode	BOOL	false	
8	DB90.DBX 3.7	"GV-SFC".State_Operation_Mode	BOOL	false	
9	//----- Enable -----				
10	DB90.DBX 1.6	"GV-SFC".Clear	BOOL	false	
11	DB90.DBX 0.1	"GV-SFC".Reset_Fault	BOOL	false	
12	DB90.DBX 0.2	"GV-SFC".Halt	BOOL	true	
13	DB90.DBX 0.3	"GV-SFC".Stop	BOOL	true	
14	DB90.DBX 0.4	"GV-SFC".Enable_Drive	BOOL	true	
15	//----- Execute -----				
16	DB90.DBX 1.5	"GV-SFC".Absolute_Relative	BOOL	false	
17	DB90.DBX 0.6	"GV-SFC".Start_Task	BOOL	false	
18	DB90.DBX 0.5	"GV-SFC".Start_Homing	BOOL	false	
19	DB90.DBX 2.0	"GV-SFC".Jog_pos	BOOL	false	
20	DB90.DBX 1.7	"GV-SFC".Jog_neg	BOOL	false	
21	DB90.DBX 2.1	"GV-SFC".Teach_Actual_Value	BOOL	false	
22	//----- Set-Values -----				
23	DB90.DBW 10	"GV-SFC".Record_No	DEZ	3	3
24	DB90.DBW 8	"GV-SFC".Set_Value_Velocity	DEZ	0	0
25	DB90.DBW 16	"GV-SFC".Set_Value_Position	DEZ	L#0	L#0
26	//-----				
27	//>>>>>>	OBSERVE DRIVE <<<<<<<			
28	//-----				
29	//----- Enable -----				
30	DB90.DBX 3.4	"GV-SFC".Supply_Voltage_Ok	BOOL	true	
31	DB90.DBX 2.7	"GV-SFC".Drive_Enabled	BOOL	true	
32	DB90.DBX 3.2	"GV-SFC".Ready	BOOL	true	
33	DB90.DBX 2.4	"GV-SFC".Halt_Not_Active	BOOL	true	
34	DB90.DBX 3.6	"GV-SFC".Warning	BOOL	false	
35	DB90.DBX 3.0	"GV-SFC".Fault	BOOL	false	
36	DB90.DBX 2.6	"GV-SFC".Drag_Error	BOOL	false	
37	//----- Status -----				

Fig. 5/4: Preselecting the record number

The positioning task is started with the bit Start_Task.

5. Examples

5.2 Downloading a parameter list

In the following the mechanism for downloading a list of parameters is represented by the example of the positioning record table.

Recommendation:
Edit the parameter list as an STL source.




Fig. 5/5: Source of the parameter list

A positioning record consists of 5 parameters with the SFC-DC. These parameters consist in turn of 5 variables which clearly describe the parameter.

Parameter3 : STRUCT //Velocity_Setpoint
PNU : INT;
Subindex : BYTE;
accessrights : BYTE;
Length : INT;
Parametervalue : DINT;

5. Examples




```
DB_SFC_RTS -- SFC_DC_V1_T\PRM_UP-DOWNLOAD
DATA_BLOCK "DB_SFC_RTS"
TITLE =
VERSION : 0.1

STRUCT
//-----
SAT2_NR_1 : STRUCT //RECORD NUMBER 1
Parameter1: STRUCT //Record_Controlbyte_1
    PNU      : INT;
    Subindex : BYTE;
    accessrights : BYTE;
    Length   : INT;
    Parametervalue : DINT;
END_STRUCT ;
Parameter2 : STRUCT //Position_Setpoint
    PNU      : INT;
    Subindex : BYTE;
    accessrights : BYTE;
    Length   : INT;
    Parametervalue : DINT;
END_STRUCT ;
Parameter3 : STRUCT //Velocity_Setpoint
    PNU      : INT;
    Subindex : BYTE;
    accessrights : BYTE;
    Length   : INT;
    Parametervalue : DINT;
END_STRUCT ;
Parameter4 : STRUCT //Acceleration
    PNU      : INT;
    Subindex : BYTE;
    accessrights : BYTE;
    Length   : INT;
    Parametervalue : DINT;
END_STRUCT ;
Parameter5 : STRUCT //Deceleration
    PNU      : INT;
    Subindex : BYTE;
    accessrights : BYTE;
    Length   : INT;
    Parametervalue : DINT;
END_STRUCT ;
//-----
SAT2_NR_2 : STRUCT //RECORD NUMBER 2
```

Fig. 5/6: Parameter declaration in the parameter list

5. Examples



```
Parameter1 : DINT;  
END_STRUCT ;  
END_STRUCT ;  
  
BEGIN  
  SATZ_NR_1.Parameter1.PNU           := 401; |  
  SATZ_NR_1.Parameter1.Subindex      := B#16#1;  
  SATZ_NR_1.Parameter1.accessrights  := B#16#0;  
  SATZ_NR_1.Parameter1.Length        := 1;  
  SATZ_NR_1.Parameter1.Parametervalue := L#0;  
  SATZ_NR_1.Parameter2.PNU           := 404;  
  SATZ_NR_1.Parameter2.Subindex      := B#16#1;  
  SATZ_NR_1.Parameter2.accessrights  := B#16#0;  
  SATZ_NR_1.Parameter2.Length        := 4;  
  SATZ_NR_1.Parameter2.Parametervalue := L#22000;  
  SATZ_NR_1.Parameter3.PNU           := 406;  
  SATZ_NR_1.Parameter3.Subindex      := B#16#1;  
  SATZ_NR_1.Parameter3.accessrights  := B#16#0;  
  SATZ_NR_1.Parameter3.Length        := 4;  
  SATZ_NR_1.Parameter3.Parametervalue := L#100;  
  SATZ_NR_1.Parameter4.PNU           := 407;  
  SATZ_NR_1.Parameter4.Subindex      := B#16#1;  
  SATZ_NR_1.Parameter4.accessrights  := B#16#0;  
  SATZ_NR_1.Parameter4.Length        := 4;  
  SATZ_NR_1.Parameter4.Parametervalue := L#20;  
  SATZ_NR_1.Parameter5.PNU           := 408;  
  SATZ_NR_1.Parameter5.Subindex      := B#16#1;  
  SATZ_NR_1.Parameter5.accessrights  := B#16#0;  
  SATZ_NR_1.Parameter5.Length        := 4;  
  SATZ_NR_1.Parameter5.Parametervalue := L#20;  
  SATZ_NR_2.Parameter1.PNU           := 401;  
  SATZ_NR_2.Parameter1.Subindex      := B#16#2;  
  SATZ_NR_2.Parameter1.accessrights  := B#16#0;  
  SATZ_NR_2.Parameter1.Length        := 1;  
  SATZ_NR_2.Parameter1.Parametervalue := L#0;  
  SATZ_NR_2.Parameter2.PNU           := 404;  
  SATZ_NR_2.Parameter2.Subindex      := B#16#2;  
  SATZ_NR_2.Parameter2.accessrights  := B#16#0;  
  SATZ_NR_2.Parameter2.Length        := 4;  
  SATZ_NR_2.Parameter2.Parametervalue := L#71837;  
  SATZ_NR_2.Parameter3.PNU           := 406;  
  SATZ_NR_2.Parameter3.Subindex      := B#16#2;  
  SATZ_NR_2.Parameter3.accessrights  := B#16#0;  
  SATZ_NR_2.Parameter3.Length        := 4;  
  SATZ_NR_2.Parameter3.Parametervalue := L#100;
```

Fig. 5/7: Current values of the parameter list

If a list of parameters is defined, only the parameter value must still be defined. When the current values of the individual parameters have been entered, the data block can be generated and loaded into the controller.

5. Examples

	Operand	Symbol	Anzei	Statuswert	Steuerwert
16	// Parametrieren über DPV1				
17	//				
18	// Eingangssignale SFC-DC Parameterize				
19	DB91.DBX 16.0	"GV2".Single_All	BOOL	 true	
20	DB91.DBX 28.0	"GV2".Via_SFC_58_59	BOOL	 false	
21	DB91.DBW 18	"GV2".DB_Source	DEZ	101	101
22	DB91.DBW 20	"GV2".DB_Target	DEZ	101	101
23	DB91.DBW 26	"GV2".Percent_Done	DEZ	0	
24	// Eingangssignale DPV1				
25	DB91.DBX 0.1	"GV2".Start	BOOL	 false	
26	DB91.DBX 0.0	"GV2".RD_wR	BOOL	 false	
27	DB91.DBW 2	"GV2".PNU	DEZ	0	0
28	DB91.DBB 1	"GV2".Subindex	DEZ	0	0
29	DB91.DBW 4	"GV2".Length	DEZ	0	0
30	DB91.DBD 8	"GV2".Value_wR	DEZ	L#0	L#0
31	// Rückmeldung				
32	DB91.DBX 0.3	"GV2".Done	BOOL	 true	
33	DB91.DBX 0.2	"GV2".Fault	BOOL	 false	
34	DB91.DBW 6	"GV2".Length_RD	DEZ	0	
35	DB91.DBD 12	"GV2".Value_RD	DEZ	L#0	
36	DB91.DBW 22	"GV2".Param_RET_VAL	HEX	w#16#0000	
37	DB91.DBW 24	"GV2".DPV1_RET_VAL	HEX	w#16#0000	

Fig. 5/8: Reply message from parameter transmission

When the source and target DBs are specified, the transmission can be started. If reference travel is successful, it will be shown at the output Done.

5. Examples

Technical appendix

Appendix A

Contents

A. Technical appendix A-1

A.1 Festo profile for handling and positioning (FHPP) A-3

 A.1.1 Supported operating modes A-3

A.2 Drive functions A-5

 A.2.1 Reference system for electric drives A-5

 A.2.2 Reference travel A-7

 A.2.3 Jogging A-9

 A.2.4 Teaching via field bus A-11

 A.2.5 Carry out record (Record Select) A-13

 A.2.6 Specifying a position directly (Direct mode) A-18

 A.2.7 Standstill monitoring A-21

A.3 Fault messages A-23

A.4 Diagnostic memory A-25

A.5 Diagnosis via PROFIBUS-DP A-27

 A.5.1 Structure of the DP diagnosis A-27

A.1 Festo profile for handling and positioning (FHPP)

The SFC-DC supports the Festo handling and positioning profile FHPP (see also chapter 1.3).

A.1.1 Supported operating modes

The operating modes differ as regards their contents and the meaning of the cyclic I/O data and in the functions which can be accessed in the SFC-DC.

Operating mode	Description
Record Select	31 position sets can be saved in the SFC-DC. A record contains all the parameters which are specified for a positioning task. The record number is transferred to the cyclic I/O data as the nominal or actual value.
Direct mode	The positioning task is transferred directly in the I/O telegram. The most important nominal values (position, speed) are thereby transferred. Supplementary parameters (e.g. acceleration) are defined by the parametrizing.

Tab. A/1: Overview of operating modes

Record Select

Preset operating mode when the SFC-DC is started up.

The SFC-DC has 31 records (1 ... 31) which contain all the information necessary for a positioning task (+ record 0 = reference travel).

The record number, which the SFC-DC is to process at the next start, is transferred to the output data of the master. The input data contains the last processed record number. The positioning task itself does not need to be active.

The SFC-DC does not support any automatic mode, i.e. no user program. Records cannot be processed automatically with a programmed logic. The drive cannot accomplish any tasks sensibly with Stand Alone; close coupling to the PLC is necessary.

Direct mode


In the direct mode positioning tasks are formulated directly in the output data of the master.

The typical application calculates dynamically the nominal target values for each task or just for some tasks. Adaption to different work item sizes is therefore possible. It is not sensible here to parametrize the record list again each time. The positioning data are managed completely in the PLC and sent directly to the SFC-DC.

Here also, close coupling between the PLC and the SFC-DC is necessary.

A.2 Drive functions

A.2.1 Reference system for electric drives



Tab. A/2: Reference system

Calculating specifications of reference system

Reference point	Calculating specification			
Axis zero point	AZ	= REF + a		
Project zero point	PZ	= AZ + d	= REF + a + d	
Lower software end position	LSE	= AZ + b	= REF + a + b	
Upper software end position	USE	= AZ + c	= REF + a + c	
Target/actual position	TP, AP	= PZ + e	= AZ + d + e	= REF + a + d + e

Tab. A/3: Calculating specifications of reference system

All position values (offset, software end positions, target positions...) have a mathematical sign and must be adapted to the position of the relevant basis point.

Value ¹⁾	Position values for SLTE-...
+	Positive values face from the basis point in the direction away from the motor.
—	Negative values face from the basis point in the direction towards the motor.
¹⁾ Factory setting (see PNU 1000)	

Measuring system



All parameters are always saved internally in increments in the SFC-DC (inc, inc/s, inc/s² ...). Positions transferred via the control block will be converted with the aid of the position factor (see chapter 3.1.1, Tab. 3/1). Measurements transferred via the parametrizing blocks always refer to an increment basis (see chapter 4.1.3).

A.2.2 Reference travel

With electric mini slide SLTE, reference travel must be carried out when the device is switched on as prerequisite for a positioning task (Bit Drive_is_referenced = TRUE).

The drive references against a stop or a reference switch. An increase in the motor current indicates that a stop has been reached. As the drive must not continuously reference against the stop, it must move at least one millimetre back into the stroke range.

Sequence:

1. Search for the reference point in accordance with the configured method.
2. Move relative to the reference point around the "Offset axis zero point".
3. Set at axis zero point:
 $\text{Current position} = 0 + \text{offset project zero point}.$

Overview of parameters involved (see also appendix B.1.2)		
Parameters involved	Description	PNU
	Offset axis zero point	1010
	Reference method (permitted: 7, 11, -18, -17)	1011
	Reference travel speed	1012
	Reference travel required	1014
	Reference travel maximum torque	1015
Start	SFC_DC_CONTROL – Start_Positioning_Task = positive edge	
Reply message	SFC_DC_CONTROL – Ack_Start = positive edge: Quit Start SFC_DC_CONTROL – Drive_is_referenced = Drive is referenced	
Prerequisites	Device control via PLC/field bus (Drive_Control_FCT_HMI = 0) Controller in status “Drive enabled” (Drive_enabled = 1) No command for jogging	

Tab. A/4: Parameters involved in reference travel

Reference travel methods		
hex	dec.	Description
07h	7	Search for reference switch in positive direction. The reference position lies at the first index pulse in the negative direction; the reference switch supplies a 0-signal.
0Bh	11	Search for reference switch in negative direction. The reference position lies at the first index pulse in the positive direction; the reference switch supplies a 0-signal.
EFh	-17	Search for negative stop. The point found is the reference position. As the axis must not stand still at the stop, the offset axis zero point must be $\neq 0$.
EEh	-18	Search for positive stop. The point found is the reference position. As the axis must not stand still at the stop, the offset axis zero point must be $\neq 0$.

Tab. A/5: Overview of reference travel methods

A.2.3 Jogging

In the status “Enable operation” the drive can be moved to the left/right by jogging. This function is usually used for:

- moving to teach positions
- moving the drive out of the way (e.g. after a system fault)
- manual positioning as normal operating mode (hand-operated feed).

Sequence

1. When one of the signals “Jog left / Jog right” is set, the drive starts to move slowly. Due to the slow speed, a position can be defined very accurately.
2. If the signal remains set, the speed will be increased until the configured maximum speed is reached. In this way large strokes can be traversed quickly.
3. If the signal changes to 0, the drive will be braked with the maximum set deceleration.
4. If the drive reaches a software end position, it will stop automatically. The software end position is not exceeded, the path for stopping depends on the ramp set. Jogging operation is also exited here with Jogging = 0.




Fig. A/1: Sequence diagram for jogging mode

Overview of parameters involved (see appendix B.1.2)		
Parameters involved	Description	PNU
	Maximum speed for phase 2 in speed unit (inc/s)	531
	Acceleration in acceleration unit (inc/s ²)	532
	Deceleration in deceleration unit (inc/s ²)	533
	Time duration of phase 1 (T1) in ms	534
Start	SFC_DC_CONTROL – Jogging_pos = positive edge: Jogging positive SFC_DC_CONTROL – Jogging_pos = positive edge: Jogging negative	
Reply message	SFC_DC_CONTROL – Drive_is_moving = 1: Drive moves SFC_DC_CONTROL – MC = 0: Motion Complete	
Prerequisites	Device control via PLC/field bus (Drive_Control_FCT_HMI = 0) Controller in status “Drive enabled” (Drive_enabled = 1)	

Tab. A/6: Parameters involved in jogging mode

A.2.4 Teaching via field bus

Position values can be taught via the field bus. Previously taught position values will then be overwritten.

Sequence

1. The drive will be moved to the desired position via jogging mode or manually. This can be accomplished in jogging mode by positioning or by moving by hand in the status "Drive blocked".
2. The user must make sure that the desired parameter is selected. For this the parameter "Teach target" and, if applicable, the correct record address must be entered.

Teach target (PNU 520)	Is taught
= 1 (specification)	Nominal position of the position set – Record Select: Position set after control byte 3 – Direct mode: Position set after PNU = 400
= 2	Axis zero point
= 3	Project zero point
= 4	Lower software end position
= 5	Upper software end position

Tab. A/7: Overview of teach targets

3. Teaching is carried out via the handshake of the bits Teach_Actual_Value and Ack_Teach:




Fig. A/2: Handshake when teaching



Note:
The drive must not stand still for teaching. However, a speed of 1 m/s means that the actual position changes by 1 mm every millisecond. With the usual cycle times of the PLC + field bus + motor controller there will be inaccuracies of several millimetres even at a speed of only 100 mm/s.

Overview of parameters involved (see appendix B.1.2)		
Parameters involved	Description	PNU
	Teach target	520
	Record number	400
Start	SFC_DC_CONTROL – Teach_Actual_Value = falling edge: Teach value	
Reply message	SFC_DC_CONTROL – Ack_Teach = 1: Value transferred	
Prerequisites	Device control via PLC/field bus (Drive_Control_FCT_HMI = 0) Controller in status “Drive enabled” (Drive_enabled = 1)	

Tab. A/8: Teach parameters involved


A.2.5 Carry out record (Record Select)

A record can be started in the status “Drive enabled”.
This function is usually used for:

- moving to any position in the record list by the PLC
- processing a positioning profile by linking records
- known target positions which seldom change (formulation change).

Sequence

1. Set the desired record number in the input Record_No.
Up till the start the controller replies with the number of the record last processed.
2. With a rising edge at Start_Positioning_Task the controller accepts the record number and starts the positioning task.
3. The controller signalizes with the rising edge at Ack_Start that the PLC output data have been accepted and that the positioning task is now active. The positioning command will be processed irrespective of whether Start_Positioning_Task has been reset to zero or not.
4. When the record is concluded, MC is set.



- 1** Prerequisite: Ack_Start = 0
- 2** Rising edge at Start_Positioning_Task causes the new record number N to be accepted and Ack_Start to be set
- 3** As soon as Ack_Start is recognized by the PLC, Start_Positioning_Task may be set to 0 again
- 4** The controller reacts with a falling edge at Ack_Start
- 5** As soon as Ack_Start is recognized by the PLC, the next record number may be started
- 6** A currently running positioning task can be stopped with "Stop"

Fig. A/3: Sequence diagram Start/stop record




Fig. A/4: Sequence diagram for stop record with Halt and continue




Fig. A/5: Sequence diagram for stop record with Halt and delete remaining path

Record composition

A positioning task in Record Select mode is written with one record of nominal values. Each nominal value is addressed by its own PNU. A record consists of the nominal values with the same subindex.

Causes of faults in application:

- referencing has not been carried out
- the target position and/or the preselect position cannot be reached
- invalid record number
- record not initialized.

Overview of parameters involved (see appendix B.1.2)		
Parameters involved	Description	PNU
	Record control byte 1	401
	Nominal value	404
	Speed	406
	Acceleration move towards	407
	Deceleration braking	408
Start	SFC_DC_CONTROL – Start_Positioning_Task = positive edge: Start – Jogging and referencing have priority.	
Reply message	SFC_DC_CONTROL – MC = 0: Motion Complete SFC_DC_CONTROL – Ack_Start = positive edge: Quit Start SFC_DC_CONTROL – Drive_is_moving = 1: Drive moves	
Prerequisites	Device control via PLC/field bus (Drive_Control_FCT_HMI = 0) Controller in status “Drive enabled” (Drive_enabled = 1) Record number must be valid (Record_No = 0 ... 31)	

Tab. A/9: Parameters involved Record Select

A.2.6 Specifying a position directly (Direct mode)

In the status “Drive enabled” (Direct mode) a positioning task is formulated directly in the I/O data which are transmitted via the field bus. The nominal values for the position are therefore held in the PLC. The function is used in the following situations:

- moving to any position within the work stroke.
- the target positions are unknown during planning or change frequently (several different work item positions).

Sequence of discrete nominal value

1. The user sets the desired nominal value (position) and the positioning condition (absolute/relative) in his output data.
2. With a rising edge at Start_Positioning_Task the controller accepts the nominal position and starts the positioning task.
3. After the start you must wait for MC before a new start can be made.
4. When the nominal position is reached, MC is set.




Fig. A/6: Start the positioning task



The sequence of the remaining control and status bits as well as the functions Halt and Stop react as with the function Record Select, see Fig. A/3, Fig. A/4 and Fig. A/5.

Causes of faults in application

- No referencing carried out.
- Target position cannot be reached or lies outside the software end positions.

Overview of parameters involved (see appendix B.1.2)		
Parameters involved	Description	PNU
Position specifications	Max. permitted speed ¹⁾	502
	Acceleration in acceleration unit (inc/s ²)	541
	Deceleration in deceleration unit (inc/s ²)	542
Start	CPOS.B1 = positive edge: Start (CDIR.B0 = nominal position absolute/relative)	
Reply message	SFC_DC_CONTROL – MC = 0: Motion Complete SFC_DC_CONTROL – Ack_Start = positive edge: Quit Start SFC_DC_CONTROL – Drive_is_moving = 1: Drive moves	
Prerequisites	Device control via PLC/field bus (Drive_Control_FCT_HMI = 0) Controller in status “Drive enabled” (Drive_enabled = 1) Valid nominal position is set (Set_Value_Position) Valid nominal speed is set (Set_Value_Velocity)	
¹⁾ In the control bytes the master transfers a percent value which is multiplied by the maximum permitted speed, in order to achieve the final nominal speed.		

Tab. A/10: Parameters involved in Direct mode

A.2.7 Standstill monitoring

With the standstill monitoring it is clear that the target position window is exited at a standstill.

When the target position is reached and the MC signal is registered the drive enters the “Standstill” status, the bit Standstill_Control is reset. If, in this status, the drive is removed from the standstill position window for a minimum defined time due to external forces or other influences, the bit Standstill_Control will be set.

As soon as the drive is in the standstill position window again for the standstill monitoring time, the bit Standstill_Control will be reset.




Fig. A/7: Standstill monitoring

The standstill monitoring cannot be switched on or off explicitly. It becomes inactive when the standstill position window is set to the value “0”.

Overview of parameters involved (see appendix B.1.2)		
Parameters involved	Description	PNU
	Target position window	1040
	Current position	1041
	Standstill position window	1042
	Standstill monitoring time	1043
Start	SFC_DC_CONTROL – MC = positive edge: Motion Complete	
Reply message	SFC_DC_CONTROL – Drive_is_moving = 1: Drive has moved out of standstill position window	
Prerequisites	Device control by PLC/field bus Controller must be in status “Drive enabled”	

Tab. A/11: Parameters involved in standstill monitoring

A.3 Fault messages

The SFC-DC indicates faults by appropriate fault messages or warnings.

Cat-egory	Name, display	Description	Device error ¹⁾	Fault number	Fault LED	Status bytes ²⁾
Fault	POSITION ERROR	Contouring error	0x0001	31	ON	FAULT, DEV
Fault message	MOTOR STOP	Motor emergency stop	0x0002	106	ON	FAULT
Fault	HOMING ERROR	Reference travel fault	0x0004	32	ON	FAULT
Fault	OVERHEATING	Overtemperature (ActTemp > 80)	0x0008	101	ON	FAULT
Fault	LOAD-POWER-DOWN	Undervoltage at controller (load voltage)	0x0010	70	ON	FAULT
Fault	I ² t-ERROR	Overheating (I ² t monitoring)	0x0020	100	ON	FAULT
Fault	HARDWARE ERROR	User data destroyed (checksum fault)	0x0040	52	ON	FAULT
Fault	TARGET POSITION OUT OF LIMIT	Position outside software end positions	0x0080	2	ON	FAULT
Warning	Reserved (LAST POSITION NOT SAVED)		0x0100	54	flashes	WARN
Fault	PLEASE ENFORCE HOMING RUN	Not referenced	0x0200	1	ON	FAULT
Fault	Reserved (POSITION PLAUS. ERROR)		0x0400	35	ON	FAULT
Fault	DIGITAL-POWER-DOWN	Undervoltage at controller (load voltage)	0x0800	71	ON	FAULT
Warning	INDEX PULSE WARNING	Index Pulse Warning	0x1000	–	flashes	WARN
¹⁾ See PNU 205 ²⁾ FHPP status bytes						

Cat-egory	Name, display	Description	Device error ¹⁾	Fault number	Fault LED	Status bytes ²⁾
Fault	MOTOR ERROR	Phase failure (no motor current)	0x2000	103	ON	FAULT
Warning	STANDSTILL WARNING	Standstill monitoring	0x4000	–	flashes	WARN, STILL
Fault	PROFIBUS INIT ERROR	PROFIBUS initialization fault	0x8000	51	ON	FAULT
¹⁾ See PNU 205 ²⁾ FHPP status bytes						

Tab. A/12: Faults and warnings with fault numbers and fault bits

A.4 Diagnostic memory

The diagnostic memory contains the codes of the last 16 diagnostic messages. The diagnostic memory is protected against power failure. If the diagnostic memory is full, the oldest element will be overwritten (FIFO principle).

Structure of the diagnostic memory			
Parameters ¹⁾	200	201	202
Format	uint8	uint16	uint32
Meaning	Diagnostic event	Fault number	Time
Subindex 1	Latest / current diagnostic message		
Subindex 2	Last diagnostic message		
...	...		
Subindex 16	Oldest diagnostic message		
¹⁾ (see appendix B.1.2)			

Tab. A/13: Structure of diagnostic memory

Configuration of the diagnostic memory with parameter 204 (see appendix B.1.2)				
Sub-index	Description	Specificat.	Min.	Max.
1	= 1: Record incoming and outgoing faults = 2: Record only incoming faults	1	1	2
2	= 1: Resolution time stamp 10 ms = 2: Resolution time stamp 1 ms	1	1	2
3	Deleting the diagnostic memory. – Write with value = 1 deletes the diagnostic memory – Read will always be answered with value = 0	0	0	1
4	Number of valid entries in the diagnostic memory	0	0	16

Tab. A/14: Structure of diagnostic memory

The faults are divided into logical groups according to the fault numbers. There are both simple and serious faults within a group.

Range	Name	Comment
0	–	No fault active
1 ... 19	Processing fault	Examples: No reference travel, nominal position outside software end positions, nominal value calculation not possible. Although the system is OK, a user comand cannot be processed. In most cases there is a fault in operation. Source: Sequence control, regulator
20 ... 29	Parameter fault	Example: Software end positions outside the working stroke. A parameter lies within the limit values so that it can be written by the user. During the new calculation of the regulator, it was ascertained that it is not permitted in the context of the other parameters. Note: Non-permitted parameters are rejected by the parameter protocol and do not generate a fault in the controller.
30 ... 49	Regulator	Examples: Positioning timeout, reference travel not successful, contouring error too large, ... The task could not be processed correctly. No hardware fault is recognized here. Source: Regulator
50 ... 69	Initialization	Fault in initializing the controller
70 ... 79	Run time of controller	Fault in controller run time: Undervoltage, checksum
80 ... 89	–	Reserved
90 ... 99	–	Reserved
100 ... 109	Run time of motor	Run time of motor: Undervoltage, overtemperature, ...
110 ... 119	–	Reserved

Tab. A/15: Overview of fault numbers



A detailed description of the warnings and faults can be found in section A.3.

A.5 Diagnosis via PROFIBUS-DP

The SFC-DC supports the following diagnostic possibilities via PROFIBUS-DP:

- FHPP status bytes
(block SFC_DC_Control, see chapter 3.1.3):
 - Warning
 - Fault
 - Contouring_error
 - Standstill_Control
- DP diagnosis (see section A.5.1):
PROFIBUS service “GetDiag” with device-related diagnosis (GbD) when activated.

The alarm model as per DPV1 is not supported.

A.5.1 Structure of the DP diagnosis

Structure of the DP diagnosis

The DP diagnosis of the SFC-DC reacts as per IEC 61158-6 type 3. 16 bytes are reserved in the SFC-DC for DP diagnosis, see Tab. A/16.

Bytes 0 ... 5 are always made available.

Bytes 6 ... 15 are only made available if there is a fault.

Byte	Octet	Diagnostic address	Description
0	1	Station status 1	Gives an overview of the communication status and the general status of the SFC-DC.
1	2	Station status 2	
2	3	Station status 3	
3	4	Master PROFIBUS address	PROFIBUS address of the DP master via which the SFC-DC was parametrized and which has both read and write access.

Byte	Octet	Diagnostic address	Description
4	5	ID number (for SFC-DC = 0973 _H)	Describes the type of the DP slave (here 0973 _H).
5	6		
6	7	Header (for the device-related diagnosis)	Specifies the length of the device-related diagnosis incl. header. ¹⁾
7	8	Status type	With the SFC-DC always 0xA0 (for “manufacturer-specific status”)
8	9	Slot no.	With the SFC-DC always 0x00 (slot is ignored)
9	10	Specifier	With the SFC-DC always 0x00 (no specification of the fault)
10	11	Device-related diagnosis 1: Firmware version number	Version number of the firmware of the SFC-DC: ²⁾ Byte 11: Main version Byte 10: Subsidiary version
11	12		
12	13	Device-related diagnosis 2: Hardware version number	Version number of the hardware of the SFC-DC: ²⁾ Byte 13: Main version Byte 12: Subsidiary version
13	14		
14	15	Device-related diagnosis 3: Fault number	Fault number, see section A.3, Tab. A/12.
15	16		
¹⁾ The SFC-DC enters the value “10” fixed in this octet. ²⁾ e.g. “0x02 0x01” ≙ V1.02			

Tab. A/16: DP diagnosis



The method of requesting the slave diagnosis can be found in the manual for the DP master.

Diagnosis via general DP master



Please note
The identifier-related or channel-related diagnosis listed in IEC 61158-6 type 3 is not supported.

Station status 1

Bit 3 is especially of interest with station status 1. If this bit is set, it is sensible to evaluate the device-related diagnosis.

Station status 1		
Bit	Meaning	Explanation
0	Diag.Station_Non_Existent	SFC-DC no longer/not yet addressable. Possible causes: – Operating voltage not applied – Data cable interrupted – Fault in data cable
1	Diag.Station_Not_Ready	SFC-DC not yet ready for data exchange
2	Diag.Cfg_Fault	The configuration data received from the master are not the same as those ascertained by the SFC-DC.
3	Diag.Ext_Diag	There is a device-related diagnosis. ¹⁾
4	Diag.Not_Supported	1 = The SFC-DC does not support the function requested.
5	Diag.Invalid_Slave_Response	Always 0 (always reset to 0 by the SFC-DC) ²⁾
6	Diag.Prm_Fault	Last parametrizing telegram faulty
7	Diag.Master_Lock	Access by a different master (set by the master)
¹⁾ Is set by the SFC-DC when a new fault occurs (new fault message). ²⁾ Is set to 1 in the DP master when the reply sent by the slave cannot be interpreted.		

Tab. A/17: Structure of station status 1

Station status 2 (only SFC-DC related bits)

Station status 2		
Bit	Meaning	Explanation
0	Diag.Prm_Req	1 = The master must configure the SFC-DC again
1	Diag.Stat_Diag	1 = The master must request diagnostic data until this bit is set to 0
2	–	Always 1 (set to logical 1 by the SFC-DC)
3	Diag.WD_On	1 = Response monitoring/watchdog activated
4	Diag.Freeze_Mode	1 = Freeze activated
5	Diag.Sync_Mode	1 = Sync activated
6	–	Reserved
7	Diag.Deactivated	Always 0 (always reset to 0 by the SFC-DC)

Tab. A/18: Diagnostic bits of station status 2

Station status 3

Station status 3		
Bit	Meaning	Explanation
0...6	–	Reserved
7	Diag.Ext_Diag_Overflow	Is always logical 0 (set by the SFC-DC)

Tab. A/19: Diagnostic bits of station status 3

Supplementary information

Appendix B

Contents

B. Supplementary information B-1

B.1 Parameters of the SFC-DC B-3

 B.1.1 General parameter structure B-3

 B.1.2 Overview of parameters B-4

B.1 Parameters of the SFC-DC

B.1.1 General parameter structure

Group	Indices	Description
Device data	100 ... 199	Device identification and device-specific settings, version numbers, identifier words, etc.
Diagnostic memory	200 ... 299	Memory for diagnostic events: Fault numbers, fault time, incoming/outgoing event
Processing data	300 ... 399	Current nominal and actual values, local I/Os, status data etc.
Record list	400 ... 499	A record contains all the nominal value parameters required for a positioning procedure
Project data	500 ... 599	Basic project settings. Maximum speed and acceleration, offset project zero point etc. → Parameters are the basis for the record list.
Factor group	600 ... 699	Reserved
Axis data Electric drives 1	1000 ... 1099	All axis-specific parameters for electric drives. Gear factor, feed constant, reference parameter ...

B.1.2 Overview of parameters

This overview shows all the parameters of motor controller type SFC-DC-...-PB with firmware version 1.10.



The current and complete description of the parameters can be found in the manual for the SFC-DC.

Name	FHPP			
	PNU	Subind. ¹⁾	Type	Access ²⁾
Device data				
Standard parameters				
Manufacturer Hardware Version (hardware version of manufacturer)	100	–	uint16	ro
Manufacturer Firmware Version (firmware version of manufacturer)	101	–	uint16	ro
Version FHPP	102	–	uint16	ro
Controller Serial Number	114	0...11	char	ro
Extended parameters				
Manufacturer Device Name (device name of manufacturer)	120	0...23	char	ro
User Device Name (device name of user)	121	0...23	char	rw1
Drive Manufacturer (manufacturer name)	122	0...29	char	ro
HTTP Drive Catalogue Address (HTTP address of manufacturer)	123	0...29	char	ro
Festo Order Number	124	0...29	char	ro
Device Control	125	–	uint8	rw2
HMI Parameters (MMI parameters)	126	0...3	uint8	rw1
Data Memory Control	127	0...1	uint8	wo

¹⁾ Subindices of the parameter for FHPP with access via parametrizing blocks (0...n-1)

²⁾ ro = read only; wo = write only; rw/rw1 = read and write at any time;
 rw2 = read and write during commissioning

B. Supplementary information

Name	FHPP			
	PNU	Subind. ¹⁾	Type	Access ²⁾
Diagnosis				
Diagnostic Event	200	0...15	uint8	ro
Fault Number	201	0...15	uint16	ro
Time Stamp	202	0...15	uint32	ro
Diagnostic Memory Parameter	204	0...3	uint8	rw1/ro
Device Fault	205	–	uint16	rw
PROFIBUS Diagnosis	206	0...5	uint8	ro
Processing data				
Local Digital Inputs	303	–	uint32	ro
Local Digital Outputs	304	0...1	uint32	rw1
Cycle Number	305	–	uint32	ro
Record list				
Record Number	400	–	uint8	rw1
Record Control Byte 1	401	0...31	uint8	rw1
Record Target Position	404	0...31	int32	rw1
Record Velocity (positioning record speed)	406	0...31	uint32	rw1
Record Acceleration	407	0...31	uint32	rw1
Record Deceleration	408	0...31	uint32	rw1
¹⁾ Subindices of the parameter for FHPP with access via parametrizing blocks (0...n-1) ²⁾ ro = read only; wo = write only; rw/rw1 = read and write at any time; rw2 = read and write during commissioning				

B. Supplementary information

Name	FHPP			
	PNU	Subind. ¹⁾	Type	Access ²⁾
Project data				
Project data – general project data				
Project Zero Point (offset project zero point)	500	–	int32	rw2
Software End Positions	501	0...1	int32	rw2
Max. Velocity (max. permitted speed)	502	–	uint32	rw2
Max. Acceleration (max. permitted acceleration)	503	–	uint32	rw2
Project data – Teach				
Teach Target	520	–	uint8	rw2
Project data – jogging mode				
Jog Mode Velocity Phase 2 (jog mode speed phase 2)	531	–	int32	rw2
Jog Mode Acceleration	532	–	uint32	rw2
Jog Mode Deceleration	533	–	uint32	rw2
Jog Mode Time Phase 1	534	–	uint32	rw2
Project data – direct mode positioning				
Direct Mode Acceleration	541	–	uint32	rw2
Direct Mode Deceleration	542	–	uint32	rw2
¹⁾ Subindices of the parameter for FHPP with access via parametrizing blocks (0...n-1) ²⁾ ro = read only; wo = write only; rw/rw1 = read and write at any time; rw2 = read and write during commissioning				

B. Supplementary information

Name	FHPP			
	PNU	Subind. 1)	Type	Access 2)
Axis data electric drives 1				
Axis data electric drives 1 – mechanical				
Polarity (change of polarity)	1000	–	uint8	rw2
Encoder Resolution	1001	0...1	uint32	rw2
Gear Ratio	1002	0...1	uint32	rw2
Feed Constant	1003	0...1	uint32	rw2
Position Factor	1004	0...1	uint32	ro
Axis Parameter	1005	0...4	uint32	rw2
Axis data electric drives 1 – reference travel				
Offset Axis Zero Point	1010	–	int32	rw2
Homing Method (reference travel method)	1011	–	uint8	rw2
Homing Velocities (reference travel speeds)	1012	0...1	uint32	rw2
Homing Required (reference travel necessary)	1014	–	uint8	ro
Homing Max. Torque (reference travel max. torque)	1015	–	uint8	rw2
Axis data electric drives 1 – control parameters				
Hold Option Code	1020	–	uint16	rw2
Fault Reaction Option Code	1021	–	uint16	rw2
Position Window (tolerance window position)	1022	–	uint32	rw2
Position Window Time (adjustment time position)	1023	–	uint16	rw2
Position Control Parameter Set (parameters of the position controller)	1024	17...20, 22, 31	uint16	rw2
Motor Data	1025	0, 2	uint32	ro/rw
Drive Data	1026	0...7	uint32	ro/rw2
¹⁾ Subindices of the parameter for FHPP with access via parametrizing blocks (0...n-1) ²⁾ ro = read only; wo = write only; rw/rw1 = read and write at any time; rw2 = read and write during commissioning				

B. Supplementary information

Name	FHPP			
	PNU	Subind. ¹⁾	Type	Access ²⁾
Axis data electric drives 1 – electronic type plate				
Motor Type	1030	–	uint16	rw2
Maximum Current	1034	–	uint16	rw2
Motor Rated Current	1035	–	uint32	rw2
Axis data electric drives 1 – standstill monitoring				
Position Target Value (nominal position)	1040	–	int32	ro
Position Actual Value (current position)	1041	–	int32	ro
Contouring Error Window (standstill position window)	1042	–	uint32	rw2
Contouring Error Timeout (standstill monitoring time)	1043	–	uint16	rw2
¹⁾ Subindices of the parameter for FHPP with access via parametrizing blocks (0...n-1) ²⁾ ro = read only; wo = write only; rw/rw1 = read and write at any time; rw2 = read and write during commissioning				

Tab. B/1: Overview of FHPP parameters

Index

Appendix C

A

Axis zero point XVI

B

BCD XVIII

C

Consistency XVIII
Controller XVI

D

Diagnosis
 Fault A-23
 PROFIBUS-DP A-27
 Structure of the DP diagnosis A-27
Diagnostic memory A-25
Direct mode A-3
Drive XVI

E

Electric axis XVI
Encoder XVI

F

Fault A-23
Fault numbers 4-16, A-26
Festo Parameter Channel (FPC) XVI
FHPP 1-5

G

GSD file XVIII, 2-3

I

Icon files 2-3
Important user instructions XI
Increments 4-5, A-6

J

Jog mode XVI

L

LSB XVIII

M

Measuring system A-6
Measuring units 4-5
MSB XVIII

O

Octet XVIII
Operating mode XVII, A-3
 Direct mode A-3
 Positioning mode XVII
 Record Select A-3
 Teach mode XVIII

P

Parameter channel (PKW)	XVIII
Parameter identifier (PKE)	XVIII
Parameter number (PNU)	XIX
Parameters of the SFC-DC	B-3
Parametrizing	
Measuring system	A-6
Pictograms	XII
PKE	XIX
PKW	XIX
PLC	XVII
PNU	XIX
Position set	XVII
Positioning mode	XVII
PROFIBUS	XIX
PROFIBUS address	XIX
PROFIBUS-DP	
Diagnosis	A-27
Profile position mode	XVII
Project zero point	XVII

R

Record Select	A-3
Reference system	A-5
Reference travel	XVII
Referencing	XVII
Reference point	XVII
Reference switch	XVII
Referencing method	XVII
Reply telegram	XIX
Response identifier (AK)	XIX

S

Safety instructions IX

Service X

SLTE XVII

Software end position XVIII

 Negative XVIII

 Positive XVIII

Subindex (IND) XIX

T

Target group X

Task identifier (AK) XIX

Task telegram XIX

Teach mode XVIII

Terminating resistor XIX

Text markings XII

V

Version XV

W

Work data XIX

Work range

 Software end position XVIII