

ECOVARIO®, **ECOSTEP®**
Use of the JAT Function Blocks for
Profibus® Servo Amplifiers acc. to DS402

Revisions:

Edition	Comment
November 2019	First English edition
January 2020	Chapter 5.2: Correction of the utilized controls

Imprint

All right reserved:

Jenaer Antriebstechnik GmbH

Buchaer Straße 1

07745 Jena

Germany

No parts of this document may be translated, reprinted or reproduced on microfilm or in other ways without written permission by Jenaer Antriebstechnik GmbH.

The content of this document has been worked out and checked carefully. Nevertheless differences from the real state of the hard and software can never be fully excluded. Necessary corrections will be carried out in the next edition.

Profibus® and PROFIdrive® are registered trademarks of PROFIBUS Nutzerorganisation e.V. PNO.
ECOVARIO® and ECOSTEP® are registered trademarks of Jenaer Antriebstechnik GmbH, Jena.

Table of Contents

1	About this document	3
2	About CAN DS402	3
3	About PROFibus® DP	4
4	Requirements for use	4
5	Installation procedure	5
5.1	Exemplary projects	5
5.2	Utilized controls	5
5.3	Project set-up	5
6	Function blocks descriptions	6
6.1	Project overview	6
6.2	Specific project blocks	7
6.3	FB ECOVARIO	8
6.4	FB ECODUAL	8
6.5	FB ECOSTEP	9
6.6	PZDtoAxisDB_DS402	10
6.7	AxisDBtoPZD_DS402	11
6.8	JAT-Axis_DS402	12
6.8.1	Extended input signal function description	13
6.8.2	AxisDB_DS402_Ax	14
6.9	JAT SDO Tunnel (FB RWVALUE/FB RWVALUED)	17
6.9.1	RWVALUE	18
6.9.2	RWVALUED	19
6.10	JAT CAN tunnel	20
7	User-defined data types	21
7.1	UDT_PAE_DS402	21
7.2	UDT_PAA_DS402	21
7.3	UDT_control_DS402	21
7.4	UDT_status_DS402	21
8	Troubleshooting	22
8.1	Warnings	22
8.2	Errors	22
9	Comparison TIA portal / Classic world	23
9.1	STEP7 classic world	23
9.1.1	Description	23
9.2	TIA portal world	24
10	Manual integration of JAT drives	25
10.1	1-axis drive	26
10.2	2-axis drive	27

11	General information regarding JAT with PROFibus®	28
12	Information regarding the universal module in SIEMENS controllers	29

1 About this document

This manual describes the integration procedure of the servo amplifiers ECOVARIO® and ECOSTEP® according to DS402 with PROFIBUS® interface into a PROFIBUS® network (master: Siemens Simatic controller S7) with the help of the JAT function blocks.

The requirement is an existing physical connection between servo amplifier and the PROFIBUS® master via the interface X22 (ECOVARIO® 114xx-[G,F][J,L]-xxx-xxx, ECOVARIO® 214xx-[G,F]-xxx-xxx, ECOVARIO® 414xx-[G,F]-xxx-xxx, ECOVARIO®616xx-[G,F]-xxx-xxx) or X1.

Further information:

- Hardware installation: installation and commissioning manual ECOVARIO® and ECOSTEP®
- Documentation by Siemens for the program package STEP 7 and the TIA portal
- Software commissioning: ECOSTUDIO® manual or online help
- Programming: Software tool ECOSTUDIO®, Manual Object Dictionary ECOVARIO®, ECOSTEP®, etc.

Requirements to personnel handling ECOVARIO® or ECOSTEP®:

Transport Personnel trained in handling electrostatic-sensitive devices.

Installation Electro-technically trained personnel who know the security directives of electrical engineering and automation.

Commissioning Qualified personnel with a broad knowledge of electrical engineering, automation and drives.

Knowledge of the use of the STEP7 PLC program package is required for the functional integration of the servo drives in a Profibus® network.

⚠ WARNING	
	<p>Failure to observe the safety instructions when handling the drive system</p> <p>Risk of life or injury</p> <ul style="list-style-type: none"> ➤ When handling the drive system, it is essential to observe the safety instructions in the above manuals.



INFORMATION

The examples listed are only to be understood as such and reflect the basic procedure for integrating the drive. In the specific application, the user must check whether all functional and safety-relevant conditions have been met.

2 About CAN DS402

The profile specifications CAN DS 402 standardize the behaviour of controller and servo drive functions. Additionally, various operating modes and their corresponding configuration parameters are defined. The profile description contains a Finite-State-Automaton (FSA) that defines the internal and external device behaviour for every status. The status of the servo amplifier regulates which commands are accepted. Changes of state are triggered when a control word is received by the host controller or by internally happening events. The actual state is represented by the status word. The control word and various command values (e.g. velocity) are mapped to standard Rx PDOs (Receive Process Data Objects). The status word and various actual values (e.g. position) are mapped to Tx PDOs (Transmit Process Data Objects).

3 About PROFibus® DP

PROFibus® is a non-proprietary, open fieldbus standard with a wide scope in the manufacturing and process automation. Die European standard EN 50170 describes three PROFibus® forms: FMS, DP and PA.

PROFibus® DP (Decentralized Peripherals) is optimized for speed, efficiency and low connection costs and is especially designed for the communication between automation systems and decentralized peripherals. Therefore, it is perfectly fit for controlling highly-dynamic drives such as ECOVARIO® and ECOSTEP® through a higher-level control system.

PROFibus® DP operates according to the master / slave principle with overlaid token passing between different masters, if required. The master / slave communication is strictly cyclical, whereby the bus' time monitoring ensures that a failure of either master or slave is recognized almost instantly. Additionally, a standardized slave analysis through a master is implemented, offering extensive possibilities to transmit error and status information. A PROFibus® DP device is identified through a configurable address. Furthermore, every device class has a so called *ID number* that is identical for all devices of the same type.

4 Requirements for use

Controlling the JAT drives via PROFibus® requires the following components (if deviations occur, please contact us):

- Servo amplifier ECOVARIO® or ECOSTEP® with PROFibus® interface
- Siemens SIMATIC control system S7-1500 / S7-300
- Suitable communication processors (CP) for the S7-1200 / S7-1511 control system
- Software suite *Totally Integrated Automation Portal* (TIA portal), V 15.1 or higher by Siemens
- Service PC with commissioning tool ECOSTUDIO® V 3.2.0.0 or higher
- Additional S7-SCL package by Siemens (JAT building blocks are programmed with SCL). If the additional package is not available, the JAT building blocks can still be used, but there is no possibility for adjustment
- The current GSD file, e.g. as [download from our website](#)
- The JAT package *FB PROFibus®* (function blocks ECOVARIO®, ECOSTEP®) which contains the elements listed in chapter 6

For wiring the components via PROFibus®, please consider the *Installation manual* ECOVARIO® or ECOSTEP® as well as the *SIMATIC control documentation*.

5 Installation procedure

5.1 Exemplary projects

To develop an understanding of the drive management, the function blocks package *FB PROFIBUS®* (function blocks ECOVARIO® and ECOSTEP®) contains the following exemplary projects for integration into the TIA-Portal

- YYYYMMDD_S7-1200CP_DP_DS402_V15_1.zap15_1
- YYYYMMDD_S7-1500CP_DP_DS402_V15_1.zap15_1
- YYYYMMDD_S7-1516_DP_DS402_V15_1.zap15_1
- YYYYMMDD_S7-300_DP_DS402_V15_1.zap15_1

To integrate into the programming environment STEP 7, use the following project

- YYYYMMDD_S7-300_DP_DS402_classic.zip

5.2 Utilized controls

- S7-314-2 PN/DP
- S7-1215 C DC/DC/DC + CM 1243-5
- S7-1511-1 PN + CP 1542-5
- S7-1516-3 DP/PN

5.3 Project set-up

- Load an exemplary project → unpack project
- Adjust to the control environment → adjust device configuration
- Configuration overview → within the projects, there are a ECOVARIO®, a ECODUAL (ECOVARIO® 114D / 616D) and a ECOSTEP® listed




Figure 1: Exemplary system configuration

6 Function blocks descriptions

6.1 Project overview

Access to JAT axes according to DS402 in a SIEMENS control system via PROFIBUS®:




Figure 2: Project overview

6.2 Specific project blocks


Table 1: List of specific project blocks

Type	Symbolic name	Description
OB1	Main	Main program <i>organisation block</i> , is executed permanently
DB	AxisDB_DS402_Ax	Storage space for axis image
FB	ECOVARIO	Application example for the function blocks for 1-axis ECOVARIO®
FB	ECODUAL	Application example for the function blocks for ECOVARIO® DUAL (2-axis: 114D / 616D)
FB	ECOSTEP	Application example for the function blocks for ECOSTEP®
FB	JAT-Axis_DS402	Function block to control the JAT servo amplifier (according to DS402)
FB	RWVALUE	Acyclical reading /writing of parameters for 1-axis servo amplifiers
FB	RWVALUED	Acyclical reading /writing of parameters for 2-axis servo amplifiers
FC	PZDtoAxisDB_DS402	Read axis data from process image
FC	AxisDBtoPZD_DS402	Write axis data into process image
UDT	UDT_Axis_Control_DS402	Input data type axis-status
UDT	UDT_Axis_Status_DS402	Output data type axis-status
UDT	UDT_PAE_DS402	Input data type process data
UDT	UDT_PAA_DS402	Output data type process data
DB	CTRLRW	Data for acyclical reading / writing of ECOVARIO® parameters
DB	CTRLRWD	Data for acyclical reading / writing of ECOVARIO® DUAL parameters
DB	CTRLRWS	Data for acyclical reading / writing of ECOSTEP® parameters


Table 2: Used abbreviations

Abbreviation	Meaning
OB	Organisation block
DB	Data block (data storage area)
FB	Function block
FC	Function
UDT	User-defined data type


6.3 FB ECOVARIO

Name	JAT-FB_SFC	
Type	Function block	
Input parameter	Data type	Comment
Output parameter	Data type	Comment
Graphical representation		
Function description	Exemplary FB application for ECOVARIO®	


6.4 FB ECODUAL

Name	JAT-FB_SFC	
Type	Function block	
Input parameter	Data type	Comment
Output parameter	Data type	Comment
Graphical representation		
Function description	Exemplary FB application for ECOVARIO® DUAL	

6.5 FB ECOSTEP

Name	JAT-FB_SFC	
Type	Function block	
Input parameter	Data type	Comment
Output parameter	Data type	Comment
Graphical representation		
Function Description	Exemplary FB application for ECOSTEP®	


6.6 PZDtoAxisDB_DS402

Name	PZDtoAxisDB_DS402	
Type	Function	
Input parameter	Data type	Comment
PAE_PZD1_STATUS	Word	ZSW from Drive (from variable table)
PAE_PZD2_TARGET_POS	DWord	Target pos from Drive (from variable table)
PAE_PZD3_POS_ACT_VALUE	DWord	Pos actual value from Drive (from variable table)
PAE_PZD4_DETECT_FAULT	DWord	detect fault from Drive (from variable table)
PAE_PZD5_MODES_OF_OP_DISPLAY	Byte	Modes of Operation Display from Drive
Output parameter	Data type	Comment
Axis_DB	UDT_PAE_DS402	to Axis_DB_Ax for axis no x
Graphical representation		
Function description	Read drive process data	

6.7 AxisDBtoPZD_DS402

Name	AxisDBtoPZD_DS402	
Type	Function	
Input parameter	Data type	Comment
Axis_DB	UDT_PAE_DS402	from Axis_DB_Ax for axis no x
Output parameter	Data type	Comment
PAA_PZD1_CONTROLWORD	Word	STW to Drive (from variable table)
PAA_PZD2_TARGET_VEL	DWord	Target velo to Drive (from variable table)
PAA_PZD3_TARGET_POS	DWord	Target Pos to Drive (from variable table)
PAA_PZD4_PROFIL_VEL	DWord	Profil velo to Drive (from variable table)
PAA_PZD5_MODES_OP	Byte	Mode of Operation to Drive (from variable table)


Graphical representation



Function description

Write drive process data

6.8 JAT-Axis_DS402

Name	JAT-Axis_DS402	
Type	Function block	
Input parameter	Data type	Comment
PZD_INPUT	UDT_PAE_DS402	Input axis process data
Control_INPUT	UDT_control_DS402	Input axis status image
b_ENABLE	Bool	enable FB state machine
b_Reset	Bool	reset Drive
b_Switch_ON	Bool	switch on drive
b_Switch_OFF	Bool	switch off drive
b_Homing	Bool	run homing
b_Move	Bool	move drive
b_Stop	Bool	stop
b_Quick_STOPP	Bool	quick stop
b_Velocity	Bool	velocity
Output parameter	Data type	Comment
PZD_OUTPUT	UDT_PAA_DS402	Output axis process data
Status_OUTPUT	UDT_status_DS402	Output axis status image
Graphical representation	 <pre> graph TD subgraph DB18 [DB18] JAT_Axis_DS402_DB["JAT-Axis_DS402_DB"] end subgraph FB3 [FB3] JAT_Axis_DS402_FB["JAT-Axis_DS402"] end EN --- JAT_Axis_DS402_FB JAT_Axis_DS402_FB --- ENO PZD_INPUT --- JAT_Axis_DS402_FB JAT_Axis_DS402_FB --- PZD_OUTPUT Control_INPUT --- JAT_Axis_DS402_FB JAT_Axis_DS402_FB --- Status_OUTPUT b_ENABLE --- JAT_Axis_DS402_FB b_Reset --- JAT_Axis_DS402_FB b_Switch_ON --- JAT_Axis_DS402_FB b_Switch_OFF --- JAT_Axis_DS402_FB b_Homing --- JAT_Axis_DS402_FB b_Move --- JAT_Axis_DS402_FB b_Stop --- JAT_Axis_DS402_FB b_Quick_STOPP --- JAT_Axis_DS402_FB b_Velocity --- JAT_Axis_DS402_FB </pre>	
Function description	FB to control JAT servo amplifiers (DS402)	

6.8.1 Extended input signal function description

Signal	Description	Control
b_ENABLE	Switch on / off internal state machine of FB	static at high level
b_Reset	Servo amplifier reset (output stage shut down)	Edge
b_Switch_ON	Switch on output stage	Edge
b_Switch_OFF	Switch off output stage	Edge
b_Homing	Execute homing procedure depending on controller settings	Edge
b_Move	Execute absolute or relative movement, depending on configuration (see AxisDB_DS402)	Edge
b_Stop	Stop current movement	Edge
b_Quick_STOPP	Stop axis with quickstop, behaviour dependent on controller configuration	Edge
b_Velocity	Axis in velocity mode (BA3)	Static

6.8.2 AxisDB_DS402_Ax

Table 3: AxisDB_DS402_Ax, PZD_Input

Name	Data type	Starting value	Observed value	Remanence	Accessible	Visible	Settings	Comment
PZD_Input	UDT_PAE_DS402			F	T	T	T	
R_STATUSWORD	Word	16#0	16#0040	F	T	T	T	Status word (Object 6041)
R_TARGET_POS	DWord	16#0	16#0000_0000	F	T	T	T	Read target position (Object 607A)
R_POS_ACT_VALUE	DWord	16#0	16#0000_0000	F	T	T	T	Actual position value(Object 6063)
R_DETECT_FAULTS	DWord	16#0	16#0000_0000	F	T	T	T	Actual error status (Object 2600)
R_MODE_OF_OP_DISPLAY	Byte	16#0	16#00	F	T	T	T	

*) T = True, F = False

Table 4: AxisDB_DS402_Ax, Control_In

Name	Data type	Starting value	Observed value	Remanence	Accessible	Visible	Settings	Comment
Control_In	UDT_control_DS402			F	T	T	T	
r_TARGET_VEL_DINT	Real	0.0	0.0	F	T	T	T	Next target velocity (°/s or mm/s)
r_TARGET_POS_DINT	Real	0.0	0.0	F	T	T	T	Next target position (° or mm)
r_PROFIL_VEL_DINT	Real	0.0	0.0	F	T	T	T	Next profile velocity (°/s or mm/s)
b_rel_abs	Bool	False	False	F	T	T	T	0 = rel or 1 = abs positioning
b_abs3F	Bool	False	False	F	T	T	T	Direct absolute positioning (3F)
b_InkGeber	Bool	True	True	F	T	T	T	1 = with incremental encoder
r_mechanic	Real	1000.0	1000.0	F	T	T	T	inc/° oder inc/mm

*) T = True, F = False

Table 5: AxisDB_DS402_Ax, Status_out

Name	Data type	Starting value	Observed value	Remanence	Accessible	Visible	Settings	Comment
Status_out	UDT_status_DS402							
L_DETECT_FAULTS_OLD	DWord	16#0	16#0000_0000	F	T	T	T	Last error
b_RUN	Bool	False	False	F	T	T	T	Run operation
b_DONE	Bool	False	False	F	T	T	T	Operation done
b_ERROR	Bool	False	False	F	T	T	T	Error during operation
s_Step	String[20]	"	' '	F	T	T	T	Debug String
w_ZSW1	Word	16#0	16#0040	F	T	T	T	
di_XIST_Position	Dint	0	0	F	T	T	T	Actual position as DINT
r_XIST_Position	Real	0.0	0.0	F	T	T	T	Actual position as REAL
b_00_Ready_to_switch_on	Bool	False	False	F	T	T	T	Status word Bits (ZSW1)
b_01_Switched_on	Bool	False	False	F	T	T	T	
b_02_Operation_enable	Bool	False	False	F	T	T	T	
b_03_Fault	Bool	False	False	F	T	T	T	
b_04_Voltage_enable	Bool	False	False	F	T	T	T	
b_05_Quick_stop_not_activated	Bool	False	False	F	T	T	T	
b_06_Switch_on_disable	Bool	False	False	F	T	T	T	
b_07_Warning	Bool	False	False	F	T	T	T	
b_08_Manufacturer_specific	Bool	False	False	F	T	T	T	
b_09_Reserved	Bool	False	False	F	T	T	T	
b_10_Target_position_reached	Bool	False	False	F	T	T	T	
b_11_Internal_limit_active	Bool	False	False	F	T	T	T	
b_12_Reserved	Bool	False	False	F	T	T	T	
b_13_Reserved	Bool	False	False	F	T	T	T	
b_14_Commutation_found	Bool	False	False	F	T	T	T	
b_15_Reference_found	Bool	False	False	F	T	T	T	
Error	Word	16#0	16#0000	F	F	F	F	from_GET_ER_ID() local error
*) T =True, F =False								

Table 6: AxisDB_DS402_Ax, PZD_Output

Name	Data type	Starting value	Observed value	Remanence	Accessible	Visible	Settings	Comment
PZD_Output	UDT_PAA_DS402			F	T	T	T	
W_CONTROLWORD	Word	16#0		F	T	T	T	Control word(object 6040)
W_TARGET_VEL	DWord	16#0		F	T	T	T	Target velocity in inc/64s (object 60FF)
W_TARGET_POS	DWord	16#0		F	T	T	T	Target position in inc (object 607A)
W_PROFIL_VEL	DWord	16#0		F	T	T	T	Profile velocity in inc/64s (object 6081)
W_MODES_OP	Byte	16#0		F	T	T	T	Operating mode (object 6060)
*) T = True, F = False								

6.9 JAT SDO Tunnel (FB RWVALUE/FB RWVALUED)

This configuration enables sending and receiving SDO messages. They are transmitted in the following format (Modul R/W Registers (9Byte DI/DO) and R/W Registers (8Byte DI/DO)):

- Byte 0: Index High byte
- Byte 1: Index Low byte
- Byte 2: Subindex
- Byte 3: Command
- Byte 4: Data byte 3
- Byte 5: Data byte 2
- Byte 6: Data byte 1
- Byte 7: Data byte 0
- Byte 8: Axis index (only used with multi-axis devices)

With 1-axis devices in the state *Data Exchange*, 8 bytes of data are exchanged in both directions. Multi-axis devices use 9 bytes, the last byte of a message transmission contains the axis index.

Special module JAT SDO tunnel for 1-axis devices

R/W Registers (8 Byte DI/DO) format in check_config package: 0xC3, 0x87, 0x87, 0x00, 0x00, 0x00

Example: Use in state *Data Exchange*

- 0x60 0x40 0x00 0x20 0x00 0x00 0x00 0x86 (reset device error / x20 = write)
- 0x21 0x00 0x01 0x40 0x00 0x00 0x00 0x00 (read universal variable 00 / x40 = read)

Special module JAT SDO tunnel for multi-axis devices

R/W Registers (9 Byte DI/DO) format in check_config package: 0xC3, 0x88, 0x88, 0x00, 0x00, 0x00


Example: Use in state *Data Exchange*

- 0x60 0x40 0x00 0x20 0x00 0x00 0x00 0x86 0x00 (reset device error axis 1)
- 0x21 0x00 0x05 0x40 0x00 0x00 0x00 0x00 0x01 (read variable unimappv_4 axis 2)

6.9.1 RWVALUE

Name		RWVALUE
Type		Function block
Input parameter	Data type	Comment
unimode	Int	Peripheral address INPUT UNIVERSALE MODULE
unimoda	Int	Peripheral address OUTPUT UNIVERSALE MODULE
object	Word	Parameter object number in ECOVARIO®
objectsub	Byte	Parameter subindex in ECOVARIO®
wvalue	DWord	Value to be written
operation	Bool	Read = 0; Write = 1
start	Bool	Starting reading
Output parameter	Data type	Comment
rvalue	DWord	Read value
run	Bool	Feedback from FB state machine
done	Bool	Feedback from FB state machine
error	Bool	Feedback from FB state machine

Graphical representation



Function description


Acyclical reading / writing of parameters (SDO) for 1-axis devices
 Input signal: start → 1 = start writing with edge FALSE → TRUE
 Output data: rvalue → read value; 0x00000000 with writing operation
 Output signals:

- run → 1 = FB operates
- done → 1 = Operation successful
- error → 1 = Error during operation

6.9.2 RWVALUED

Name	JAT-RDWR_PAP	
Type	Function Block	
Input parameter	Data type	Comment
unimode	Int	Peripheral address INPUT UNIVERSALE MODULE
unimoda	Int	Peripheral address OUTPUT UNIVERSALE MODULE
object	Word	Parameter object number in ECOVARIO®
objectsub	Byte	Parameter subindex in ECOVARIO®
wvalue	DWord	Value to be written
operation	Bool	Read = 0; Write = 1
axisnum	Bool	Axis number: FALSE → 0, TRUE → 1
start	Bool	Start reading
Output parameter	Data type	Comment
rvalue	DWord	Read value
run	Bool	Feedback from FB state machine
done	Bool	Feedback from FB state machine
error	Bool	Feedback from FB state machine

Graphical representation



Function description

Acyclical reading / writing of parameters (SDO) for 2-axis devices
 Input signal: start → 1 = start writing with edge FALSE → TRUE
 Output data: rvalue → read value; 0x00000000 with writing operation
 Output signals:

- run → 1 = FB operates
- done → 1 = Operation successful
- error → 1 = Error during operation

6.10 JAT CAN tunnel

The ECODUAL 2-axis servo drive additionally the **CAN tunnel module** R/W CAN-Reg (9Byte DI/DO_1). This encodes the data into the format seen below. The **function blocks RWVALUE / RWVALUED do not support this module.**

This module allows to process SDO messages as if it were a CAN bus. Data are transmitted in the following format:

- Byte 0: Command
- Byte 1: Index low byte
- Byte 2: Index high byte
- Byte 3: Subindex
- Byte 4: Data byte 0
- Byte 5: Data byte 1
- Byte 6: Data byte 2
- Byte 7: Data byte 3
- Byte 8: Axis index (only in use on multi-axis devices)

Special module JAT CAN Tunnel for 1-axis devices

R/W Registers (8 Byte DI/DO1) format in check_config package: 0xC3, 0x87, 0x87, 0x00, 0x00, 0x01

Example: Use in state *Data Exchange*

- 0x20 0x40 0x60 0x00 0x86 0x00 0x00 0x00 (Rücksetzen der Gerätefehler)

Special module JAT CAN Tunnel for multi-axis devices

R/W Registers (9 Byte DI/DO1) format in check_config package: 0xC3, 0x88, 0x88, 0x00, 0x00, 0x01

Example: Use in state *Data Exchange*

- 0x20 0x40 0x60 0x00 0x86 0x00 0x00 0x00 0x01 (reset device errors axis 2)
- 0x40 0x00 0x21 0x05 0x00 0x00 0x00 0x00 0x00 (read variable unimappv_4 from axis 1)

7 User-defined data types

7.1 UDT_PAE_DS402

UDT_PAE_DS402								
	Name	Datentyp	Defaultwert	Erreichbar a...	Schrei...	Sichtbar i...	Einstellwert	Kommentar
1	<input type="checkbox"/> R_STATUSWORD	Word	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Statuswort (Objekt 6041)
2	<input type="checkbox"/> R_TARGET_POS	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	read Target Position (Objekt 607A)
3	<input type="checkbox"/> R_POS_ACT_VALUE	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Position actual Value (Objekt 6063)
4	<input type="checkbox"/> R_DETECT_FAULTS	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	current error (Objekt 2600)
5	<input type="checkbox"/> R_MODE_OF_OP_DISPLAY	Byte	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Figure 3: Read axis process data

7.2 UDT_PAA_DS402

UDT_PAA_DS402								
	Name	Datentyp	Defaultwert	Erreichbar a...	Schrei...	Sichtbar i...	Einstellwert	Kommentar
1	<input type="checkbox"/> W_CONTROLWORD	Word	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Controlwort (Objekt 6040)
2	<input type="checkbox"/> W_TARGET_VEL	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Target velocity in Inkr./64s (Objekt 60FF)
3	<input type="checkbox"/> W_TARGET_POS	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Target position in Inkr. (Objekt 607A)
4	<input type="checkbox"/> W_PROFIL_VEL	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Profil velocity in Inkr./64s (Objekt 6081)
5	<input type="checkbox"/> W_MODES_OP	Byte	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Modes of Operation (Objekt 6060)

Figure 4: Output axis process data

7.3 UDT_control_DS402

UDT_control_DS402								
	Name	Datentyp	Defaultwert	Erreichbar a...	Schrei...	Sichtbar i...	Einstellwert	Kommentar
1	<input type="checkbox"/> r_TARGET_VEL_DINT	Real	0.0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	next Target velocity (°/s or mm/s)
2	<input type="checkbox"/> r_TARGET_POS_DINT	Real	0.0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	next Target position (° or mm)
3	<input type="checkbox"/> r_PROFIL_VEL_DINT	Real	0.0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	next Profil velocity (°/s or mm/s)
4	<input type="checkbox"/> b_rel_abs	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0= rel. or 1 = abs. positioning
5	<input type="checkbox"/> b_abs3F	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	direct absolut positioning (3F)
6	<input type="checkbox"/> b_InkGeber	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1 = with Incremental Encoder
7	<input type="checkbox"/> r_mechanic	Real	0.0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	incl° or incl/mm

Figure 5: Image read axis status

7.4 UDT_status_DS402

UDT_status_DS402								
	Name	Datentyp	Defaultwert	Erreichbar a...	Schrei...	Sichtbar i...	Einstellwert	Kommentar
1	<input type="checkbox"/> L_DETECT_FAULTS_OLD	DWord	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	last error
2	<input type="checkbox"/> b_RUN	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	operation run
3	<input type="checkbox"/> b_DONE	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	operation done
4	<input type="checkbox"/> b_ERROR	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	operation with error
5	<input type="checkbox"/> s_Step	String[20]	"	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	debug string
6	<input type="checkbox"/> w_ZSW1	Word	16#0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7	<input type="checkbox"/> di_XIST_Position	Dint	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	current position as DINT
8	<input type="checkbox"/> r_XIST_Position	Real	0.0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	current position as REAL
9	<input type="checkbox"/> b_00_Ready_to_switch_on	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
10	<input type="checkbox"/> b_01_Switched_on	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
11	<input type="checkbox"/> b_02_Operation_enable	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
12	<input type="checkbox"/> b_03_Fault	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
13	<input type="checkbox"/> b_04_Voltage_enabled	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
14	<input type="checkbox"/> b_05_Quick_stop_not_activa...	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
15	<input type="checkbox"/> b_06_Switch_on_disable	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
16	<input type="checkbox"/> b_07_Warning	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
17	<input type="checkbox"/> b_08_Manufacturer_specific	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
18	<input type="checkbox"/> b_09_Reserved	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
19	<input type="checkbox"/> b_10_Target_postion_reached	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
20	<input type="checkbox"/> b_11_Internal_limit_active	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
21	<input type="checkbox"/> b_12_Reserved	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
22	<input type="checkbox"/> b_13_Reserved	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
23	<input type="checkbox"/> b_14_Commutation_found	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
24	<input type="checkbox"/> b_15_Reference_found	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	bit from Statusword (ZSW1)
25	<input type="checkbox"/> Error	Word	16#0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	from GET_ER_ID() local Error handling

Figure 6: Output image axis controller

8 Troubleshooting

8.1 Warnings

The objects used for warning messages and a list thereof are described in the manual *Object directory ECOVARIO® and ECOSTEP®*.

8.2 Errors

The objects used for error messages and a list thereof are described in the manual *Object directory ECOVARIO® and ECOSTEP®*.

9 Comparison TIA portal / Classic world

9.1 STEP7 classic world

Every part of the program has its own window with different design.

- STEP 7
- DriveES
- WinCC Flexible
- PDM
- Starter

9.1.1 Description




Figure 7: SIMATIC STEP 7 Software

STEP 7 Professional is the compilation of the following software packages:

- STEP7 Basic software
- S7 - Graph
- S7 - SCL
- S7 - PLCSIM

Compared to the also individually available software packages, the suite offers a substantial price advantage, as well as a reduced installation effort and the possibility to use a single software update service for the whole suite.

There are directories included that show which versions are compatible.

9.2 TIA portal world

All programs and functions are **combined into a uniform interface**. Thus, independent of which program part is installed first, the central program is always a part of the installation process. **Only the exactly same versions of the program parts are compatible.**

The V12 Professional version therefore requires the compatible HMI in version 12, otherwise basic panels cannot be programmed with V12 Professional (which is possible without explicit WinCC Compact / Comfort / Advanced V12)



Figure 8: TIA portal interface

10 Manual integration of JAT drives

Connect JAT servo amplifiers

1. Start the program suite STEP 7
2. Open an existing project or create a new one
3. Integrate the appropriate .GSD file. There are 2 different .GSD files provided:
 - **ECOVARIO.GSD:** for all 1-axis servo amplifiers, meaning ECOSTEP® 100, ECOSTEP® 200, ECOVARIO® 114, ECOVARIO® 214, ECOVARIO® 414
 - **ECODUAL.GSD:** for 2-axis servo amplifiers, e. g. ECOVARIO® 114D. The 2-axis servo amplifier acts as any 1-axis servo amplifier at the PROFibus®. The second axis is realized by additional project modules.

Project the PROFibus®. JAT drives can be found in **Further field devices \ Drives \ JAT**.




Figure 9: PROFibus® projecting devices and networks

10.1 1-axis drive

For driving a single axis, the following modules need to be projected:

Table 7: 1-axis drive modules overview

R / W	Module	Description
W	controlword	Control word (object 6040)
W	modes_of_operation	Operating mode (object 6060)
W	target_position	Target position in increments (object 607A)
W	profile_velocity	Profile velocity in positioning mode in inc / 64 s (object 6081)
W	target_velocity	Target velocity in velocity mode in inc / 64 s (object 60FF)
R	statusword	Status word (object 6041)
R	detected_faults	Current error status (object 2600)
R	position_actual_value	Actual position (object 6063)
R	target_position	Target position in increments (object 607A)
R	modes_display	Display operating mode (object 6061)
R / W	Registers (8 Byte DI/DO)	Optional, see below

The following figure shows an exemplary projected 1-axis servo amplifier within its interface. The addresses are not fix, but can be found in different directories in dependence of the used S7 controller.

The module *R/W Registers (8 Byte DI/DO)* is required for the function block RWVALUE.




Figure 10: 1-axis drive exemplary projecting

10.2 2-axis drive

For operating a 2-axis drive (e.g. ECOVARIO® 114D), the following modules need to be projected. The second axis' modules are indicated by an additional `_1` at the end of their module names.

Table 8: 2-axis drive modules overview

R / W	Module	Beschreibung
W	controlword	Control word axis 1 (object 6040)
W	controlword_1	Control word axis 2 (object 6040)
W	modes_of_operation	Operating mode axis 1 (object 6060)
W	modes_of_operation_1	Operating mode axis 2 (object 6060)
W	target_position	Target position axis 1 in increments (object 607A)
W	target_position_1	Target position axis 2 in increments (object 607A)
W	profile_velocity	Profile velocity axis 1 in positioning mode in inc / 64 s (object 6081)
W	profile_velocity_1	Profile velocity axis 2 in positioning mode in inc / 64 s (object 6081)
W	target_velocity	Target velocity axis 1 in velocity mode in inc / 64 s (object 60FF)
W	target_velocity_1	Target velocity axis 2 in velocity mode in inc / 64 s (object 60FF)
R	statusword	Status word axis 1 (object 6041)
R	statusword_1	Status word axis 2 (object 6041)
R	detected_faults	Current error status axis 1 (object 2600)
R	detected_faults_1	Current error status axis 2 (object 2600)
R	position_actual_value	Actual position axis 1 (object 6063)
R	position_actual_value_1	Actual position axis 2 (object 6063)
R	target_position	Target position in increments axis 1 (object 607A)
R	target_position_1	Target position in increments axis 1 (object 607A)
R	modes_display	Display operating mode axis 1 (object 6061)
R	modes_display_1	Display operating mode axis 2 (object 6061)
R / W	Registers (9 Byte DI/DO)	Optional, see below

The following figure shows an exemplary projecting for a 2-axis servo amplifier within its interface. The addresses are not fix, but can be found in different directories in dependence of the used S7 controller. The module *R/W Registers (9 Byte DI/DO)* is required for the function block *RWVALUED*.




Figure 11: 2-axis drive exemplary projecting

11 General information regarding JAT with PROFibus®

- The baud rate is determined automatically
- The DP address is set via the CAN address
- With DUAL devices, only the first axis' address is addressed
- With DUAL devices, the second axis is addressed via the first axis ($x6000 + x800$)
- Theoretically, DUAL devices allow to address $2 \cdot 127$ axes (see above). Consider the transmission rate / bus load
- The configuration telegram's maximal size is 160 byte (1 module requires 6 byte)

12 Information regarding the universal module in SIEMENS controllers

The universal module is a freely configurable I/O module in the HW catalogue included into the respective device.

SIEMENS creates the universal module automatically in the HW catalogue. It is included in the catalogue independent of the .GSD file.




Figure 12: Universal module configuration

The universal module is created through drag & drop in a free slot for the respective drive. Double-clicking the universal module allows it to be set as input, output, out- / input or be left empty.




Figure 13: Setting the I/O type

The input addresses and output addresses are set according to the I/O type and the device object (length).

To illustrate, three examples follow.

Read object 0x2100:02 universal variable 02




Figure 14: Read object 0x2100:02 universal variable 02

Write object 0x2100:03 universal variable 03




Figure 15: Write object 0x2100:03 universal variable 03

Read object 0x21C0:02 positioning capturing strobe counter




Figure 16: Read object 0x21C0:02 positioning capturing strobe counter

Comparison VAT in STEP7 and variables table in ECOSTUDIO®

18	// Universalmodul			
19	PQD 335	HEX		DW#16#00000002
20	PID 374	HEX		DW#16#0000000B
21	PID 378	HEX		DW#16#0000000A

Figure 17: VAT in STEP 7

User Defined Variables			
	210002	unimappv_01	0000000B hex
	210003	unimappv_02	00000002 hex
	21C002	position_capture_count	0000000A hex

Figure 18: Variables table in ECOSTUDIO®

Information regarding 2-axis devices

Consider the axis index (axis 1 = 00, axis 2 = 01).




Figure 19: Axis index configuration

General information

The E/A type out- / input is only available for the R/W registry.