

SIEMENS

Ingenuity for life

24/7

Industry Online Support

Home

SIMATIC S7-1500T FlyingSawAdvanced LFlyingSaw for SIMATIC

Application description / V1.4.0 / 10/2022

<https://support.industry.siemens.com/cs/ww/en/view/109744840>

Siemens
Industry
Online
Support



Legal information

Use of application examples

Application examples illustrate the solution of automation tasks through an interaction of several components in the form of text, graphics and/or software modules. The application examples are a free service by Siemens AG and/or a subsidiary of Siemens AG ("Siemens"). They are non-binding and make no claim to completeness or functionality regarding configuration and equipment. The application examples merely offer help with typical tasks; they do not constitute customer-specific solutions. You yourself are responsible for the proper and safe operation of the products in accordance with applicable regulations and must also check the function of the respective application example and customize it for your system.

Siemens grants you the non-exclusive, non-sublicensable and non-transferable right to have the application examples used by technically trained personnel. Any change to the application examples is your responsibility. Sharing the application examples with third parties or copying the application examples or excerpts thereof is permitted only in combination with your own products. The application examples are not required to undergo the customary tests and quality inspections of a chargeable product; they may have functional and performance defects as well as errors. It is your responsibility to use them in such a manner that any malfunctions that may occur do not result in property damage or injury to persons.

Disclaimer of liability

Siemens shall not assume any liability, for any legal reason whatsoever, including, without limitation, liability for the usability, availability, completeness and freedom from defects of the application examples as well as for related information, configuration and performance data and any damage caused thereby. This shall not apply in cases of mandatory liability, for example under the German Product Liability Act, or in cases of intent, gross negligence, or culpable loss of life, bodily injury or damage to health, non-compliance with a guarantee, fraudulent non-disclosure of a defect, or culpable breach of material contractual obligations. Claims for damages arising from a breach of material contractual obligations shall however be limited to the foreseeable damage typical of the type of agreement, unless liability arises from intent or gross negligence or is based on loss of life, bodily injury or damage to health. The foregoing provisions do not imply any change in the burden of proof to your detriment. You shall indemnify Siemens against existing or future claims of third parties in this connection except where Siemens is mandatorily liable.

By using the application examples you acknowledge that Siemens cannot be held liable for any damage beyond the liability provisions described.

Other information

Siemens reserves the right to make changes to the application examples at any time without notice. In case of discrepancies between the suggestions in the application examples and other Siemens publications such as catalogs, the content of the other documentation shall have precedence.

The Siemens terms of use (<https://support.industry.siemens.com>) shall also apply.

Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. For additional information on industrial security measures that may be implemented, please visit <https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at: <https://www.siemens.com/industrialsecurity>.

Table of contents

| | | |
|----------|--|-----------|
| | Legal information | 2 |
| 1 | Basic information | 5 |
| 1.1 | Aim and purpose of this application | 5 |
| 1.1.1 | Task..... | 5 |
| 1.1.2 | Advantages of the standard SIMATIC application Flying saw | 6 |
| 1.2 | Components included in the standard application | 7 |
| 2 | Range of applications | 8 |
| 2.1 | Application | 8 |
| 2.1.1 | Available controllers | 8 |
| 2.1.2 | Tasks that can be addressed using the core function | 8 |
| 2.1.3 | Features of the application | 8 |
| 2.2 | Application environment | 12 |
| 2.2.1 | Real machine | 12 |
| 3 | Geometry and function | 13 |
| 3.1 | Design of the flying saw | 13 |
| 3.2 | Application modes SIMATIC Flying Saw..... | 15 |
| 3.3 | Mode of operation | 17 |
| 3.3.1 | Possibilities of determining the cut position | 17 |
| 3.3.2 | Synchronization | 19 |
| 3.3.3 | Options of defining the reversal position | 21 |
| 3.3.4 | Creating a gap..... | 23 |
| 3.3.5 | Dynamically defining the next start position | 24 |
| 3.3.6 | Dynamic running back operation Running Back Optimization (RBO) | 25 |
| 3.3.7 | Double Cut | 26 |
| 4 | Description of the integration into the user project | 28 |
| 4.1 | Integrating the LFlyingSaw into a STEP 7 project | 28 |
| 4.2 | Structure of the LFlyingSaw library | 29 |
| 4.2.1 | LFlyingSaw_Blocks | 29 |
| 4.2.2 | LFlyingSaw_HMI | 30 |
| 4.2.3 | LFlyingSaw_Tags & _Types | 30 |
| 5 | Preparation of the TO configuration | 31 |
| 5.1 | TO structure of the standard SIMATIC Flying Saw application..... | 31 |
| 5.2 | Configuring the TO FlyingSawAxis | 32 |
| 5.3 | Configuring the leading value TO..... | 35 |
| 5.3.1 | Configuring a axis as leading value | 35 |
| 5.3.2 | Configuring an external encoder as leading value | 38 |
| 6 | Description of the blocks and their structure | 40 |
| 6.1 | “LFS_CallsForMain” structure | 40 |
| 6.2 | LFS_FlyingSaw | 41 |
| 6.3 | LFS_Servo | 47 |
| 6.4 | Axis Blocks | 48 |
| 6.4.1 | LFS_FlyingSawAxis | 48 |
| 6.4.2 | LFS_LeadingValue | 50 |
| 6.4.3 | LFS_LeadingValueMeasuringInput | 52 |
| 7 | Description of the data and their structure | 54 |
| 7.1 | Overview..... | 54 |
| 7.2 | Enumeration types | 54 |
| 7.2.1 | LFS_Constant_CalcProfile_Errors | 55 |

| | | |
|----------|--|-----------|
| 7.2.2 | LFS_Constant_ErrorIDs | 56 |
| 7.2.3 | LFS_Constant_Operating..... | 58 |
| 7.2.4 | LFS_Constant_UnitConversion..... | 59 |
| 7.2.5 | LFS_Constant_UserConfig | 59 |
| 7.3 | Data types | 60 |
| 7.3.1 | LFS_typeAutoCutting (UDT) | 61 |
| 7.3.2 | LFS_typeAxisTOs (UDT)..... | 61 |
| 7.3.3 | LFS_typeCutPositionBuffer (UDT) | 62 |
| 7.3.4 | LFS_typeCutPositionBufferManagement (UDT) | 62 |
| 7.3.5 | LFS_typeFlyingSaw (UDT)..... | 63 |
| 7.3.6 | LFS_typeFlyingSawAxisCommand (UDT) | 66 |
| 7.3.7 | LFS_typeFlyingSawAxisOutput (UDT)..... | 67 |
| 7.3.8 | LFS_typeFlyingSawAxisServoValues (UDT) | 69 |
| 7.3.9 | LFS_typeFlyingSawInfo (UDT) | 70 |
| 7.3.10 | LFS_typeLCMRetProfileAccel (UDT) | 72 |
| 7.3.11 | LFS_typeLCMRetProfileDist (UDT) | 72 |
| 7.3.12 | LFS_typeLCMRetProfileJerk (UDT) | 73 |
| 7.3.13 | LFS_typeLCMRetProfileTime (UDT)..... | 73 |
| 7.3.14 | LFS_typeLeadingValueCommand (UDT) | 73 |
| 7.3.15 | LFS_typeLeadingValueMeasuringInputCommand (UDT) | 74 |
| 7.3.16 | LFS_typeLeadingValueMeasuringInputOutput (UDT) | 74 |
| 7.3.17 | LFS_typeLeadingValueOutput (UDT) | 75 |
| 7.3.18 | LFS_typeLeadingValueTOs (UDT) | 77 |
| 7.3.19 | LFS_typeMeasuringValue (UDT) | 78 |
| 7.3.20 | LFS_typeShiftPosCalc (UDT) | 79 |
| 7.3.21 | LFS_typeUsersInterface (UDT)..... | 80 |
| 8 | Operating the application | 83 |
| 8.1 | Operating instructions for the application example | 84 |
| 8.2 | Operating/overview screen form FS operating..... | 87 |
| 8.2.1 | FS Operating | 87 |
| 8.2.2 | Parameterizing screen form FS-Data1 (UI)..... | 89 |
| 8.2.3 | Diagnostics screen form FSdata2 (FSI) | 90 |
| 8.2.4 | Diagnostics screen form FS-Data3 (CPB-MI) | 91 |
| 8.2.5 | Diagnostic screen form FS messages | 92 |
| 9 | Appendix | 93 |
| 9.1 | Service and Support..... | 93 |
| 9.2 | Industry Mall | 94 |
| 9.3 | Contact persons | 94 |
| 9.4 | References | 94 |
| 9.5 | Documentation History | 94 |

1 Basic information

1.1 Aim and purpose of this application

1.1.1 Task

A material web that is fed in using a material feeder is to be processed, where the processing (e.g., cutting) cannot be carried out in a short time window but takes a slightly longer period. In order that the material web motion has no effect on the processing, the processing device must move in synchronism with the material, i.e., it must be processed "on the fly".

Why on-the-fly processing?

"On-the-fly" processing is required, if:


- Production processes cannot be stopped (e.g., extruders).
- Stopping the material web and the associated acceleration and deceleration forces cannot be realized.
- The individual processing steps are too different, so that a uniform wait time is no longer feasible from an efficiency perspective.

Basic design of a flying saw

The material is fed to the processing unit with a constant velocity.

The cut position on the material web is either sensed using a sensor and an appropriate mark – or is specified by the control after an adjustable cut length. At the same time, the synchronous position is defined, from where the shears slide of the flying saw travels in synchronism with the position where the material is to be cut and the cutting operation can be started. After cutting has been completed, the shears slide is positioned back to its initial position, where it waits for the next cut position.

Fig. 1-1: Principle of operation of a flying saw



1.1.2 Advantages of the standard SIMATIC application Flying saw

The standard SIMATIC Flying Saw application presented here helps to implement the described tasks – and allows a functioning application to be developed as quickly as possible.

The standard application includes a function block that controls the flying saw and controls motion using parameters corresponding to the specific application.

Using the user program, only the material feed must be controlled.

Further, the standard application includes a block to connect a user interface (HMI) to test and diagnose the flying saw functions.

The standard SIMATIC Flying Saw application offers users many advantages:

- **Fast program generation**

The standard application SIMATIC Flying Saw allows the functionality of a flying saw to be quickly and simply implemented based on a SIMATIC S7-1500T controller.

The function blocks included in the standard application can be quickly and simply transferred into the application to be generated by copying. Configuring steps that are additionally required are explained in this description.

- **Automatic motion control**

The core functions of the standard application completely handle the motion control based on the technology functions of the S7-1500T controller. The user only programs a control sequence that corresponds to the behavior of his machine function sequence to be implemented.

- **Adaptability**

All of the source codes are available in commented form for the standard application. Therefore, the core functions can be simply and quickly expanded to include customized functions.

1.2 Components included in the standard application

The standard SIMATIC Flying Saw application is implemented in the form of a library.

This library is used in a project that is supplied.

This project is used to quickly understand the functionality, commission the application and diagnose the standard SIMATIC Flying Saw application.

The program has the following tasks:

- Represent the FB-FlyingSaw from the perspective of the user program
- Allow all interfaces of the standard application to be used and operated
- Visualize all the relevant data of the standard application
- Graphically represent the synchronizing operations
- Incorporate the additional library of the axis FB.

In this way, the core functions of the standard SIMATIC Flying Saw application can be quickly and simply integrated in projects that users have created themselves.

2 Range of applications

2.1 Application

2.1.1 Available controllers

The standard SIMATIC TIA flying saw application can be used on any SIMATIC S7-1500T controller with Firmware 2.9.4 or higher. Therefore you need at least TIA Portal V17.

2.1.2 Tasks that can be addressed using the core function

The core function is used to control flying equipment, for example for

- Cutting
- Perforating
- Embossing
- Sealing
- Sawing
- Drilling
- Painting
- Measuring
- etc.

Definition In the following, the term **flying saw** is representative for all other conceivable machine versions.

Further, the term **"Saw"** is representative for the part of the machine that is in direct contact with the material.

2.1.3 Features of the application

The following features have been implemented and can be used in the user program.

Providing the leading value for cutting

The "flying saw" can be provided with a leading value for cutting in the following ways:

- Axis with actual value/setpoint coupling
- External encoder with actual value coupling
- The application does not change the leading value. Users can configure the leading axis as either linear or as modulo linear axis.
- It is possible to switch over the leading value during run of the web.

Cutting to length

- The cut length can be adapted at each cut

Sensor-defined cut position

- The distance between the sensor and cutting unit can be freely configured
- Sensing the cut is independent of the motion of the cutting unit
- The measured values are saved to a buffer memory
- The measuring points can be simulated (for commissioning)
- An active range can be defined for the measurement based on the format length.
- An alarm is output if a measurement is not realized in the active range. A counter is also incremented. A cut is made over the defined format length. The new active range is calculated based on the position of the last cut and the format length

Traveling to the transfer position

- After the cut, the material can be accompanied by the saw up to a defined transfer (handover) position

Creating a gap

- A "positive" gap can be created after the cut. The material is shifted relative to a defined length
- A "negative gap" can be created before approaching the transfer position. This is required in order to retract the material from the saw clamping mechanism before the transfer position is approached

Dynamically defining the next start position

When calculating the next start position, the flying saw can already be returning to the start position. Application for this function include:

- If natural materials are cut, then each cut can take a different time. On the average, the cutting time must be so short that the flying saw reaches the start position. However, if individual cuts take a longer time, then the flying saw can move in the direction of the defined end position
- A cutting unit should cut several short formats quickly one after the other, then followed again by a long format. During the short formats, the machining unit traverses in the direction of the end position; during the long format, it can go back to the start position
- Cutting "short" lengths from the transfer position, without the set start position being able to be reached

Specification of synchronous position

The synchronous position

- can be entered by value
- dynamic calculated in relation to web velocity

Running back optimization

- For fixed format lengths, for the return travel, the acceleration (optimized according to the torque, the thermal utilization), or the jerk (optimized according to the mechanical stress) can be adapted, so that the flying saw reaches the start position just before the start of the next synchronization
- The block automatically calculates the dynamic responses

Precisely synchronizing at a specific position

- The application provides "by time", and "by distance" (typically symmetrical) modes. The synchronization mode required depends on the constraints imposed by the mechanical system. The coupling type (setpoint/actual value coupling) and the maximum permissible drive torque) also have an influence

On the spot cut

- The material is cut when it is at a standstill
- The material is cut when it is moving only in the mode "cutting to length" (A cut is initiated by the operator, independent of the material distance traveled)

Skip next cut

On operator request or by initiation of a supervision system that detects web problems leading to a damage of the cutting system, when cutting

Interrupt / continue production

- The flying saw is stopped for brief maintenance work while the material web is running in the automatic mode (actual cut length and/or measured value buffer are kept)

Gear ratio between flying saw and the material

A gear ratio can be set between the material velocity that can be measured – and the material velocity active when cutting

- For instance, this is required when cutting wound paper cores as the material is wound with a skew, and therefore the material velocity measured using a measuring wheel does not correspond to the resulting core velocity
- Sawing and synchronizing with just one drive is another application. This diagonally moves the saw over the material web, which results in synchronous travel and cutting motion at the same time

Calculating the cut material length

- The calculation is based on the actual position and the runtime compensation

Control using the mode manager

- Initial position: The axes are activated – and the defined start or maintenance position approached
- Automatic: Process mode
- Manual: Standard interface to control basic axis functions – such as homing, jogging, ...

HMI with associated interface

- Optional commissioning/test interface in parallel to control from the user program
- Simulation of process feedback signals for test operation without material

Activation length when searching for the print mark

- Length that must be traveled through until the measured value acquisition is activated

Permanent print mark search

- The measured value acquisition permanently searches for a print mark without considering cut length (raster) and activation range

Wait for print mark on request

- The measured value acquisition is requested to search for the next print mark outside of the cut length (raster). If the print mark was found, then from this position, a search is made for the next print mark within a fixed raster. This function is used to synchronize cuts to a new or offset raster.

Central axis handling

- Technology and axis handling are separate.
- The application uses the functions of the "LAxisCtrl for SIMATIC" library to control the axes. When the flying saw is in the manual mode, users can issue motion commands, such as homing or jogging via the known interface of this library.

Multi instancing

- If it is necessary, more than one flying saw system can be operated in one CPU. Only limited by capacity of CPU

Double Cut

- The application offers the possibility for short cuts after and before a longer cut to do a double cut. This means the sledge delays exact for the short format length during synchronous phase and is not going to standstill before doing the short cut (double cut)


2.2 Application environment

The standard SIMATIC Flying Saw application can be used in the following hardware environment:

- Real machine
- Demonstration application (e.g., demonstration case or drives/motors without coupling to a real machine in a laboratory set up!)

2.2.1 Real machine

Fig. 2-1: Application environment of the standard SIMATIC TIA flying saw application with a real machine




SIMATIC can be used to control the material feed and the drives of the flying saw. Alternatively, the flying saw can be coupled using a machine encoder.

3 Geometry and function

3.1 Design of the flying saw

The application based on the flying saw comprises, for example, a spindle axis, to which the cutting unit is attached.

Fig. 3-1: Physical variables of the flying saw application



3 Geometry and function

Table 3-1: Explanation of the parameterizable physical variables

| Physical variable | Description |
|---|--|
| Distance to sensor <i>usersInterface.</i> <i>distanceToSensor</i> [mm] | Distance between the axis zero point of the flying saw and the sensor used for material and print mark detection |
| Start position <i>usersInterface.</i> <i>startPos</i> [mm] | Standstill position of the cutting unit with reference to the axis zero point of the flying saw. |
| Start (synchron area) <i>usersInterface.</i> <i>syncPos</i> [mm] | The position where the cutting unit reaches the specified material position and material velocity. Starting point of the synchronous range |
| End (synchron area) <i>usersInterface.</i> <i>endSyncPos</i> [mm] | End point of the synchronous range. If the cutting operation has still not been completed at this position, then it is canceled. |
| End position <i>usersInterface.</i> <i>endPos</i> [mm] | End point of the traversing range of the flying saw (e.g., software limit switch!) |

3.2 Application modes SIMATIC Flying Saw

The application automatically controls the flying saw to implement the required functionality.

This functionality is subdivided into five operating states. The flying saw sequences are realized in the corresponding operating modes or transitions between them.

Therefore, the user only influences the flying saw by entering the required mode.

Figure 3-2 Operating Modes




Table 3-2: SIMATIC Flying Saw application operating modes

| Operating mode | Description |
|---------------------------|---|
| ERROR (0) | An error has been identified – and the flying saw brought into a safe state. The error is still active and can be evaluated by the user. The flying saw axis has been stopped and deactivated. |
| DISABLE (1) | The flying saw is ready for use, the drive has not been enabled. All active faults have been successfully acknowledged. The flying saw axis is in the status after a reset, deactivated and stopped. |
| START POSITION (2) | The flying saw is at the start position – and is ready to be synchronized to the material web. The flying saw axis is activated. The axis waits in the START POSITION mode. |
| AUTOMATIC (3) | The flying saw is operational. The application synchronizes the shears to the material corresponding to what has been parameterized. |
| MANUAL (4) | The flying saw is in the manual mode, and the user can manually move the axis. |

3 Geometry and function

These modes are available to implement machine functionality in the user program and can be transferred to function block *LFS_FlyingSaw* via input parameters.

The function block indicates the actual state that has been reached using an output parameter.


3.3 Mode of operation

3.3.1 Possibilities of determining the cut position

Users can select one of the following methods:


- CP_CALCULATED: cut to a parameterized cut length

Figure 3-3 CP_Calculated



- CP_MEASURED: cut to a mark

Figure 3-4 CP_Detected



CP_CALCULATED

The material is always cut at the position derived from the actual material position and the cut length.

Precondition:

- The material axis is created as a linear axis **with** or **without** modulo length.
- The FlyingSaw block is in the "AUTOMATIC" operating mode

First cut at standstill:

- The cut is initiated with a positive edge at input "onTheSpotCut"
- The cut position is determined from the actual material position
- After a successful cut, the next cut position is calculated by increasing the actual cut position by the cut length and saved as the next cut position

First cut from the motion:

- When the "AUTOMATIC" mode is activated, the new cut position is determined from the actual material position and the specified

synchronization, so that the shears can synchronize by the time this position is reached.

- After a successful cut, the next cut position is calculated by increasing the actual cut position by the cut length and saved as the next cut position

All other cuts:

- After a successful cut, the next cut position is calculated by increasing the actual cut position by the cut length and saved as the next cut position

Immediate cuts are possible at any time if the shears are at the start position, and output "onTheSpotCutPossible" is set.

CP_MEASURED

The positions at which the material should be cut are determined at the measuring location in front of the flying saw, interpolated to the synchronous position and entered a circulating buffer. The flying saw reads these values from the buffer and deletes them once the position has been cut. The required offset between the cut and mark can be set by adapting parameter "distanceToSensor".

Precondition:

- The material axis is created as a linear axis **with** or **without** modulo length
- A sensor is necessary if CPM_DETECTED is activated

CPM_DETECTED:

- A sensor at the leading value is necessary
- The application waits for a 1st measured value, interpolates this to the synchronous position and enters it into the circulating buffer. In this case, after the measuring system has been activated, the system can wait for an adjustable activation length to be traveled through
- **UsersInterface.LookForFirstPrintmarkRequired:**
 - Can be activated during automatic run for detecting a new printmark as first printmark
 - The measuring system is then interpolated by the cut length for the next measured value and activated based on an activation range
- **UsersInterface.LookForFirstPrintmarkPermanent:**
 - Measuring input detects every printmaker on material, cut length **is not** considered for detecting
 - Cut length **is** considered for adapting the start position, when no printmark is detected, the application calculates the time in which the saw must reach its start position for the next cut. Therefore, enter the lowest possible cut length, so that the start position will be adapted if needed
- If a measured value is identified, then this is interpolated to the synchronous position and entered the circulating buffer
- If a measured value is not identified, then an error counter is incremented, and the old measured value increased by the "cut length" – interpolated to the synchronous position – and entered as new "measured value" into the circulating buffer
- The error counter is reset with the next successful measurement
-

CPM_SIMULATED:

- A sensor is not required
- When activating the application automatic mode, the actual leading value is automatically interpolated to the synchronous position and entered as 1st measured value in the circulating buffer.
- All additional "measured values" are determined by coupling with the "cut length" and interpolating to the synchronous length; they are then subsequently entered the circulating buffer.

Immediate cuts are possible in the CP_MEASURED mode.

3.3.2 Synchronization


Users can make a distinction between three synchronization types:

- With velocity overshoot
 - BY_TIME
 - BY_LEADING_AXIS_VALUE
- Without velocity overshoot
 - SYMMETRIC

With velocity overshoot

If the dynamic response values are high enough, the saw waits before starting synchronizing motion, and then accelerates to a velocity higher than the material velocity in order to catch up with the synchronous point. The velocity increase in the synchronization phase depends on the parameterized synchronizing velocity. In order that the saw can synchronize, the velocity must be higher than the material web velocity. The synchronization distance is obtained from the parameterized dynamic response values.

Figure 3-5 synchronizing with velocity overshoot



If the dynamic response values have been selected too low, the saw does not start and error message "Sync not possible" is output


Without velocity overshoot

For setting SYMMETRIC, the distance is dimensioned so that symmetrical synchronization is achieved without requiring excess velocity. The saw starts with synchronizing motion so that when it reaches the material velocity then it has precisely caught up with the synchronous point.

In this case, $\text{Synclength} = 2x (\text{SyncPos} - \text{StartPos})$.

The synchronization is realized with a constant acceleration rate. In this case, acceleration and jerk cannot be directly influenced.

Figure 3-6 Synchronizing without velocity overshoot



If SyncLength is selected to be too short, then the saw does not start – and error message "Sync not possible" is output

A continuous acceleration rate is also used in the BY_LEADING_AXIS_VALUE mode. The dynamic response values are indirectly influenced via the configured synchronization length

3.3.3 Options of defining the reversal position


After the cut, the flying saw can immediately reverse, or convey the material to a defined transfer position.

If in both options the start position cannot be reached in time before having to synchronize on material again, the application **calculates automatically a new shifted start position** which is in between the range of start position and the maximum start position. This function cannot be disabled.

MOVE_ZERO_POS

Immediately after executing its tasks (cut and creating a gap, if activated), the saw returns to its start position.


Figure 3-7 Move to start position after cut



RUN_HANDBER_POS

After the cut, the saw accompanies the material to the transfer position, and then returns to the start position


Figure 3-8 Convey material piece to handover position after cut



3.3.4 Creating a gap

GAP positive

Figure 3-9 creating a positive gap



- **MOVE_ZERO_POS:**
 - A "positive" gap can be created after the cut. The material is shifted in relative terms by the saw in the cutting position by a defined length in the transport direction
- **RUN_HANDOVER_POS:**
 - A "positive" gap can be created after the cut. The material is shifted in relative terms by the saw in the cutting position by a defined length in the transport direction. The shears then accompany the material to the transfer (handover) position

GAP negative

- **MOVE_ZERO_POS:**
 - No "negative" gap is possible, saw returns directly to start position after knife is out of the material
- **RUN_HANDOVER_POS:**
 - A "negative" gap can be created after the cut. In this case, the saw is first retracted out of the material and then the shears slide is moved relative to the material in the opposite direction to the transport direction through a defined length. The shears then accompany the material to the transfer (handover) position. This means that the material can be moved for transfer from the clamping range of the saw

3.3.5 Dynamically defining the next start position


At the start of synchronization, the flying saw can already be on its return travel to the start position. This functionality is required for the following applications:

- If natural materials are cut, then each cut can take a different time. On the average, the cutting time must be so short that the flying saw reaches the start position. However, if individual cuts take a longer time, then the flying saw can move in the direction of the defined end position until the maximum start position has reached.
- A cutting unit should cut several short formats quickly one after the other, then followed again by a long format. During the short formats, the machining unit traverses in the direction of the end position; after the long format, it can go back to the start position.
- Cutting "short" lengths from the transfer position, without the set start position being able to be reached.

3.3.6 Dynamic running back operation Running Back Optimization (RBO)


For fixed format lengths, for the return travel, the acceleration (optimized according to the torque, the thermal utilization), or the jerk (optimized according to the mechanical stress) can be adapted, so that the flying saw only reaches the start position at the next synchronization start. The block automatically calculates the dynamic responses.

Figure 3-10 Difference RBO activated and disabled



RBO by adapting jerk or acceleration


Figure 3-11 Difference RBO adapting jerk or acceleration



3.3.7 Double Cut

In case you want to make a very short follow-up cut once or always after a long cut, the double cut function has been implemented. With the double cut, the saw does not synchronize after the first cut, but is delayed by the entered double cut length and then the second cut can be made.

Figure 3-12 Position and velocity of flying saw during double cut




Note When using double cut, pay attention on the double cut length, if this is too big the way of the flying saw may not enough.

Double cut dynamic factor

By value of the parameter “usersInterface.doubleCutDynamicFactor” you can influence the dynamics of the delay. With a factor equal to 1.0 the length of the delay is equal to the double cut length. With a factor greater than 1.0 the length of the delay is increased (smaller dynamics) accordingly and with a factor smaller than 1.0 it is decreased (higher dynamics).

Figure 3-13 “usersInterface.doubleCutDynamicFactor”




4 Description of the integration into the user project

4.1 Integrating the LFlyingSaw into a STEP 7 project

The following table lists the steps to integrate the LFlyingSaw library into a STEP 7 project. The library blocks can then be used.

Note The precondition is that a STEP 7 project must exist

Table 4-1 Integration of the library into STEP 7

| Step | Task | | | | | | | | |
|------|---|-----|------|----|--|----|---|----|--|
| 1. | Unzip library LFlyingSaw_Vx.x.x.zip to a local folder. | | | | | | | | |
| 2. | In the TIA Portal, select "Options" -> "Global libraries" -> "Open library...." | | | | | | | | |
| 3. | Search for file LFlyingSaw_Vx.x.x_al | | | | | | | | |
| 4. | It is in subfolder LFlyingSaw of the unzipped zip file. | | | | | | | | |
| 5. | Open the global library in the read-only mode. | | | | | | | | |
| 6. | <p>Select the master copy to be copied into the project</p>  <table border="1" data-bbox="379 1279 1369 1503"> <thead> <tr> <th>No.</th> <th>Task</th> </tr> </thead> <tbody> <tr> <td>1.</td> <td>The blocks under LFlyingSaw_Blocks must be copied to the user program.</td> </tr> <tr> <td>2.</td> <td>Additionally, the HMI project must be integrated into the project by drag and drop.</td> </tr> <tr> <td>3.</td> <td>In addition, independent of the leading value type LFlyingSaw_Tags and LFlyingSaw_Types must be integrated into the project.</td> </tr> </tbody> </table> | No. | Task | 1. | The blocks under LFlyingSaw_Blocks must be copied to the user program. | 2. | Additionally, the HMI project must be integrated into the project by drag and drop. | 3. | In addition, independent of the leading value type LFlyingSaw_Tags and LFlyingSaw_Types must be integrated into the project. |
| No. | Task | | | | | | | | |
| 1. | The blocks under LFlyingSaw_Blocks must be copied to the user program. | | | | | | | | |
| 2. | Additionally, the HMI project must be integrated into the project by drag and drop. | | | | | | | | |
| 3. | In addition, independent of the leading value type LFlyingSaw_Tags and LFlyingSaw_Types must be integrated into the project. | | | | | | | | |
| 7. | Integration of the LAxisCtrl library according to the manual en: https://support.industry.siemens.com/cs/ww/en/view/109749348 | | | | | | | | |

4.2 Structure of the LFlyingSaw library

4.2.1 LFlyingSaw_Blocks




Table 4-2 LFlyingSaw_Blocks

| No. | Description |
|-----|---|
| 1 | LFlyingSaw_LibraryBlocks This folder contains all library relevant blocks to enable the standard application to function. The files in this folder structure should NOT be customized by the user |
| 1.1 | LFS_aVersion This block contains information of all already released versions |
| 1.2 | LFS_FlyingSaw Core block of the standard application "Flying Saw", which was programmed for OB1 "Main" |
| 1.3 | LFS_Servo Core block of the standard application "Flying Saw", which was programmed for the cyclic call e.g. MC_PreServo. |
| 1.4 | AxisBlocks In this folder are all blocks to enable the communication of the application with the technology objects |
| 1.5 | SubBlocks This folder contains blocks which are instantiated by the above-mentioned blocks |
| 2 | LFlyingSaw_UserBlocks This folder contains blocks to control the standard application. The files in this folder structure may be customized by the user |
| 2.1 | DataBlocks This folder contains all instance blocks |
| 2.2 | ExampleBlocks This folder contains example blocks which have to be called in the organization blocks |
| 2.3 | TestBlocks This folder contains the sequence block for an example control of the application and communication with the HMI |

4.2.2 LFlyingSaw_HMI

Figure 4-2 LFlyingSaw_ExampleHMI




Table 4-3

| No. | Description |
|-----|---|
| 1 | HMI_FlyingSaw Example HMI project for FlyingSaw application |

4.2.3 LFlyingSaw_Tags & _Types

Figure 4-3 LFlyingSaw_Tags & _Types




Table 4-4 LFlyingSaw_Tags and _Types

| No. | Description |
|-----|--|
| 1 | LFlyingSaw_Tags All constants of the standard application Flying Saw. More information in Datatypes and Tags |
| 2 | LFlyingSaw_Types All types of the standard application Flying Saw. Further information in Datatypes and Tags |


5 Preparation of the TO configuration

The standard SIMATIC Flying Saw application requires the following technology objects:

- For the FlyingSawAxis a **TO_SynchronousAxis**
- As leading value
 - Either a **TO_PositioningAxis** or **TO_SynchronousAxis** (with or without a **TO_MeasuringInput**)
 - Or a **TO_ExternalEncoder** (with or without a **TO_MeasuringInput**)

5.1 TO structure of the standard SIMATIC Flying Saw application



Fig. 5-1 TO configuration for the standard SIMATIC Flying Saw application






+

5.2 Configuring the TO FlyingSawAxis


Table 5-1 Configuring the TO FlyingSawAxis

| | | |
|-----------|---|---|
| <p>1.</p> | <p>Insert a new TO_SynchronousAxis</p> <p>And enter the "FlyingSawAxis" name</p> |  |
| <p>2.</p> | <p>Configure</p> <ul style="list-style-type: none"> - Axis type - Dimension units - Modulo - Simulation <p>For the FlyingSaw application it is important that axis type "linear" is selected.</p> <p>The dimension units have to be as used in the application mm and mm/s.</p> <p>It is not permissible that "Modulo" is activated as the FlyingSaw axis has a limited traversing range!</p> |  |

5 Preparation of the TO configuration

| <p>3.</p> | <p>Here, the PROFIdrive drive of the FlyingSawAxis is assigned TO FlyingSawAxis</p> |  <p>Drive type: PROFIdrive Data connection: Drive Drive: SINAMICS-S120-CU320-2PN.D0... Device configuration</p> | | | | | | | | |
|-----------------------------|---|---|-------------------------|------------------|------------------|----------|-----------------------------|--------------|-------|----------|
| <p>4.</p> | <p>The settings for</p> <ul style="list-style-type: none"> - Encoder - Data exchange, drive - Data exchange, encoder - Mechanical system - Dynamic response default setting - Emergency Stop - Position limits - Dynamic limits - Torque limiting - Fixed stop detection - Homing active/passive - Position monitoring - Standstill signal - Following error <p>must all be carried out</p> | <p>Encoder</p>  <p>Encoder on startup: Encoder 1</p> <p>Encoder 1</p> <p><input checked="" type="checkbox"/> Use encoder</p> <p>Data connection: Encoder Encoder: SINAMICS-S120-CU320-2PN.D0... Device configuration Encoder type: Absolute</p> | | | | | | | | |
| <p>5.</p> | <p>Here, all the possible leading value interconnections must be entered with their associated coupling type.</p> <p> </p> | <p>Leading value interconnections</p> <table border="1" data-bbox="678 1310 1356 1400"> <thead> <tr> <th>Possible leading values</th> <th>Type of coupling</th> </tr> </thead> <tbody> <tr> <td>LeadingValueAxis</td> <td>Setpoint</td> </tr> <tr> <td>LeadingValueExternalEncoder</td> <td>Actual value</td> </tr> <tr> <td><add></td> <td>Setpoint</td> </tr> </tbody> </table> | Possible leading values | Type of coupling | LeadingValueAxis | Setpoint | LeadingValueExternalEncoder | Actual value | <add> | Setpoint |
| Possible leading values | Type of coupling | | | | | | | | | |
| LeadingValueAxis | Setpoint | | | | | | | | | |
| LeadingValueExternalEncoder | Actual value | | | | | | | | | |
| <add> | Setpoint | | | | | | | | | |
| <p>6.</p> | <p>The control parameters are set here.</p> <p>In conjunction with SINAMICS S120, a</p> <p>Pre-control = 100.0 % Speed control loop substitute time = 0.0 s</p> <p>should be set.</p> <p>The gain (Kv factor) should be set corresponding to the requirements of the application. </p> | <p>Control loop</p> <p>Position control</p>  <p>Precontrol: 100.0 % Speed control loop substitute time: 0.0 s Gain (kv factor): 150.0 1/s</p> <p>Dynamic Servo Control (DSC)</p> <p>Dynamic Servo Control is only possible with drive telegram 5 6, 105 or 106</p> <p><input checked="" type="radio"/> Position control in the drive (DSC enabled) <input type="radio"/> Position control in the PLC</p> | | | | | | | | |

5 Preparation of the TO configuration



| | | |
|-----------|--|---|
| <p>7.</p> | <p>Here, settings are not required, as the FlyingSawAxis is not used as leading value for an additional following axis with actual value coupling.</p> | <p>Actual value extrapolation</p>  <p>The diagram illustrates the 'Actual value extrapolation' process. It starts with an input 'XIST' entering a 'Position filter' block. The output of the position filter is 'Filtered XIST', which goes to the 'Actual value extrapolation with hysteresis' block. Simultaneously, the output of the position filter is also fed into a 'Differentiation' block, which outputs 'Filtered v'. This 'Filtered v' then passes through a 'Velocity filter with tolerance band' block. The outputs of both the 'Actual value extrapolation with hysteresis' and the 'Velocity filter with tolerance band' are 'x leading value' and 'v leading value' respectively.</p> <p>Position filter T1: <input type="text" value="0.0"/> s</p> <p>Position filter T2: <input type="text" value="0.0"/> s</p> <p>Velocity filter T1: <input type="text" value="0.0"/> s</p> <p>Tolerance band width: <input type="text" value="0.0"/> mm/s</p> <p>Following axis dependent extrapolation time: <input type="text" value="0.0"/> s</p> <p>Hysteresis value: <input type="text" value="0.0"/> mm</p> |
|-----------|--|---|

5.3 Configuring the leading value TO




As leading value TO, you have the option of either accessing an axis – or an external encoder.

5.3.1 Configuring a axis as leading value




Table 5-2 Configuring TO LeadingValueAxis

| | | |
|-----------|--|---|
| <p>1.</p> | <p>Inserting a new TO_PositioningAxis or TO_SynchronousAxis</p> <p>And enter the "LeadingValueAxis" name</p>  |  |
|-----------|--|---|

5 Preparation of the TO configuration




| | | |
|--|--|--|
| <p>2.</p> <p>Configure</p> <ul style="list-style-type: none"> - Axis type - Dimension units - Modulo - Simulation <p>For the Flying Saw application, it is important that axis type "linear" is selected.</p> <p>The dimension units can be mm or m with corresponding velocity unit.</p> <p>It is permissible that LeadingValueAxis is operated with or without modulo.</p> <p>If the axis is to be operated without modulo, it must be ensured that the axis is reset from time to time, as accuracy problems occur for excessively high values.</p> | | <p>Basic parameters</p> <p>Name: LeadingValueAxis</p>  <p>Axis type</p> <p><input type="checkbox"/> Virtual axis</p> <p><input checked="" type="radio"/> Linear</p> <p><input type="radio"/> Rotary</p>  <p>Measuring units</p> <p>Measuring unit position: mm</p> <p>Measuring unit velocity: mm/s</p> <p>Measuring unit torque: Nm</p> <p>Measuring unit force: N</p> <p>Modulo</p> <p><input type="checkbox"/> Enable modulo</p> <p>Modulo start value: 0.0 mm</p> <p>Length: 1000.0 mm</p> <p>Simulation</p> <p><input type="checkbox"/> Activate simulation</p> |
| <p>3.</p> | <p>Here, the PROFIDrive drive of the LeadingValueAxis is assigned to TO LeadingValueAxis</p> | <p>Drive</p>  <p>Drive type: PROFIDrive</p> <p>Data connection: Drive</p> <p>Drive: SINAMICS-S1 20-CU320-2PN.D0... Device configuration</p> |

5 Preparation of the TO configuration




| | | |
|---|--|--|
| <p>4.</p> <ul style="list-style-type: none"> - Encoder - Data exchange, drive - Data exchange, encoder - Mechanical system - Dynamic response default setting - Emergency Stop - Position limits - Dynamic limits - Torque limiting - Fixed stop detection - Homing active/passive - Position monitoring - Standstill signal - Following error <p>must all be carried out</p> | |  |
| <p>5.</p> <p>The control parameters are set here.</p> <p>In conjunction with SINAMICS S120, a</p> <p>Pre-control = 100.0 %</p> <p>Speed control loop substitute time = 0.0 s</p> <p>should be set.</p> <p>The gain (Kv factor) should be set corresponding to the requirements of the application. </p> | |  |
| <p>6.</p> <p>In this case, settings should only be made if LeadingValueAxis is used as leading value of an actual value coupling.</p> <p>Entries are not required for a setpoint coupling!</p> | |  |

5.3.2 Configuring an external encoder as leading value

Table 5-3 Configuring the TO LeadingValueExternalEncoder

| | |
|---|---|
| <p>1.</p> <p>Insert a new TO_ExternalEncoder</p> <p>And enter the "LeadingValue ExternalEncoder" name</p>  |  |
| <p>2.</p> <p>Configure</p> <ul style="list-style-type: none"> - Encoder type - Dimension units - Modulo <p>For the Flying Saw application, it is important that encoder type "linear" is selected.</p> <p>The dimension units can be mm or m with corresponding velocity unit.</p> <p>It is permissible that the LeadingValue ExternalEncoder is operated with or without modulo.</p> <p>If the encoder is to be operated without modulo, it must be ensured that the axis is reset from time to time, as accuracy problems occur for excessively high values.</p> |  |


5 Preparation of the TO configuration

| | | |
|-----------|---|---|
| <p>3.</p> | <p>Here, the PROFIDrive encoder is assigned to TO LeadingValue ExternalEncoder</p> |  <p>Encoder</p> <p>PLC ← Data exchange → Encoder</p> <p>Data connection: Encoder Encoder: SINAMICS-S120-CU320-2PN.DO Encoder type: Incremental</p> <p>Device configuration</p> |
| <p>4.</p> | <p>The settings for - Encoder - Data exchange - Mechanical system - Homing</p> <p>must all be carried out</p> |  <p>Data exchange</p> <p>PLC ← Data exchange → Encoder</p> <p>Encoder telegram: Telegram 83</p> <p><input type="checkbox"/> Automatic transfer of encoder parameter values</p> <p>Measuring system: Rotary Increments per revolution: 2048</p> <p>Fine resolution Bits in Gx_XIST1: 11 bit</p> <p>Device configuration</p> |
| <p>5.</p> | <p>This screen form is automatically populated.</p> <p>Adaptations can be made here if problems are encountered with the actual value coupling.</p> |  <p>Actual value extrapolation</p> <p>XIST → Position filter → Filtered XIST → Actual value extrapolation with hysteresis → x leading value</p> <p>XIST → Differentiation → Velocity filter with tolerance band → Filtered v → Actual value extrapolation with hysteresis → v leading value</p> <p>Calculation of extrapolation velocity</p> <p>Position filter T1: 0.0 s Position filter T2: 0.0 s</p> <p>Velocity filter T1: 0.0 s Tolerance band width: 0.0 mm/s</p> <p>Following axis dependent extrapolation time: 0.0 s Hysteresis value: 0.0 mm</p> |

6 Description of the blocks and their structure

6.1 “LFS_CallsForMain” structure

Figure 6-1 LFS_CallsForMain structure



© Siemens AG 2022 All rights reserved

6.2 LFS_FlyingSaw

Block name

LFS_FlyingSaw

Task

Control block of the SIMATIC Flying Saw application. The block includes the following functions:


- Operating mode manager of the application, including operating modes ERROR, DISABLE, MANUAL, STARTPOSITION, AUTOMATIC
- Determining the cut position – either based on a print mark and sensor or a cut length that can be parameterized
- Synchronizing to the material web
- During synchronous travel, controlling the cutting equipment
- Possibility of "Creating a gap"

Integration into the execution system


The function block can be called in every cyclic OB. Users must integrate the block.

Interface description

Block Interface



6 Description of the blocks and their structure



Input parameter

| Identifier | Data type | Default value | Description |
|----------------------------------|--|---------------|--|
| cutLength | LReal | 800.0 | [mm] format length |
| execute | Bool | FALSE | Activates the mode of operation switchover with the operating mode specified in "Mode". |
| mode | DInt | 0 | [-] Using mode, the mode is preselected, which is activated with the next positive edge at the execute input |
| stopCutting | Bool | FALSE | Cutting has been finished |
| knifeOut | Bool | FALSE | Tool is out of material |
| gapLength | LReal | 10.0 | [mm] Length of the gap |
| gap | Bool | FALSE | Move a gap afterwards a cut |
| doubleCut | Bool | FALSE | Activate double cut |
| doubleCutLength | LReal | 100.0 | [mm] Length of double cut |
| onTheSpotCut | Bool | FALSE | Activate on the spot cut |
| skipNextCut | Bool | FALSE | Skip next cut |
| constantVelocityAtCut | Bool | FALSE | Assume constant leading value velocity during synchronous phase |
| flyingSawAxisOutput | LFS_typeFlyingSawAxisOutput | --- | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |
| leadingValueOutput | LFS_typeLeadingValueOutput | --- | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |
| leadingValueMeasuringInputOutput | LFS_typeLeadingValueMeasuringInputOutput | --- | This structure contains all the required feedback signals of the measuring input at the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputOutput |
| leadingValueConfig | LAxisCtrl_typeAxisConfig | --- | |

Output parameter

| Identifier | Data type | Description |
|---------------------------|------------------------------|---|
| done | Bool | TRUE: Selected mode is activated |
| busy | Bool | TRUE: Operating mode switchover is active |
| error | Bool | TRUE: Displays an error within the FBs or at the flying saw axes. Details see errorID. |
| cut | Bool | TRUE: FlyingSaw is in synchronous Phase |
| flyingSawInStartPos | Bool | TRUE: FlyingSaw stands in its startposition |
| endSyncPosReached | Bool | TRUE: FlyingSaw has reached the end of synchronuous range |
| handoverPosReached | Bool | TRUE: FlyingSaw has reached the handover position |
| onTheSpotCutPossible | Bool | TRUE: On the spot cut is possible |
| onTheSpotCutDone | Bool | TRUE: On the spot cut has been done |
| skipNextCutPossible | Bool | TRUE: Skip next cut is possible |
| syncNotPossible | Bool | TRUE: Synchronization is not possible, because upper limit for starting synchronization was overrun in automatic state "AR_GEARIN_FSA_ABSOLUTE" or "AR_GEARIN_FSA_RELATIVE" before starting synchronization |
| forSyncToLate | Bool | TRUE: Synchronization is not possible, because upper limit for starting synchronization was overrun in automatic state "AR_WAIT_FOR_FLYING_SAW_START" or "AR_POS_STARTPOS_NEXT_START" before starting synchronization |
| errorID | DWord | Error code. The ErrorIDs are described in this document. |
| state | DInt | [-] Active mode: LFS_OM_ERROR (0): ERROR mode LFS_OM_DISABLE (1): DISABLE mode LFS_OM_START_POSITION (2): STARTPOSITION mode LFS_OM_AUTOMATIC (3): AUTOMATIC mode LFS_OM_MANUAL (4): MANUAL mode LFS_OM_NOTHING_SELECTED (8): No mode change LFS_OM_CHANGING (9): Mode change active |
| flyingSawAxisActive | Bool | TRUE: FlyingSaw axis is enabled |
| startPositionAutoAdaptAct | Bool | TRUE: Automatic adapting of startposition is active |
| flyingSawAxisCommand | LFS_typeFlyingSawAxisCommand | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisCommand |

6 Description of the blocks and their structure

| Identifier | Data type | Description |
|-----------------------------------|---|--|
| LeadingValueMeasuringInputCommand | LFS_typeLeadingValueMeasuringInputCommand | This structure contains the command interface to the axis FB, reduced to the requirements of the measuring input. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLeadingValueMeasuringInputCommand |

In/Out parameter

| Identifier | Data type | Description |
|-----------------------------|-------------------------------------|---|
| flyingSawAxisConfig | LAxisCtrl_typeAxisConfig | |
| usersInterface | LFS_typeUsersInterface | This structure contains the interface for the user to enter physical conditions, dynamics and FlyingSaw behaviour. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeUsersInterface |
| flyingSawInfo | LFS_typeFlyingSawInfo | This structure contains the internal data area to display actual I values, actual cut position as well as binary signals for the FlyingSaw position. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawInfo |
| cutPositionBufferManagement | LFS_typeCutPositionBufferManagement | This structure contains the internal data area for entering precise cut position for the print mark cutting. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeCutPositionBufferManagement |
| measuringValue | LFS_typeMeasuringValue | This structure contains the internal measuring data area for the print mark cutting. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeMeasuringValue |

© Siemens AG 2022. All rights reserved.

Functionality

Function block *LFS_FlyingSaw* is the most important application element. The connected flying saw is parameterized and controlled using this block.

Initial state of LFS_FlyingSaw

After the initialization, *LFS_FlyingSaw* is in the DISABLE mode.


Each time the control starts, the initialization must be executed by setting the restart bit ("*LFS_Data*".*flyingSaw[0].usersInterface.restart*) in the Start Up task. (This is realized automatically when using the *LFS_CallsForStartup* block)

Therefore, the block is transitioned into its basic state, important parameters are subject to a plausibility check, if possible, adapted – and parameterizing errors are displayed at the error output to inform users.

Sequence when switching over operating modes

The actual block operating mode is indicated at output **state**.

Fig. 6-2: Inputs and outputs of the operating mode switchover function



Transition of the operating modes

To transition the operating mode, the number of the required operating mode must be specified at the input **mode**. The switchover is realized by using a rising edge at the input **execute**. The active switchover to the new block operating mode is signaled using a high signal at output **busy**. If all switchover actions are successfully performed, and the new operating mode is reached, this is indicated by a high signal at output **done** of the block. The number of the new operating mode can be read at output **state**.

Checking the input parameters and parameterizing the mandatory technology settings

This program function is only executed after a "new start" – or if it is activated by the user using the restart bit of *UsersInterface*.

The following are monitored:

- The existence and drive interconnection of the specified TOs.
- Deviations with respect to what has been specified are displayed as error messages

Axis monitoring

The function block is switched into the error state (ERROR mode) if errors occur at the technology object axis of the flying saw.

However, the monitoring is only active if the parameterization of the technology objects has been successfully checked.

Using the restart bit

("LFS_Data".flyingSaw[0].usersInterface.restart)

Each time the SIMATIC starts or when changing the parameterization, then the restart bit must be set. Therefore, an initialization routine as well as a parameter check is performed in *LFS_FlyingSaw*, and the block is brought into a defined state.

Note

We recommend that the example FC LFS_CallsForStartup provided is used and called in an OB StartUp to initialize block *LFS_FlyingSaw*.

The restart bit should also be set there so that the block is brought into a defined state!

Note


After restart, the block checks the essential parameters of the technology as well as the existence of technology objects that have been saved.

After the block has been successfully initialized, the block is automatically reset again.

Error handling

If, during operation of the *LFS_FlyingSaw*, errors occur in the block itself or at the technology objects and technology functions involved, then these are signaled at the **error** and **errorID** block outputs.

Fig. 6-3: Block outputs for error messages



The **error** signals an active error, while an error code is output at **errorID**; this can be used to analyze the cause of the error. [All possible errors are described in this document.](#)

6.3 LFS_Servo

Block name

LFS_Servo

Task


- Reading of all relevant axis data used in servo clock. Calculation of precision of cut length using two following cuts.
- Detection and presetting of velocity at "Constant Velocity at Cut"

Integration into the execution system

The function block must be called in OB MC-PreServo. Users must integrate the block.

Interface description

Block Interface



Input parameter

| Identifier | Data type | Default value | Description |
|--------------------|-----------------------------|---------------|---|
| FSNumber | Int | 0 | Number of FlyingSaw instance |
| leadingValueOutput | LFS_typeLeadingValue Output | --- | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |

6.4 Axis Blocks

6.4.1 LFS_FlyingSawAxis

Control block of the flying saw Axis

Block name

LFS_FlyingSawAxis

Task


Controlling the flying saw axis by calling axis FB functions.

Integration into the execution system

The function block must be called in a cyclic OB. (Standard: OB1)

Interface description

Block Interface



Input parameter

| Identifier | Data type | Default value | Description |
|-------------|------------------------------|---------------|---|
| FSNumber | Int | 0 | Number of FlyingSaw instance |
| state | DInt | 0 | [·] Active mode: LFS_OM_ERROR (0): ERROR mode LFS_OM_DISABLE (1): DISABLE mode LFS_OM_START_POSITION (2): STARTPOSITION mode LFS_OM_AUTOMATIC (3): AUTOMATIC mode LFS_OM_MANUAL (4): MANUAL mode LFS_OM_NOTHING_SELECTED (8): No mode change LFS_OM_CHANGING (9): Mode change active |
| userCommand | LFS_typeFlyingSawAxisCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisCommand |

6 Description of the blocks and their structure

| Identifier | Data type | Default value | Description |
|-----------------|------------------------------|---------------|---|
| internalCommand | LFS_typeFlyingSawAxisCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisCommand |

Output parameter

| Identifier | Data type | Description |
|------------|-----------------------------|--|
| Output | LFS_typeFlyingSawAxisOutput | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisOutput |

In/Out parameter

| Identifier | Data type | Description |
|----------------|--------------------------|-------------|
| userConfig | LAxisCtrl_typeAxisConfig | |
| internalConfig | LAxisCtrl_typeAxisConfig | |

Functionality

- This block controls the active call interface for the axis FB of the FlyingSawAxis, as a function of the operating mode of the FlyingSaw block.
- In the "Manual" mode (state = LFS_OM_MANUAL(4)), the axis of the FlyingSawAxis is called with the user command interface (userCommand) and the user configuration data (userConfig). Therefore, in this mode users have unrestricted access to the Flying Saw axis.
- In all other operating modes (state = LFS_OM_ERROR(0), LFS_OM_DISABLE(1), LFS_OM_START_POSITION(2) and LFS_OM_AUTOMATIC(3)), the axis FB of the FlyingSawAxis is called with the internal command interface (internalCommand) and the internal configuration data (internalConfig). In these modes, the Flying Saw axis is exclusively accessed using the standard "Flying Saw" application.

Error messages

The block does not generate any error messages.

6.4.2 LFS_LeadingValue

Control block of the leading value axis

Block name

LFS_LeadingValue

Task


- Identification whether axis or external encoder is interconnected as leading value
- Switch between different leading values
- Controlling the leading value axis by calling the axis FB functions via the user interface
- Reading out all the leading value data relevant for LFS_FlyingSaw

Integration into the execution system

The function block must be called in a cyclic OB. (Standard: OB1)

Interface description

Block Interface



Input parameter

| Identifier | Data type | Default value | Description |
|------------|-----------|---------------|------------------------------|
| FSNumber | Int | 0 | Number of FlyingSaw instance |

In/Out parameter

| Identifier | Data type | Description |
|-------------|-----------------------------|--|
| userCommand | LFS_typeLeadingValueCommand | This structure contains the command interface to the axis FB, reduced to the requirements of the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueCommand |
| output | LFS_typeLeadingValueOutput | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |
| config | LAxisCtrl_typeAxisConfig | |

Functionality

- Provision of the axis FB interface to operate the axis as leading value for the user.
- Provision of all the relevant axis data as leading value for the FlyingSaw block.
- Switch between different leading values by access to an array of leading values up to "LFS_MAX_NUMBER_OF_LEADING_VALUES" number of elements.
- Possible leading values:
 - TO SynchronousAxis
 - TO PositioningAxis
 - TO ExternalEncoder

Error messages

The block does not generate any error messages.

6.4.3 LFS_LeadingValueMeasuringInput

Control block of the leading value measuring Input

Block name

LFS_LeadingValueMeasuringInput

Task


Controlling the leading value measuring Input by calling PLC open blocks MC_RESET and MC_MEASURINGINPUT.

Integration into the execution system

The function block must be called in a cyclic OB.
(Standard: OB1)

Interface description

Block Interface



Input parameter

| Identifier | Data type | Default value | Description |
|--------------------|---|---------------|--|
| FSNumber | Int | 0 | Number of FlyingSaw instance |
| internalCommand | LFS_typeLeadingValueMeasuringInputCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the measuring input. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputCommand |
| leadingValueOutput | LFS_typeLeadingValueOutput | --- | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |

Output parameter

| Identifier | Data type | Description |
|------------|--|--|
| output | LFS_typeLeadingValueMeasuringInputOutput | This structure contains all the required feedback signals of the measuring input at the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputOutput |

Functionality

- Calling of the sensor functions by the FlyingSaw block via internal command interface.
- Providing of all the relevant sensor data at the leading value for the FlyingSaw block.

Error messages

The block does not generate any error messages.

7 Description of the data and their structure

7.1 Overview

Enumeration types

Enumeration type declarations are provided for some of the input and output parameters of the function blocks. Various modes and properties can be set using these parameters.

Data structures

In some instances, the function blocks of the SIMATIC Flying Saw application are parameterized using data structures, which should be created for the block. Structures with the appropriate parameters are available for each block.

7.2 Enumeration types

Table 7-1 Enumeration types, declared in LFLyingSaw_Tags

| Name of the enumeration type | Content |
|---------------------------------|--|
| LFS_Constant_CalcProfile_Errors | This enumeration type contains constants for errors which are internally used for calculating profiles. Not interesting for user. Because of this there is no description in manual. |
| LFS_Constant_ErrorIDs | This enumeration type defines the value of all possible ErrorIDs (errors, warnings) |
| LFS_Constant_Operating | This enumeration type contains DINT constants to select and display the operating and functionality of function block LFS_FlyingSaw |
| LFS_Constant_UnitConversion | This enumeration type contains UDINT constants for the TIA Portal TO length and velocity unit number for calculating the unit conversion factors. |
| LFS_Constant_UserConfig | This enumeration contains constants which have to be adapted by the user to specific values of the machine. |

7.2.1 LFS_Constant_CalcProfile_Errors

Constant identifier, values and description

| Identifier & Value | Description |
|---|-------------|
| LCM_ERR_ACCELERATION_OUT_OF_BOUNDS 116 | |
| LCM_ERR_DECELERATION_OUT_OF_BOUNDS 117 | |
| LCM_ERR_JERK_OUT_OF_BOUNDS 113 | |
| LCM_ERR_NEGATIVE_RESULT 111 | |
| LCM_ERR_NOT_SOLVABLE 114 | |
| LCM_ERR_VELOCITY_OUT_OF_BOUNDS 115 | |
| LCM_ERR_WRONG_ACCEL_ARGUMENT 100 | |
| LCM_ERR_WRONG_ACCEL_LIMIT_ARGUMENT 101 | |
| LCM_ERR_WRONG_DECEL_ARGUMENT 102 | |
| LCM_ERR_WRONG_DISTANCE_ARGUMENT 103 | |
| LCM_ERR_WRONG_JERK_ARGUMENT 104 | |
| LCM_ERR_WRONG_MODE_ARGUMENT 118 | |
| LCM_ERR_WRONG_TIME_ARGUMENT 106 | |
| LCM_ERR_WRONG_VELOCITY_ARGUMENT 107 | |
| LCM_MINJERK_TOLERANCE 1.0e-6 | |
| LCM_MODE_DIRECTION_RELATED 173 | |
| LCM_MODE_STATE_RELATED 91 | |

7.2.2 LFS_Constant_ErrorIDs

Constant identifier, values and description

| Identifier & Value | Description |
|--|--|
| LFS_ERR_ACT_POS_BIGGER_THAN_END_POS 16#060A_8002 | Actual position of the axis of the flying saw > usersInterface.EndPos |
| LFS_ERR_AR_DOUBLECUT 16#0603_8009 | Error when activating MC_OFFSETRELATIVE or MC_MOVESUPERIMPOSE D during automatic run state DOUBLE CUT |
| LFS_ERR_AR_GEARIN_FSA_ABSOLUTE 16#0603_8003 | Error when activating MC_GEARINPOS during automatic run |
| LFS_ERR_AR_GEARIN_FSA_RELATIVE 16#0603_8002 | Error when activating MC_GEARIN during automatic run |
| LFS_ERR_AR_MOVE_GAP 16#0603_8004 | Error when activating MC_MOVESUPERIMPOSE D during automatic run |
| LFS_ERR_AR_ON_SPOT_CUT_LV_POS_LOWER_THAN_FS_START_POS 16#0603_8007 | On the spot cut at standstill selected, but material position is lower than start position of flying saw. Therefore, material is not under flying saw, cut into void |
| LFS_ERR_AR_POS_STARTPOS_NEXT_START 16#0603_8006 | Error when activating MC_MOVEABSOLUTE during automatic run state POS STARTPOS NEXT START |
| LFS_ERR_AR_STOP_FSA 16#0603_8005 | Error when activating MC_HALT during automatic run |
| LFS_ERR_AR_SYNC_POS_LOWER_THAN_START_POS 16#0603_8008 | Wrong parameterization: 0.0 < UsersInterface.SyncPos < UsersInterface.StartPos |
| LFS_ERR_AR_WAIT_FOR_FLYING_SAW_START 16#0603_8001 | Error when activating MC_MOVEABSOLUTE during automatic run state WAIT FOR FLYING SAW START |
| LFS_ERR_AT_FS_AXIS 16#060A_8001 | Error at TO of flying saw axis |
| LFS_ERR_AUTOMATIC_TO_DISABLE 16#0631_8001 | Error when activating MC_HALT during mode change AUTOMATIC to DISABLE |
| LFS_ERR_AUTOMATIC_TO_STARTPOSITION 16#0632_8001 | Error when activating MC_MOVEABSOLUTE during mode change AUTOMATIC to STARTPOSITION |

7 Description of the data and their structure

| Identifier & Value | Description |
|--|---|
| LFS_ERR_DISABLE_TO_DISABLE 16#0611_8001 | Error when activating MC_HALT during mode change DISABLE to DISABLE |
| LFS_ERR_DISABLE_TO_STARTPOSITION 16#0612_8001 | Error when activating MC_MOVEABSOLUTE during mode change DISABLE to STARTPOSITION |
| LFS_ERR_INAVLID_MODE_AFTER_AUTOMATIC_MODE 16#060F_8004 | Invalid mode after mode AUTOMATIC selected |
| LFS_ERR_INAVLID_MODE_AFTER_DISABLE_MODE 16#060F_8002 | Invalid mode after mode DISABLE selected |
| LFS_ERR_INAVLID_MODE_AFTER_ERROR_MODE 16#060F_8001 | Invalid mode after mode ERROR selected |
| LFS_ERR_INAVLID_MODE_AFTER_MANUAL_MODE 16#060F_8005 | Invalid mode after mode MANUAL selected |
| LFS_ERR_INAVLID_MODE_AFTER_STARTPOSTION_MODE 16#060F_8003 | Invalid mode after mode STARTPOSITION selected |
| LFS_ERR_LV_INVALID_LENGTH_OR_VELOCITY_UNIT 16#060A_8003 | Invalid length or velocity unit at leading value TO |
| LFS_ERR_MANUAL_TO_DISABLE 16#0641_8001 | Error when activating MC_HALT during mode change MANUAL to DISABLE |
| LFS_ERR_MANUAL_TO_STARTPOSITION 16#0642_8001 | Error when activating MC_MOVEABSOLUTE during mode change MANUAL to STARTPOSITION |
| LFS_ERR_MODULO_LENGTH_EQUAL_ZERO_MODE 16#060C_8004 | Modulo at leading value active, but length is 0.0 |
| LFS_ERR_OM_CHANGE_DURING_INTERRUPT_PRODUCTION 16#0603_8010 | Mode change with active production interrupted. Before the change, production continued is necessary. |
| LFS_ERR_STARTPOSITION_TO_DISABLE 16#0621_8001 | Error when activating MC_HALT during mode change STARTPOSITION to DISABLE |
| LFS_ERR_STARTPOSITION_TO_STARTPOSITION 16#0622_8001 | Error when activating MC_MOVEABSOLUTE during mode change STARTPOSITION to STARTPOSITION |
| LFS_ERR_TO_MISSING_FOR_FS 16#060C_8001 | No TO connected to flying saw axis |
| LFS_ERR_TO_MISSING_FOR_LV 16#060C_8002 | No TO connected to leading value axis |
| LFS_ERR_TO_MISSING_FOR_MI 16#060C_8003 | No TO measuring input connected to leading value |
| LFS_NO_ERROR 16#0000_0000 | No error |

| Identifier & Value | Description |
|--|---|
| LFS_WAR_FIRST_CUT_LENGTH_POSSIBLY_WRONG 16#0603_4001 | First cut after immediate cut at standstill and leading value at the external encoder is still in acceleration phase. First cut length possibly wrong |

7.2.3 LFS_Constant_Operating

Constant identifier, values and description

| Identifier & Value | Description |
|---|--|
| LFS_BY_LEADING_AXIS_VAL UE 2 | Synchronization by distance. The distance is saved in variable "usersInterface.SyncPos" |
| LFS_BY_TIME 1 | Synchronization by time |
| LFS_CP_CALCULATED 2 | Cut position remains constant, the material position is reduced by the cut length after the cut (the amount cutoff). This procedure does not require any stored position data. |
| LFS_CP_MEASURED 1 | Cut position is measured using the sensor and print mark or calculated, and then entered into the CutPositionBuffer |
| LFS_CPM_DETECTED 1 | Cut position is measured using the sensor and print mark |
| LFS_CPM_SIMULATED 2 | Cut position is calculated from the specified cut length |
| LFS_MOVE_ZERO_POS 1 | Flying saw directly returns to the start position |
| LFS_OM_AUTOMATIC 3 | LFS_FlyingSaw is in the AUTOMATIC mode |
| LFS_OM_CHANGING 6 | LFS_FlyingSaw is presently undergoing a mode change |
| LFS_OM_DISABLE 1 | LFS_FlyingSaw is in the DISABLE mode |
| LFS_OM_ERROR 0 | LFS_FlyingSaw is in the ERROR mode |
| LFS_OM_MANUAL 4 | LFS_FlyingSaw is in the MANUAL mode |
| LFS_OM_NOTHING_SELECTE D 5 | LFS_FlyingSaw has not detected a mode change |
| LFS_OM_START_POSITION 2 | LFS_FlyingSaw is in the STARTPOSITION mode |
| LFS_RUN_HANDOVER_POS 2 | Flying saw first returns to the transfer position – and then to the start position |
| LFS_SYMMETRIC 3 | Synchronization is symmetrical without velocity overshoot |

7.2.4 LFS_Constant_UnitConversion

Constant identifier, values and description

| Identifier & Value | Description |
|---|--|
| LFS_LENGTH_UNIT_M 1010 | Length unit of TO is m |
| LFS_LENGTH_UNIT_MM 1013 | Length unit of TO is mm |
| LFS_LENGTH_UNIT_MM_HIGH_RESOLUTION 1536 | Length unit of TO is mm with high resolution |
| LFS_VELOCITY_UNIT_M_PER_H 1063 | Velocity unit of TO is m/h |
| LFS_VELOCITY_UNIT_M_PER_MIN 1525 | Velocity unit of TO is m/min |
| LFS_VELOCITY_UNIT_M_PER_S 1061 | Velocity unit of TO is m/s |
| LFS_VELOCITY_UNIT_MM_PER_H 1526 | Velocity unit of TO is mm/h |
| LFS_VELOCITY_UNIT_MM_PER_MIN 1524 | Velocity unit of TO is mm/min |
| LFS_VELOCITY_UNIT_MM_PER_S 1062 | Velocity unit of TO is mm/s |
| LFS_VELOCITY_UNIT_MM_PER_S_HIGH_RESOLUTION 1538 | Velocity unit of TO is mm/s with high resolution |

7.2.5 LFS_Constant_UserConfig

Constant identifier, values and description

| Identifier & Value | Description |
|--|--|
| LFS_CPB_MAX-1 4 | Maximum length of CutPosition Buffer - 1 |
| LFS_DELTA_STARTPOS 3.0 | Range in which FlyingSaw is in Startposition |
| LFS_MAX_NUMBER_OF_FLYING_SAWS-1 0 | Maximum number of flying saws - 1 |
| LFS_MAX_NUMBER_OF_LEADING_VALUES 3 | Maximum number of leading values |
| LFS_NUMBER_OF_FLYING_SAWS 1 | Number of FlyingSaw axes |
| LFS_START_AREA 20.0 | Range for starting the synchronization |
| LFS_START_SYNC_WAITING_DISTANCE 10.0 | Safety distance to begin with synchronization at the latest practicable date |
| LFS_STATEVAL_MAX_BUFFERLENGTH 50 | Maximum buffer length for average calculating of leading value velocity |

7.3 Data types

Data structure

Overview of the LFS_FlyingSaw data types and structure. Each data type is explained in detail below.

| Name of the structure | Content |
|---|---|
| LFS_typeAutoCutting | This structure contains all data required to simulate a cut in conjunction with flying saw application. Declared in: LFlyingSaw_Types/LFS_typeAutoCutting |
| LFS_typeAxisTOs | This structure contains all in FlyingSaw application required TOs using datatype DB_ANY. Declared in: LFlyingSaw_Types/LFS_typeAxisTOs |
| LFS_type CutPositionBuffer | This structure contains the memory in which the cut positions with the associated position deviations are saved. Declared in: LFlyingSaw_Types/LFS_typeCutPositionBuffer |
| LFS_type CutPositionBufferManagement | This structure contains the internal data area for entering precise cut position and cut position deviation for the print mark correction. Declared in: LFlyingSaw_Types/LFS_typeCutPositionBufferManagement |
| LFS_typeFlyingSaw | This structure contains the complete global data of the SIMATIC Flying Saw application. Declared in: LFlyingSaw_Types/LFS_typeFlyingSaw |
| LFS_type FlyingSawAxisCommand | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSawAxis. Declared in: LFlyingSaw_Types/LFS_typeFlyingSawAxisCommand |
| LFS_type FlyingSawAxisOutput | This structure contains all the required feedback signals of the FlyingSawAxis. Declared in: LFlyingSaw_Types/LFS_typeFlyingSawAxisOutput |
| LFS_type FlyingSawAxisServoValues | This structure contains all the required feedback signals of the FlyingSawAxis used in servo clock. Declared in: LFlyingSaw_Types/LFS_typeFlyingSawAxisServoValues |
| LFS_type FlyingSawInfo | The structure includes data about the actual leading value, the actual position of the leading value as well as its length from the perspective of the flying saw. Declared in: LFlyingSaw_Types/LFS_typeFlyingSawInfo |
| LFS_type LCMRetProfileAccel | Return structure of FC LCMRetProfileAccel Declared in: LFlyingSaw_Types/LFS_typeLCMRetProfileAccel |
| LFS_type LCMRetProfileDist | Return structure of FC LCMRetProfileDist Declared in: LFlyingSaw_Types/LFS_typeLCMRetProfileDist |
| LFS_type LCMRetProfileJerk | Return structure of FC LCMRetProfileJerk Declared in: LFlyingSaw_Types/LFS_typeLCMRetProfileJerk |
| LFS_type LCMRetProfileTime | Return structure of des FC LCMRetProfileTime Declared in: LFlyingSaw_Types/LFS_typeLCMRetProfileTime |
| LFS_type LeadingValueCommand | This structure contains the command interface to the axis FB for the LeadingValue (Axis or ExternalEncoder!) Declared in: LFlyingSaw_Types/LFS_typeLeadingValueCommand |
| LFS_typeLeadingValue MeasuringInputCommand | This structure contains the command interface to the MeasuringInput Declared in: LFlyingSaw_Types/LFS_typeLeadingValueMeasuringInputCommand |
| LFS_typeLeadingValue MeasuringInputOutput | This structure contains all the required feedback signals of the MeasuringInput. Declared in: LFlyingSaw_Types/LFS_typeLeadingValueMeasuringInputOutput |
| LFS_type LeadingValueOutput | This structure contains all the required feedback signals of the LeadingValue. (Axis or ExternalEncoder!) Declared in: LFlyingSaw_Types/LFS_typeLeadingValueOutput |

7 Description of the data and their structure

| Name of the structure | Content |
|-------------------------|---|
| LFS_typeLeadingValueTOs | This structure contains all possible TOs which can be assigned to a LeadingValue. Declared in: LFlyingSaw_Types/LFS_typeLeadingValueTOs |
| LFS_typeMeasuringValue | This structure contains the internal data area for determining the cut position. Declared in: LFlyingSaw_Types/LFS_typeMeasuringValue |
| LFS_typeShiftPosCalc | This structure contains all relevant data for supervision of dynamic start position adaption. Declared in: LFlyingSaw_Types/LFS_typeShiftPosCalc |
| LFS_typeUsersInterface | The structure contains the interface for users to enter geometrical and motion data of the mechanical system of the shears – and to specify operating variants. Declared in: LFlyingSaw_Types/LFS_typeUsersInterface |

7.3.1 LFS_typeAutoCutting (UDT)

Description

This structure contains all the required parameter for simulating a cut with defined time if no real machine is available: LFlyingSaw_Types/BasicTypes/LFS_typeAutoCutting

Parameter description

| Identifier | Data type | Default value | Description |
|-------------------|-----------|---------------|--------------------------|
| autoCuttingActive | Bool | FALSE | Test auto cutting active |
| autoCuttingTime | Int | 100 | Test auto cutting time |

7.3.2 LFS_typeAxisTOs (UDT)

Description

This structure contains all the required TOs as DB_ANY. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeAxisTOs

Parameter description

| Identifier | Data type | Default value | Description |
|-----------------|---|---------------|--|
| toFlyingSawAxis | DB_ANY | --- | Interconnection of FlyingSaw axis TO |
| leadingValue | Array[1..LFS_MAX_NUMBER_OF_LEADING_VALUES] of LFS_typeLeadingValueTOs | --- | This structure contains all necessary TOs of a leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueTOs |

7.3.3 LFS_typeCutPositionBuffer (UDT)

Description

This structure contains the buffer in which the cut positions with the associated position deviations are saved. Declared in: LFlyingSawTypes/BasicTypes/LFS_typeCutPositionBuffer

Parameter description

| Identifier | Data type | Default value | Description |
|----------------------------------|----------------------------------|---------------|---|
| cutPositionsMeasured | Array[0..LFS_CPB_MAX-1] of LReal | --- | [mm] Buffer for the measured cut positions |
| cutPositionsMeasuredNumberModulo | Array[0..LFS_CPB_MAX-1] of DInt | --- | Buffer for the number of modulo of measured cut positions |
| cutPositionsRead | Array[0..LFS_CPB_MAX-1] of Bool | --- | Buffer of flag "cut position read" |
| cutPositionsEntered | Array[0..LFS_CPB_MAX-1] of Bool | --- | Buffer of flag "cut position entered" |
| OnTheSpotCutPositionsEntered | Array[0..LFS_CPB_MAX-1] of Bool | --- | Buffer of on the spot cut flags |

7.3.4 LFS_typeCutPositionBufferManagement (UDT)

Description

This structure contains the internal data area for entering precise cut position for the print mark cutting. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeCutPositionBufferManagement

Parameter description

| Identifier | Data type | Default value | Description |
|-------------------|---------------------------|---------------|--|
| cutPositionBuffer | LFS_typeCutPositionBuffer | --- | This structure contains the buffer in which the cut positions with the associated position deviations are saved. Declared in: LFlyingSawTypes/BasicTypes/LFS_typeCutPositionBuffer |
| bufferIn | Int | 0 | Pointer to the next input position of buffer |
| bufferOut | Int | 0 | Pointer to next output position of buffer |
| cutCorrectionWait | Int | 0 | Number of cuts without cut correction |
| bufferReadTrigger | Bool | FALSE | Start trigger to read the next buffer entry |

7.3.5 LFS_typeFlyingSaw (UDT)

Description

This structure contains the complete global data of the SIMATIC FlyingSaw application. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSaw

Parameter description

| Identifier | Data type | Default value | Description |
|-----------------------------|-------------------------------------|---------------|--|
| axisTOs | LFS_typeAxisTOs | --- | This structure contains all the required TOs as DB_ANY. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeAxisTOs |
| usersInterface | LFS_typeUsersInterface | --- | This structure contains the interface for the user to enter physical conditions, dynamics and FlyingSaw behaviour. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeUsersInterface |
| cutPositionBufferManagement | LFS_typeCutPositionBufferManagement | --- | This structure contains the internal data area for entering precise cut position for the print mark cutting. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeCutPositionBufferManagement |
| flyingSawInfo | LFS_typeFlyingSawInfo | --- | This structure contains the internal data area to display actual I values, actual cut position as well as binary signals for the FlyingSaw position. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawInfo |
| measuringValue | LFS_typeMeasuringValue | --- | This structure contains the internal measuring data area for the print mark cutting. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeMeasuringValue |
| cutLength | LReal | 800.0 | [mm] format length |
| execute | Bool | FALSE | Activates the mode of operation switchover with the operating mode specified in "Mode". |
| mode | DInt | 0 | Using mode, the mode is preselected, which is activated with the next positive edge at the execute input |
| stopCutting | Bool | FALSE | Cutting has been finished |
| knifeOut | Bool | FALSE | Tool is out of material |
| gapLength | LReal | 10.0 | Length of the gap |
| gap | Bool | FALSE | Move a gap afterwards a cut |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|----------------------------|-----------|-----------------|---|
| doubleCutLength | LReal | 100.0 | Length of double cut |
| doubleCut | Bool | FALSE | Activate double cut |
| onTheSpotCut | Bool | FALSE | Activate on the spot cut |
| skipNextCut | Bool | FALSE | Skip next cut |
| constantVelocityAtCut | Bool | FALSE | Assume constant leading value velocity during synchronous phase |
| numberLeadingValueSelected | Int | 0 | Number of selected leading value |
| done | Bool | FALSE | TRUE: Selected mode is activated |
| busy | Bool | FALSE | TRUE: Operating mode switchover is active |
| error | Bool | FALSE | TRUE: Displays an error within the FBs or at the flying saw axes. Details see errorID. |
| cut | Bool | FALSE | TRUE: FlyingSaw is in synchronousPhase |
| flyingSawInStartPos | Bool | FALSE | TRUE: FlyingSaw stands in its startposition |
| endSyncPosReached | Bool | FALSE | TRUE: FlyingSaw has reached the end of synchronous range |
| handoverPosReached | Bool | FALSE | TRUE: FlyingSaw has reached the handover position |
| onTheSpotCutPossible | Bool | FALSE | TRUE: On the spot cut is possible |
| onTheSpotCutDone | Bool | FALSE | TRUE: On the spot cut has been done |
| skipNextCutPossible | Bool | FALSE | TRUE: Skip next cut is possible |
| syncNotPossible | Bool | FALSE | TRUE: Synchronization is not possible, because upper limit for starting synchronization was overrun in automatic state "AR_GEARIN_FSA_ABSOLUTE" or "AR_GEARIN_FSA_RELATIVE" before starting synchronization |
| forSyncToLate | Bool | FALSE | TRUE: Synchronization is not possible, because upper limit for starting synchronization was overrun in automatic state "AR_WAIT_FOR_FLYING_SAW_START" or "AR_POS_STARTPOS_NEXT_START" before starting synchronization |
| numberLeadingValueActive | Int | 0 | Number of active leading value |
| errorID | DWord | 16#0000 0000 | Error code. The ErrorIDs are described in this document. |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|---|---|---------------|--|
| state | DInt | 0 | Active mode LFS_OM_ERROR (0): ERROR mode LFS_OM_DISABLE (1): DISABLE mode LFS_OM_START_POSITION (2): STARTPOSITION mode LFS_OM_AUTOMATIC (3): AUTOMATIC mode LFS_OM_MANUAL (4): MANUAL mode LFS_OM_NOTHING_SELECT ED (8): No mode change LFS_OM_CHANGING (9): Mode change active |
| flyingSawAxisActive | Bool | FALSE | TRUE: FlyingSaw axis is enabled |
| startPositionAutoAdaptAct | Bool | FALSE | Automatic adapting of startposition is active |
| userCommandFlyingSawAxis | LFS_typeFlyingSawAxisCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisCommand |
| userConfigFlyingSawAxis | LAxisCtrl_typeAxisConfig | --- | |
| internalCommandFlyingSawAxis | LFS_typeFlyingSawAxisCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisCommand |
| internalConfigFlyingSawAxis | LAxisCtrl_typeAxisConfigs | --- | |
| outputFlyingSawAxis | LFS_typeFlyingSawAxisOutput | --- | This structure contains all the required feedback signals of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisOutput |
| internalCommandLeadingValueMeasuringInput | LFS_typeLeadingValueMeasuringInputCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the measuring input. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLeadingValueMeasuringInputCommand |

| Identifier | Data type | Default value | Description |
|----------------------------------|--|---------------|--|
| outputLeadingValueMeasuringInput | LFS_typeLeadingValueMeasuringInputOutput | --- | This structure contains all the required feedback signals of the measuring input at the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputOutput |
| commandLeadingValue | LFS_typeLeadingValueCommand | --- | This structure contains the command interface to the axis FB, reduced to the requirements of the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueCommand |
| configLeadingValue | LAxisCtrl_typeAxisConfig | --- | |
| outputLeadingValue | LFS_typeLeadingValueOutput | --- | This structure contains all the required feedback signals of the FlyingSaw axis, Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisOutput |

7.3.6 LFS_typeFlyingSawAxisCommand (UDT)

Description

This structure contains the command interface to the axis FB, reduced to the requirements of the FlyingSaw axis. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisCommand

Parameter description

| Identifier | Data type | Default value | Description |
|--------------|-----------|---------------|---|
| enable | Bool | FALSE | TRUE: Enable functionality of FB |
| enableAxis | Bool | FALSE | TRUE: Set axis enable; FALSE: Remove axis enable |
| resetAxis | Bool | FALSE | Rising edge: Acknowledgment of technology alarms or restart of the axis (depending on configuration) |
| jogForward | Bool | FALSE | Rising edge: Move an axis in jog mode (forward); Falling edge: Stop jogging |
| jogBackward | Bool | FALSE | Rising edge: Move an axis in jog mode (backward); Falling edge: Stop jogging |
| moveVelocity | Bool | FALSE | Rising edge: Move an axis at constant velocity/speed |
| stop | Bool | FALSE | Rising edge: Brake an axis until it comes to a standstill. Note: MC_Halt is triggered internally |
| fastStop | Bool | FALSE | Rising edge: Brake an axis until it comes to a standstill (with fastStop dynamics). Note: MC_Halt is triggered internally |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|-----------------|-----------|---------------|--|
| torqueLimiting | Bool | FALSE | TRUE: Enable force/torque limiting |
| homing | Bool | FALSE | Rising edge: Home axis |
| posRelative | Bool | FALSE | Rising edge: Move an axis relative to its position when execution of the job began |
| posAbsolute | Bool | FALSE | Rising edge: Move an axis to an absolute position |
| gearInRelative | Bool | FALSE | Rising edge: Start a gearing operation (relative) |
| gearInAbsolute | Bool | FALSE | Rising edge: Start a gearing operation (absolute) |
| offset | Bool | FALSE | Rising edge: Start an offset operation |
| simulation | Bool | FALSE | TRUE: Axis is in gearIn simulation mode |
| phasing | Bool | FALSE | Rising edge: Start a phasing operation |
| posSuperimposed | Bool | FALSE | Rising edge: Start a superimposed operation |

7.3.7 LFS_typeFlyingSawAxisOutput (UDT)

Description

This structure contains all the required feedback signals of the FlyingSaw axis.
Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisOutput

Parameter description

| Identifier | Data type | Default value | Description |
|----------------------|-----------|---------------|--|
| valid | Bool | FALSE | TRUE: Axis-FB displays valid |
| busy | Bool | FALSE | TRUE: Axis-FB active |
| error | Bool | FALSE | TRUE: Axis-FB in error state. Status and Diagnostic provide further information. The meaning can be looked up in the LAxisCtrl manual. |
| status | Word | 16#0000 | Status word of the axis FB. The meaning can be looked up in the LAxisCtrl operating instructions. |
| commandBusy | Bool | FALSE | TRUE: Selected command active. There is an extra variable for the superimposed movement. |
| commandDone | Bool | FALSE | TRUE: Selected command completed. There is an extra variable for the superimposed movement. |
| commandAborted | Bool | FALSE | TRUE: Selected command canceled. There is an extra variable for the superimposed movement. |
| superimposedBusy | Bool | FALSE | TRUE: Superimposed command active |
| superimposedDone | Bool | FALSE | TRUE: Superimposed command completed |
| superimposedAborted | Bool | FALSE | TRUE: Superimposed command canceled |
| homingBusy | Bool | FALSE | TRUE: Homing active |
| homingDone | Bool | FALSE | TRUE: Homing completed |
| homingAborted | Bool | FALSE | TRUE: Homing canceled |
| jogSelected | Bool | FALSE | TRUE: Jog operation selected |
| moveVelocitySelected | Bool | FALSE | TRUE: Velocity-controlled operation selected |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|-------------------------|---------------------------|---------------|---|
| posAbsoluteSelected | Bool | FALSE | TRUE: Absolute positioning selected |
| posRelativeSelected | Bool | FALSE | TRUE: Relative positioning selected |
| posSuperimposedSelected | Bool | FALSE | TRUE: MC_MoveSuperimposed selected |
| homingSelected | Bool | FALSE | TRUE: Homing selected |
| stopSelected | Bool | FALSE | TRUE: Stop selected |
| fastStopSelected | Bool | FALSE | TRUE: Stop (fast) selected |
| torqueLimitingSelected | Bool | FALSE | TRUE: Torque limiting is selected |
| gearInRelativeSelected | Bool | FALSE | TRUE: Relative synchronous operation selected |
| gearInAbsoluteSelected | Bool | FALSE | TRUE: Absolute synchronous operation selected |
| phasingSelected | Bool | FALSE | TRUE: MC_Phasing is selected |
| offsetSelected | Bool | FALSE | TRUE: MC_Offset is selected |
| diagnostics | LAxisCtrl_typeDiagnostics | --- | |
| toFollowingAxis | Bool | FALSE | TRUE: Axis is an following axis |
| toDriveCommunicationOk | Bool | FALSE | TRUE: drive exists and is switched on |
| toEnabled | Bool | FALSE | TRUE: TO is switched on |
| toError | Bool | FALSE | TRUE: TO is in the error state. More detailed information can be found in the TO structure. |
| toErrorReaction | DInt | 0 | Error response |
| toDriveInOperation | Bool | FALSE | TRUE: drive is ready and is generating a torque |
| toRestartActive | Bool | FALSE | TRUE: Restart at the TO active |
| toStandstill | Bool | FALSE | TRUE: drive is at a standstill |
| toHomed | Bool | FALSE | TRUE: axis-TO is homed |
| toHomingActive | Bool | FALSE | TRUE: Homing is active at the TO |
| toJogActive | Bool | FALSE | TRUE: Jog operation is active at the TO |
| toSynchronizing | Bool | FALSE | TRUE: Synchronizing is active at the TO |
| toSynchronous | Bool | FALSE | TRUE: The TO is synchronized |
| toActualPosition | LReal | 0.0 | [mm] Actual position of the TO |
| toActualVelocity | LReal | 0.0 | [mm/s] Actual velocity of the TO |
| toActualAcceleration | LReal | 0.0 | [mm/s ²] Actual acceleration of the TO |
| toModuloEnabled | Bool | FALSE | TRUE: Modulo length is activated at the TO |
| toModuloLength | LReal | 0.0 | [mm] Modulo length |
| toNotPositionControlled | Bool | FALSE | TRUE: The TO is not in the position-controlled mode |
| toMaxVelocity | LReal | 0.0 | [mm/s] Maximum velocity of the TO |
| toMaxAcceleration | LReal | 0.0 | [mm/s ²] Maximum acceleration of the TO |
| toMaxDeceleration | LReal | 0.0 | [mm/s ²] Maximum deceleration of the TO |
| toLeadScrew | LReal | 0.0 | [mm] Spindle pitch (leadscrew) |

| Identifier | Data type | Default value | Description |
|------------------------|-----------|---------------|--|
| toGearFactor | LReal | 0.0 | [-] Gear ratio |
| toVirtualAxisMode | UDInt | 0 | 0 not a virtual axis 1 virtual axis |
| usersCommandActive | Bool | FALSE | TRUE: TO can be operated by the user. FALSE: TO is operated via the standard application. |
| toStatusSensorState | DInt | 0 | Status of the encoder value |
| toSetVelocity | LReal | 0.0 | Set velocity from TO |
| toSyncMotionLVVelocity | LReal | 0.0 | [TO_Unit] Effective leading value velocity of the synchronization (TO.StatusSynchronizedMotion.EffectiveLeadingValue.Velocity). This velocity is the leading velocity for the synchronization of the flying saw axis |
| toSyncMotionLVPosition | LReal | 0.0 | [TO_Unit] Effective leading value position of the synchronization (TO.StatusSynchronizedMotion.EffectiveLeadingValue.Position). This position is the leading position for the synchronization of the flyingSaw axis |

7.3.8 LFS_typeFlyingSawAxisServoValues (UDT)

Description

This structure contains values to display the TO data from FlyingSaw axis read in the servo clock cycle. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeFlyingSawAxisServoValues

Parameter description

| Identifier | Data type | Default value | Description |
|-----------------------------|-----------|---------------|---|
| flyingSawAxisPosition | LReal | 0.0 | [mm] set position of FlyingSaw axis |
| flyingSawAxisActualPosition | LReal | 0.0 | [mm] actual position of FlyingSaw axis |
| flyingSawAxisStatusword | DWord | 16#00000000 | statusword of FlyingSaw axis |
| toSyncMotionLVPosition | LReal | 0.0 | [mm] Effective leading value position of the synchronization (TO.StatusSynchronizedMotion.EffectiveLeadingValue.Position). This position is the leading position for the synchronization of the flyingSaw axis |
| toSyncMotionLVVelocity | LReal | 0.0 | [mm/s] Effective leading value velocity of the synchronization (TO.StatusSynchronizedMotion.EffectiveLeadingValue.Velocity). This velocity is the leading velocity for the synchronization of the flying saw axis |

7.3.9 LFS_typeFlyingSawInfo (UDT)

Description

This structure contains the internal data area to display actual I values, actual cut position as well as binary signals for the FlyingSaw position. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawInfo

Parameter description

| Identifier | Data type | Default value | Description |
|--|-----------|---------------|---|
| toLeadingValueActive | DB_ANY | --- | DB number of active leading value |
| toLeadingValueMeasuringInputActive | DB_ANY | --- | Measuring input active. This variable is needed for implezite value transformation. |
| toLeadingValueSyncAxisLeadingValueActive | DB_ANY | --- | If the leading axis of the FlyingSaw axis is also a synchronous axis, it is possible that this leading axis has another leading axis. TheDB-number of this master axis is entered in this variable. |
| numberOfLeadingValuesEntered | Int | 0 | Number of possible leading values |
| changeLeadingValueActive | Bool | FALSE | Change of leading value active |
| axisAsLeadingValue | Bool | FALSE | TRUE: Leading value is a real or virtual axis (no external encoder) FALSE: Leadingvalue is an external encoder |
| externalEncoderAsLeadingValue | Bool | FALSE | TRUE: Leading value is an external encoder FALSE: No external encoder specified as leading value |
| leadingValueActive | Bool | FALSE | TRUE: Leading value axis is enabled |
| leadingValueStandstill | Bool | FALSE | TRUE: Leading value axis is in standstill |
| leadingValueDirectionPositive | Bool | FALSE | TRUE: Leading value moves in positive direction |
| leadingValueDirectionNegative | Bool | FALSE | TRUE: Leading value moves in negative direction |
| materialPosActualStart | LReal | 0.0 | [mm] Material position when FlyingSaw starts movement |
| materialPosActualStartNumberModulo | DInt | 0 | [-] Number of modulo overflows of materialPosActualStart |
| materialPosActual | LReal | 0.0 | [mm] Actual material position |
| materialPosActualNumberModulo | DInt | 0 | [-] Number of modulo overflows of actual material position |
| onTheSpotCutSelected | Bool | FALSE | On the spot cut is selected |
| maZeroPos | LReal | 0.0 | [mm] Material position when printmark reach FlyingSaw axis zero point |
| maZeroPosNumberModulo | DInt | 0 | [-] Number of modulo overflows of maZeroPos |
| maSyncPos | LReal | 0.0 | [mm] Actual sychron position on material |
| maSyncPosNumberModulo | DInt | 0 | [-] Number of modulo overflows of maSyncPos |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|-----------------------------------|-----------|---------------|---|
| maOffset | LReal | 0.0 | [mm] Actual offset between the reference systems material-axis and the axis of the flying saw |
| maPosForTechnologie | LReal | 0.0 | [mm] Actual position of the material axis in the reference system of the flying saw axis |
| cutLengthActivated | LReal | 0.0 | [mm] Activated format length |
| leadingValueDeltaSyncPos | LReal | 0.0 | [mm] Leading value difference between two synchronous positions |
| deltaTwoCutsCutLength | LReal | 0.0 | [mm] Measured/Calculated length between two cuts |
| interruptProductionActivated | Bool | FALSE | Interrupt production is activated |
| continueProductionActivated | Bool | FALSE | Continue production is activated |
| productionInterrupted | Bool | FALSE | Production is interrupted |
| productionContinued | Bool | FALSE | Production is continued |
| lowerLimit | LReal | 0.0 | [mm] Minimum material position to start synchronization |
| lowerLimitNumberModulo | DInt | 0 | [-] Number of modulo overflows of lowerLimit |
| deltaNumberModuloLowerLimit | DInt | 0 | [-] Modulo difference between LowerLimit and the actual material position |
| upperLimitToLate | LReal | 0.0 | [mm] Maximum material position to start synchronization |
| upperLimitToLateNumberModulo | DInt | 0 | [-] Number of modulo overflows of upperLimitToLate |
| upperLimitNotPossible | LReal | 0.0 | [mm] Material position to cancel synchronization |
| upperLimitNotPossibleNumberModulo | DInt | 0 | [-] Number of modulo overflows of upperLimitNotPossible |
| deltaNumberModuloToLate | DInt | 0 | [-] Modulo difference between UpperLimitToLate and the actual material position |
| deltaNumberModuloNotPossible | DInt | 0 | [-] Modulo difference between UpperLimitNotPossible and the actual material position |
| cutPositionGenerationMode | DInt | 2 | Generation of cutposition 1: printmark detection, 2: cut to format length |
| cutPositionMeasureMode | DInt | 1 | Determination of buffer entries 1: real measuring input, 2: simulate printmark |
| shiftPosition | LReal | 0.0 | [mm] Shift position of startposition when adapting it |
| estimatedCutWay | LReal | 180.0 | [mm] Estimated material and FlyingSaw way during cutting without gap and double cut |
| syncPositionMaster | LReal | 0.0 | [mm] Actual SyncPosition of the leading value axis |
| syncPositionMasterNumberModulo | DInt | 0 | [-] Number of modulo overflows of the actual SyncPosition of the leading value axis |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|----------------------------|-----------|---------------|---|
| syncPositionSlave | LReal | 0.0 | [mm] Actual SyncPosition of the FlyingSaw axis |
| actualCuttingTime | LReal | 0.0 | [ms] actual cutting time |
| materialVelocityActual | LReal | 0.0 | [mm/s] actual material velocity |
| mASyncDistance | LReal | 0.0 | [mm] material distance to be moved before starting next synchronization |
| fsaPositionMaximum | LReal | 0.0 | Maximum FlyingSaw position at stillstand after cut, before driving back to startposition |
| materialPassed | LReal | 0.0 | [mm] Material distance from the start of the cut until the shears come to a standstill |
| maPositionAtFSASstandstill | LReal | 0.0 | [mm] material position when FlyingSaw is at stillstand after cut and before returning back to startposition |
| syncLengthActual | LReal | 0.0 | [mm] Actual synchronizing length |
| measuredAtStandstill | Bool | FALSE | TRUE: Sensor was activated when the shears were at a standstill |
| accelerationActive | LReal | 0.0 | [mm/s ²] active acceleration |
| jerkActive | LReal | 0.0 | [mm/s ³] active jerk |
| runningBackTimeActual | LReal | 0.0 | [s] actual running back time |

7.3.10 LFS_typeLCMRetProfileAccel (UDT)

Description

This structure contains all internal values to calculate an acceleration based profile. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLCMRetProfileAccel

Parameter description

| Identifier | Data type | Default value | Description |
|----------------|-----------|---------------|-------------|
| accel | LReal | 0.0 | |
| functionResult | DInt | 0 | |

7.3.11 LFS_typeLCMRetProfileDist (UDT)

Description

This structure contains all internal values to calculate the distance how long a profile needs to be done. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLCMRetProfileDist

Parameter description

| Identifier | Data type | Default value | Description |
|----------------|-----------|---------------|-------------|
| dist | LReal | 0.0 | |
| functionResult | DInt | 0 | |

7.3.12 LFS_typeLCMRetProfileJerk (UDT)**Description**

This structure contains all internal values to calculate an jerk based profile.
Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLCMRetProfileJerk

Parameter description

| Identifier | Data type | Default value | Description |
|----------------|-----------|---------------|-------------|
| jerk | LReal | 0.0 | |
| functionResult | DInt | 0 | |

7.3.13 LFS_typeLCMRetProfileTime (UDT)**Description**

This structure contains all internal values to calculate the time how long a profile needs to be done. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLCMRetProfileTime

Parameter description

| Identifier | Data type | Default value | Description |
|----------------|-----------|---------------|-------------|
| tGes | LReal | 0.0 | |
| functionResult | DInt | 0 | |

7.3.14 LFS_typeLeadingValueCommand (UDT)**Description**

This structure contains the command interface to the axis FB, reduced to the requirements of the leading value. Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeLeadingValueCommand

Parameter description

| Identifier | Data type | Default value | Description |
|--------------|-----------|---------------|--|
| enable | Bool | FALSE | TRUE: Enable functionality of FB |
| resetAxis | Bool | FALSE | Rising edge: Acknowledgment of technology alarms or restart of the axis (depending on configuration) |
| enableAxis | Bool | FALSE | TRUE: Set axis enable; FALSE: Remove axis enable |
| jogForward | Bool | FALSE | Rising edge: Move an axis in jog mode (forward); Falling edge: Stop jogging |
| jogBackward | Bool | FALSE | Rising edge: Move an axis in jog mode (backward); Falling edge: Stop jogging |
| moveVelocity | Bool | FALSE | Rising edge: Move an axis at constant velocity/speed |
| posAbsolute | Bool | FALSE | Rising edge: Move an axis to an absolute position |
| posRelative | Bool | FALSE | Rising edge: Move an axis relative to its position when execution of the job began |
| homing | Bool | FALSE | Rising edge: Home axis |
| stop | Bool | FALSE | Rising edge: Brake an axis until it comes to a standstill. Note: MC_Halt is triggered internally |

| Identifier | Data type | Default value | Description |
|-----------------|-----------|---------------|---|
| fastStop | Bool | FALSE | Rising edge: Brake an axis until it comes to a standstill (with fastStop dynamics). Note: MC_Halt is triggered internally |
| torqueLimiting | Bool | FALSE | TRUE: Enable force/torque limiting |
| gearInRelative | Bool | FALSE | Rising edge: Start a gearing operation (relative) |
| gearInAbsolute | Bool | FALSE | Rising edge: Start a gearing operation (absolute) |
| phasing | Bool | FALSE | Rising edge: Start a phasing operation |
| posSuperimposed | Bool | FALSE | Rising edge: Start a superimposed operation |

7.3.15 LFS_typeLeadingValueMeasuringInputCommand (UDT)

Description

This structure contains the command interface to the axis FB, reduced to the requirements of the measuring input. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputCommand

Parameter description

| Identifier | Data type | Default value | Description |
|------------------|-----------|---------------|---|
| miResetExecute | Bool | FALSE | TRUE: Reset (MI) activated |
| miResetRestart | Bool | FALSE | TRUE: Reset realized with restart |
| miExecute | Bool | FALSE | TRUE: Measuring input active |
| miMode | DInt | 0 | Measurement type 0 Measurement of the next rising edge 1 Measurement of the next falling edge 2 Measurement of the next two edges 3 Measurement at the two edges, starting with the rising edge 4 Measurement at the two edges, starting with the falling edge |
| miMeasuringRange | Bool | FALSE | TRUE: Only sense the measured values within the measuring range |
| miStartPosition | LReal | 0.0 | Initial position of the measuring range |
| miEndPosition | LReal | 0.0 | End position of the measuring range |

7.3.16 LFS_typeLeadingValueMeasuringInputOutput (UDT)

Description

This structure contains all the required feedback signals of the measuring input at the leading value. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeLeadingValueMeasuringInputOutput

Parameter description

| Identifier | Data type | Default value | Description |
|-----------------------|-----------|---------------|-----------------------------------|
| miResetDone | Bool | FALSE | TRUE: Reset (MI) completed |
| miResetBusy | Bool | FALSE | TRUE: Reset (MI) active |
| miResetCommandAborted | Bool | FALSE | TRUE: Reset (MI) command canceled |
| miResetError | Bool | FALSE | TRUE: Reset (MI) error active |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|----------------------------|-----------|---------------|---|
| miResetErrorId | Word | 16#0000 | Reset (MI) error number |
| miDone | Bool | FALSE | TRUE: Measurement successfully completed Measured values are valid |
| miBusy | Bool | FALSE | TRUE: Measurement is being executed |
| miCommandAborted | Bool | FALSE | TRUE: Measurement task was canceled |
| miError | Bool | FALSE | TRUE: An error occurred during processing. Information relating to the error cause can be taken from parameter "ErrorID" |
| miErrorId | Word | 16#0000 | Error identification of the FB MC_MeasuringInput |
| miMeasuredValue1 | LReal | 0.0 | First measured value |
| miMeasuredValue2 | LReal | 0.0 | Second measured value |
| leadingValueMeasuringInput | Bool | FALSE | TRUE: Measuring input available at the leading value |

7.3.17 LFS_typeLeadingValueOutput (UDT)

Description

This structure contains all the required feedback signals of the FlyingSaw axis,
Declared in: LFlyingSaw_Types/BasicTypes/ LFS_typeFlyingSawAxisOutput

Parameter description

| Identifier | Data type | Default value | Description |
|---------------------|-----------|---------------|--|
| valid | Bool | FALSE | TRUE: Axis-FB displays valid |
| busy | Bool | FALSE | TRUE: Axis-FB active |
| error | Bool | FALSE | TRUE: Axis-FB in error state. Status and Diagnostic provide further information. The meaning can be looked up in the LAxisCtrl manual. |
| status | Word | 16#0000 | Status word of the axis FB. The meaning can be looked up in the LAxisCtrl operating instructions. |
| commandBusy | Bool | FALSE | TRUE: Selected command active. There is an extra variable for the superimposed movement. |
| commandDone | Bool | FALSE | TRUE: Selected command completed. There is an extra variable for the superimposed movement. |
| commandAborted | Bool | FALSE | TRUE: Selected command canceled. There is an extra variable for the superimposed movement. |
| superimposedBusy | Bool | FALSE | TRUE: Superimposed command active |
| superimposedDone | Bool | FALSE | TRUE: Superimposed command completed |
| superimposedAborted | Bool | FALSE | TRUE: Superimposed command canceled |
| homingBusy | Bool | FALSE | TRUE: Homing active |
| homingDone | Bool | FALSE | TRUE: Homing completed |
| homingAborted | Bool | FALSE | TRUE: Homing canceled |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|------------------------------|---------------------------|---------------|---|
| jogSelected | Bool | FALSE | TRUE: Jog operation selected |
| moveVelocitySelected | Bool | FALSE | TRUE: Velocity-controlled operation selected |
| posAbsoluteSelected | Bool | FALSE | TRUE: Absolute positioning selected |
| posRelativeSelected | Bool | FALSE | TRUE: Relative positioning selected |
| posSuperimposedSelected | Bool | FALSE | TRUE: MC_MoveSuperimposed selected |
| homingSelected | Bool | FALSE | TRUE: Homing selected |
| stopSelected | Bool | FALSE | TRUE: Stop selected |
| fastStopSelected | Bool | FALSE | TRUE: Stop (fast) selected |
| torqueLimitingSelected | Bool | FALSE | TRUE: Torque limiting is selected |
| gearInRelativeSelected | Bool | FALSE | TRUE: Relative synchronous operation selected |
| gearInAbsoluteSelected | Bool | FALSE | TRUE: Absolute synchronous operation selected |
| phasingSelected | Bool | FALSE | TRUE: MC_Phasing is selected |
| diagnostics | LAxisCtrl_typeDiagnostics | --- | |
| toFollowingAxis | Bool | FALSE | TRUE: Axis is an following axis |
| toDriveCommunicationOk | Bool | FALSE | TRUE: drive exists and is switched on |
| toEnabled | Bool | FALSE | TRUE: TO is switched on |
| toError | Bool | FALSE | TRUE: TO is in the error state. More detailed information can be found in the TO structure. |
| toErrorReaction | DInt | 0 | Error response |
| toDriveInOperation | Bool | FALSE | TRUE: drive is ready and is generating a torque |
| toRestartActive | Bool | FALSE | TRUE: Restart at the TO active |
| toStandstill | Bool | FALSE | TRUE: drive is at a standstill |
| toHomed | Bool | FALSE | TRUE: axis-TO is homed |
| toHomingActive | Bool | FALSE | TRUE: Homing is active at the TO |
| toJogActive | Bool | FALSE | TRUE: Jog operation is active at the TO |
| toSynchronizing | Bool | FALSE | TRUE: Synchronizing is active at the TO |
| toSynchronous | Bool | FALSE | TRUE: The TO is synchronized |
| toActualPosition | LReal | 0.0 | [mm] Actual position of the TO |
| toActualPositionNumberModulo | DInt | 0 | [-] Actual number of modulo cycles of actual position of the leading value |
| toActualVelocity | LReal | 0.0 | [mm/s] Actual velocity of the TO |
| toActualAcceleration | LReal | 0.0 | [mm/s ²] Actual acceleration of the TO |
| toModuloEnabled | Bool | FALSE | TRUE: Modulo length is activated at the TO |
| toModuloLength | LReal | 0.0 | [mm] Modulo length |
| toNotPositionControlled | Bool | FALSE | TRUE: The TO is not in the position-controlled mode |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|-------------------------------|-----------|---------------|---|
| toDirectionPositive | Bool | FALSE | TRUE: leading value moves in positive direction |
| toDirectionNegative | Bool | FALSE | TRUE: leading value moves in negative direction |
| toMaxVelocity | LReal | 0.0 | [mm/s] Maximum velocity of the TO |
| toMaxAcceleration | LReal | 0.0 | [mm/s ²] Maximum acceleration of the TO |
| toMaxDeceleration | LReal | 0.0 | [mm/s ²] Maximum deceleration of the TO |
| toLeadScrew | LReal | 0.0 | [mm] Spindle pitch (leadscrew) |
| toGearFactor | LReal | 0.0 | [-] Gear ratio |
| toVirtualAxisMode | UDInt | 0 | 0 not a virtual axis 1 virtual axis |
| axisAsLeadingValue | Bool | FALSE | TRUE: The leading value is an axis |
| externalEncoderAsLeadingValue | Bool | FALSE | TRUE: The leading value is an external encoder |
| toStatusSensorState | DInt | 0 | Status of the encoder value |
| toSetVelocity | LReal | 0.0 | Set velocity from TO |
| toExtEnclnAcceleration | Bool | FALSE | Material on ExternalEncoder is in acceleration |
| UnitsConversion | Struct | --- | Factores for unit conversion of leading value unit to FlyingSaw unit |
| LengthUnitConversion | LReal | 0.0 | Length unit conversion from leading value unit to mm |
| VelocityUnitConversion | LReal | 0.0 | Velocity unit conversion from leading value unit to mm/s |
| AccelerationUnitConversion | LReal | 0.0 | Acceleration unit conversion from leading value unit to mm/s ² |

© Siemens AG 2022. All rights reserved.

7.3.18 LFS_typeLeadingValueTOs (UDT)

Description

This structure contains all necessary TOs of a leading value. Declared in:
LFlyingSaw_Types/BasicTypes/ LFS_typeLeadingValueTOs

Parameter description

| Identifier | Data type | Default value | Description |
|------------------------|-----------|---------------|---|
| toLeadingValue | DB_ANY | --- | TO leading Value |
| toMeasuringInput | DB_ANY | --- | TO measuring input according to leading value |
| toSyncAxisLeadingValue | DB_ANY | --- | TO leading value for leading value, if leading value is an axis |

7.3.19 LFS_typeMeasuringValue (UDT)**Description**

This structure contains the internal measuring data area for the print mark cutting.
Declared in: LFLyingSaw_Types/BasicTypes/ LFS_typeMeasuringValue

Parameter description

| Identifier | Data type | Default value | Description |
|--------------------------------------|-----------|---------------|--|
| startMeasuring | Bool | FALSE | Flag: Start of measured value detection |
| cutLengthActivated | LReal | 0.0 | [mm] Actual cut length |
| measuredValueNew | LReal | 0.0 | [mm] Actual measured value |
| measuredValueNewNumberModulo | DInt | 0 | [-] Number of modulo overflows of the actual measured value |
| measuredValueOld | LReal | 0.0 | [mm] Measured value, old |
| measuredValueOldNumberModulo | DInt | 0 | [-] Number of modulo overflows of the old measured value |
| mvDelta | LReal | 0.0 | [mm] Difference between the new and old measured value |
| waitForFirstCutPosition | Bool | FALSE | Flag: Wait for first measured value |
| waitForCyclCutPosition | Bool | FALSE | Flag Wait for cyclic measured value |
| cutPositionMeasuringActive | Bool | FALSE | Flag: Print mark detection has been activated. Waiting for the first measured value |
| startPosAtSensorDetected | Bool | FALSE | Flag: Start position (first printmark) measured |
| applicationInAutomatic | Bool | FALSE | Application in operation mode "LFS_AUTOMATIC" |
| newCutPositionEntered | Bool | FALSE | Flag: New cut position entered |
| setPosNextCutPosAtSensor | LReal | 0.0 | [mm] Interpolated next cut position at the sensor |
| setPosNextCutPosAtSensorNumberModulo | DInt | 0 | [-] Number of modulo overflows of the interpolated next cut position at the sensor |
| setPosToleranceRangeStart | LReal | 0.0 | [mm] Tolerance bandwidth: Start of the search for the next cutting position (value in mm before expected print mark position) |
| setPosToleranceRangeEnd | LReal | 0.0 | [mm] Tolerance bandwidth: End of the search for the next cutting position (value in mm after expected print mark position) |
| cutPositionErrorCounter | Int | 0 | Cut position error counter. Counter at which no measured value is present, but the calculated value is used. This value is reset at the next recognized print mark |
| cutLengthMeasured | LReal | 0.0 | [mm] Measured cut length |
| cutPosAtSensor | LReal | 0.0 | [mm] Measured material position if the cut position is at the measuring point |
| cutPosAtSensorNumberModulo | DInt | 0 | [-] Number of modulo overflows of the measured material position if the cut position is at the measuring point |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|--------------------------------------|-----------|---------------|--|
| cutPosAtFlyingSawZeroPos | LReal | 0.0 | [mm] Interpolated material position if the cut position is at the FlyingSaw zero point |
| cutPosAtFlyingSawZeroPosNumberModulo | DInt | 0 | [-] Number of modulo overflows of the interpolated material position if the cut position is at the FlyingSaw zero point |
| cutPosAtSyncPos | LReal | 0.0 | [mm] Interpolated material position if the cut position occurs at the synchronous point |
| cutPosAtSyncPosNumberModulo | DInt | 0 | [-] Number of modulo overflows of the interpolated material position if the cut position occurs at the synchronous point |
| blindLengthPosition | LReal | 0.0 | [mm] Interpolated material position if the blind length is run through |
| blindLengthPositionNumberModulo | DInt | 0 | [-] Number of modulo overflows of the interpolated material position if the blind length is run through |
| blindLengthRunThrough | Bool | FALSE | Flag: blind length is run through |
| leadingValueModuloActive | Bool | FALSE | Flag: leading value modulo active |
| leadingValueModuloLength | LReal | 0.0 | [mm] leading value modulo length |

7.3.20 LFS_typeShiftPosCalc (UDT)

Description

This structure contains the internal variables for calculating an adapted startposition if needed. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeShiftPosCalc

Parameter description

| Identifier | Data type | Default value | Description |
|----------------------------|-----------|---------------|---|
| loopCount | DInt | 0 | [-] Loop counter of shiftposition calculation |
| shiftPosition | LReal | 0.0 | [mm] Last shift of start position |
| maStartSyncDistance | LReal | 0.0 | [mm] Web distance to next StartSync Position |
| fsaWayBackToActualStartpos | LReal | 0.0 | [mm] Way back of FlyingSaw to actual start position |
| shiftPositionNew | LReal | 0.0 | [mm] Actual shift of start position |
| functionResult | DInt | 0 | [-] Return value of distance calculation |

7.3.21 LFS_typeUsersInterface (UDT)**Description**

This structure contains the interface for the user to enter physical conditions, dynamics and FlyingSaw behaviour. Declared in: LFlyingSaw_Types/BasicTypes/LFS_typeUsersInterface

Parameter description

| Identifier | Data type | Default value | Description |
|------------------------|-----------|---------------|--|
| distanceToSensor | LReal | 200.0 | [mm] Distance between sensor of printmark detection and FlyingSaw axis zero point |
| startPos | LReal | 0.0 | [mm] Start position within the distance-reference system of the flying saw |
| syncPos | LReal | 100.0 | [mm] Position within the distance-reference system of the flying saw at which the synchronization operation has been completed (synchronous position) |
| maxStartPos | LReal | 350.0 | [mm] Maximum possible start position for dynamic start position determination |
| handoverPos | LReal | 540.0 | [mm] Handover position within the distance-reference system of the flying saw |
| endSyncPos | LReal | 550.0 | [mm] Maximum synchronous position within the distance-reference system of the flying saw at which the synchronous motion must have been completed (end of the synchronous range) |
| endPos | LReal | 600.0 | [mm] End point within the distance-reference system of the flying saw |
| toStartPosVelocity | LReal | 100.0 | [mm/s] Velocity when positioning to the start position |
| gapVelocity | LReal | 50.0 | [mm/s] Additional velocity when executing greating a gap |
| cutAcceleration | LReal | 100.0 | [mm/s ²] Acceleration when synchronizing for the cut |
| cutJerk | LReal | 1000000.0 | [mm/s ³] Jerk when synchronizing for the cut |
| toStartPosAcceleration | LReal | 100.0 | [mm/s ²] Acceleration when positioning to start position |
| toStartPosJerk | LReal | 1000000.0 | [mm/s ³] Jerk when positioning to start position |
| gapAcceleration | LReal | 100.0 | [mm/s ²] Acceleration when executing greating a gap |
| gapJerk | LReal | 1000000.0 | [mm/s ³] Jerk when executing greating a gap |
| gearingRatio | LReal | 1.0 | [-] Virtual gearing ratio between real material and measured values |
| cpDeltaToleranceRange | LReal | 10.0 | [mm] Half the tolerance bandwidth for the activation range of the cut position sensing |
| restart | Bool | FALSE | Flag: Restart (must set by user, is reset by application) |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|---------------------------------|-----------|---------------|--|
| interruptProduction | Bool | FALSE | Flag: Stopping the Flying Saw in the automatic mode (e.g. for STO) |
| continueProduction | Bool | FALSE | Flag: Reactivating the Flying Saw in the automatic mode (e.g. after STO) |
| cutPositionGenerationMode | DInt | 2 | Method to determine the cut position: LFS_CP_CALCULATED (2): Cut position is calculated and the material position specified by cutting to length LFS_CP_MEASURED (1): Cut position is measured and entered into the CutPositionBuffer |
| cutPositionMeasureMode | DInt | 1 | Methods to measure the cut position, only valid if cutPositionGenerationMode = LFS_CP_MEASURED (1): LFS_CPM_DETECTED (1): The cut position is measured using print mark and sensor LFS_CPM_SIMULATED (2): Cut position is calculated from the CutLength that has been selected |
| typeOfSynchronisation | DInt | 1 | Synchronizing method to synchronize to the material axis: LFS_BY_TIME (1): Time-related LFS_BY_LEADING_VALUE (2): Distance-related LFS_SYMMETRIC (3): Distance-related, without overshoot of the velocity |
| wayBackMode | DInt | 1 | LFS_MOVE_ZERO_POS (1): FlyingSaw travels directly back to startposition after cut LFS_RUN_HANOVER_POS (2): FlyingSaw travels to handover position after cut, before returning back to startposition |
| rboActive | Bool | FALSE | TRUE: Running back optimization is activated |
| rboByAcceleration | Bool | true | TRUE: Running back optimization by adapting the acceleration FALSE: Running back optimization by adapting the jerk |
| blindlength | LReal | 0.0 | [mm] Travelling distance without active measuring input when material started |
| lookForFirstPrintmarkPermanent | Bool | FALSE | TRUE: The measuring input detects each print mark and enters the position in the CutPositionBuffer |
| lookForFirstPrintmarkAsRequired | Bool | FALSE | Flag: The measuring input detects the next print mark and enters the position in the CutPositionBuffer (If done, the flag will be reset) |
| maxRunningBackTime | LReal | 0.0 | [s] Maximum running back time for running back optimization |
| sampleNumberLWAverageVelocity | UInt | 0 | [-] Number of measuring values used for calculation the average material velocity. (Used for „Constant Velocity at Cut“) |

7 Description of the data and their structure

| Identifier | Data type | Default value | Description |
|----------------------------|-----------|---------------|---|
| doubleCutDynamicFactor | LReal | 1.0 | [-] Dynamic factor for double cut, = 1.0: length of offset movement = double cut length, > 1.0: higher length of offset movement and therefore smoother offset movement |
| machineStandstillVelExtEnc | LReal | 5.0 | [TO Unit of leading value] As soon as the speed of the external encoder TO is below this value, the machine is assumed to be at standstill. External encoders do not have such a setting in the TO, but this is necessary for the application, e.g. for interrupt production. |
| machineAccelerationExtEnc | LReal | 5.0 | [TO Unit of leading value] As soon as the acceleration of the external encoder TO is below this value, the machine is assumed to be at constant speed. External encoders do not have such a setting in the TO, but this is necessary for the application. |

8 Operating the application

This application serves to simply get to know the functionality of the FB FlyingSaw as it is used in any user application and should be called. This application is prepared for the demonstration case; however, it can be directly adapted to suit the hardware of the user.

Preconditions

The following preconditions must be fulfilled to operate the application example:

- The SIMATIC TIA project is available online in the SIMATIC S7-15xxT.
- The parameterization for the appropriate application has been loaded into the SINAMICS using Starter.
CU320-2PN_2xTEL105 for "LeadingValue Axis"
or
CU320-2PN_2xTEL105_TEL83 for "LeadingValue EXTERNAL ENCODER"
- all devices relate to Profinet and switched on.
- The SIMATIC S7-15xxT is switched into the "Run" state.
- WinCC Advanced is installed on the PC/PG.




Note

WinCC Advanced requires the appropriate authorization. Authorization is required for a minimum of 256 power tags.

8.1 Operating instructions for the application example

Execute the steps listed in the following table in sequence to demonstrate the application example:


Table 8-1: Operating instructions to present/demonstrate the example project SIMATIC Flying Saw

| No. | Action | Remark |
|-----|--|--|
| 1 | Start screen after calling the WinCC RT user interface |  |
| 2 | Activation of "Auto Cutting" With "Auto Cutting", the knife feedback signals are automatically generated, and do not have to be set by the user. This simplifies using the application. This function is activated using the "Auto Cutting" button. |  |
| 3 | Switch FlyingSaw to manual Select the "Manual" mode Activate the "Execute" button (edge 0→1) Home the FlyingSaw axis using the "Home" button (The axis is homed if "Homed" is lit!) |  |

8 Operating the application

| | |
|---|--|
| <p>4 Move the FlyingSaw to the start position Select the "Start position" mode Activate the "Execute" button (edge 0→1!)</p> | |
| <p>5 Switch the FlyingSaw into the automatic mode Select the "Automatic" mode Activate the "Execute" button (edge 0→1!)</p> | |
| <p>6 Activating material motion Switch-on the material axis Select velocity value Select acceleration Start motion (stop motion)</p> | |
| <p>7 Change the cut length in operation The change is made by entering a new cut length</p> | |

8 Operating the application

| | | |
|----------|---|--|
| <p>8</p> | <p>Changing the transfer position</p> <p>The change is performed by selecting the "Way back mode"</p> |  |
| <p>9</p> | <p>We hope you are successful in checking out the application</p> | |

8.2 Operating/overview screen form FS operating

8.2.1 FS Operating

Fig. 8-1 FS operating




Table 8-2 Explanation of sub screen forms for FS operating

| No. | Sub Screen form |
|-----|---|
| 1. | <p>Standard operation LFS_FlyingSaw</p> <p>The following are specified and displayed here</p> <ul style="list-style-type: none"> Cut length Operating mode selected Signals to control the saw Gap Double cut Immediate cut Skip next cut Cut with constant velocity (not exact synchronous to material velocity!) |
| 2. | <p>Extended operation LFS_FlyingSaw</p> <p>The following are specified and displayed here</p> <ul style="list-style-type: none"> Restart Interrupt/continue production First print mark |
| 3. | <p>Standard display LFS_FlyingSaw</p> <ul style="list-style-type: none"> Outputs from LFS_FlyingSaw |
| 4. | "Auto Cutting" |

8 Operating the application

| No. | Sub Screen Form | | | | | | | | | | | | | | | | |
|-----|---|--------|-------------------|--------|---------------|--|---------------------|--------|---------------|--|---------------------|------|--------------|--|----------------------------|------|--------------|
| | The "Auto Cutting" function generates the control signals for the saw for test operation (without material and saw!) | | | | | | | | | | | | | | | | |
| 5. | "Leading Value Active", "ErrorID" and "State" The following are displayed here <ul style="list-style-type: none"> • Active leading value • Error messages of LFS_FlyingSaw in ErrorID • The actual operating state of LFS_FlyingSaw in State | | | | | | | | | | | | | | | | |
| 6. | Extended display LFS_FlyingSaw The following are displayed here <ul style="list-style-type: none"> • Whether the FlyingSaw axis is active • Whether the start position is automatically shifted | | | | | | | | | | | | | | | | |
| 7. | Operation and display of running back optimization (RBO) The following are specified and displayed here <ul style="list-style-type: none"> • Whether RBO is activated • Whether optimization is carried out based on the jerk, or the acceleration | | | | | | | | | | | | | | | | |
| 8. | Using the "Way back mode" The "Way back mode" is specified here. Either after cut "Travel to handover position" or "Travel to start position". | | | | | | | | | | | | | | | | |
| 9. | Operation and display of the synchronization mode and cut position determination | | | | | | | | | | | | | | | | |
| 10. | "State" display area | | | | | | | | | | | | | | | | |
| 11. | "Graphic" display area Legend: <table style="margin-left: 20px; border: none;"> <tr> <td style="border-bottom: 1px solid orange; width: 50px;"></td> <td>material velocity</td> <td>[mm/s]</td> <td>Y axis, right</td> </tr> <tr> <td style="border-bottom: 1px solid magenta; width: 50px;"></td> <td>flying saw velocity</td> <td>[mm/s]</td> <td>Y axis, right</td> </tr> <tr> <td style="border-bottom: 1px solid cyan; width: 50px;"></td> <td>flying saw position</td> <td>[mm]</td> <td>Y axis, left</td> </tr> <tr> <td style="border-bottom: 1px solid blue; width: 50px;"></td> <td>relative material position</td> <td>[mm]</td> <td>Y axis, left</td> </tr> </table> | | material velocity | [mm/s] | Y axis, right | | flying saw velocity | [mm/s] | Y axis, right | | flying saw position | [mm] | Y axis, left | | relative material position | [mm] | Y axis, left |
| | material velocity | [mm/s] | Y axis, right | | | | | | | | | | | | | | |
| | flying saw velocity | [mm/s] | Y axis, right | | | | | | | | | | | | | | |
| | flying saw position | [mm] | Y axis, left | | | | | | | | | | | | | | |
| | relative material position | [mm] | Y axis, left | | | | | | | | | | | | | | |
| 12. | Operating/display area of the FlyingSaw axis | | | | | | | | | | | | | | | | |
| 13. | Operating/display area of the leading value | | | | | | | | | | | | | | | | |
| 14. | Display area of the calculated cut accuracy | | | | | | | | | | | | | | | | |
| 15. | Operating and monitoring of the actual visualized instance The actual visualized instance can be switched here. | | | | | | | | | | | | | | | | |

8.2.2 Parameterizing screen form FS-Data1 (UI)

Fig. 8-2 FS-Data1 (UI)




Table 8-3 Explanation of the sub screen forms for FS-Data1 (UI)

| No. | Sub Screen Form |
|-----|---|
| 1. | Input of numerical usersInterface |
| 2. | Input area for text-based user parameters |
| 3. | Operation and display of running back optimization (RBO) |
| 4. | Display of the operating state and state of the automatic run state machine |
| 5. | Control of the print mark detection |
| 6. | Operating and monitoring of the actual visualized instance The actual visualized instance can be switched here. |

8.2.3 Diagnostics screen form FSdata2 (FSI)

Fig. 8-3: FS-Data2 (FSI)




Table 8-4 Explanation of the sub screen forms for FS-Data2 (FSI)

| No. | Sub Screen Form |
|-----|--|
| 1. | Display of the numerical data "Flying Saw Info" |
| 2. | Display of the binary data "Flying Saw Info" |
| 3. | Display of the text-based data "Flying Saw Info" |
| 4. | Display of the operating state and state of the automatic run state machine |
| 5. | Operating and monitoring of the actual visualized instance The actual visualized instance can be switched here. |

8.2.4 Diagnostics screen form FS-Data3 (CPB-MI)

Fig. 8-4 FS-Data3 (CPB-MI)




Table 8-5 Explanation of the sub screen forms for FS-Data3 (CPB-MI)

| No. | Sub Screen Form |
|-----|---|
| 1. | Display of the CutPositionBuffers |
| 2. | Display of the numerical data of the MeasuringInterface |
| 3. | Display of the binary signals of the MeasuringInterface |
| 4. | Display of the cut position determination |
| 5. | Display of the operating state and state of the automatic run state machine |
| 6. | Operating and monitoring of the actual visualized instance The actual visualized instance can be switched here. |

8.2.5 Diagnostic screen form FS messages

Fig. 8-5 System error display

The screenshot displays the SIMATIC HMI interface for FS-Messages. The top bar shows the date 4/9/2020 and time 1:38:32 PM. The main area contains a table of error messages with columns for No., Time, Date, Status, Text, and Acknowledge gr... Below this is a 'Diagnostic overview' section with a table listing plant information.

| No. | Time | Date | Status | Text | Acknowledge gr... |
|-----------|------------|----------|--------|---|-------------------|
| \$ 240001 | 1:31:27... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 1:21:27... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 1:11:27... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 1:01:27... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:51:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:41:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:31:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:21:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:11:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| \$ 240001 | 12:01:2... | 4/9/2020 | I | Too many tags (Powertags) have been configured. | 0 |
| NA 35 | 11:54:0... | 4/9/2020 | (I)O | CPU status message: CPU not in RUN Current CPU operating mode: STOP... | 0 |
| NA 59 | 11:54:0... | 4/9/2020 | I | MC Fatal Alarm 101: PLC_1 LeadingValueAxisMeasuringInput: Configuration error. (Illegal value in P... | 0 |
| NA 59 | 11:54:0... | 4/9/2020 | (I)O | MC Fatal Alarm 101: PLC_1 LeadingValueAxisMeasuringInput: Configuration error. (Illegal value in P... | 0 |

| Status | Name | Ope... | Slot | Type | Order number | Address | Plant design... | Location ide... |
|--------|--------------------------|--------|------|----------------|--------------|---------|-----------------|-----------------|
| ✓ | Plant | | | | | | | |
| ✓ | S71500/ET200MP station_1 | | | S71500/ET20... | | 32* | | |

The bottom navigation bar includes buttons for 'FS-Operating', 'FS-Data1 (UI)', 'FS-Data2 (FSI)', and 'FS-Data3 (CPB-MI)'. The 'FS-Nr:' field shows '1 1'. There are also status icons for a blue flag and a red stop sign.

9 Appendix

9.1 Service and Support

Industry Online Support

Do you have any questions or need assistance?

Siemens Industry Online Support offers round the clock access to our entire service and support know-how and portfolio.

The Industry Online Support is the central address for information about our products, solutions and services.

Product information, manuals, downloads, FAQs, application examples and videos – all information is accessible with just a few mouse clicks:

support.industry.siemens.com

Technical Support

The Technical Support of Siemens Industry provides you fast and competent support regarding all technical queries with numerous tailor-made offers – ranging from basic support to individual support contracts.

Please send queries to Technical Support via Web form:

support.industry.siemens.com/cs/my/src

SITRAIN – Digital Industry Academy

We support you with our globally available training courses for industry with practical experience, innovative learning methods and a concept that's tailored to the customer's specific needs.

For more information on our offered trainings and courses, as well as their locations and dates, refer to our web page:

siemens.com/sitrain

Service offer

Our range of services includes the following:

- Plant data services
- Spare parts services
- Repair services
- On-site and maintenance services
- Retrofitting and modernization services
- Service programs and contracts

You can find detailed information on our range of services in the service catalog web page:

support.industry.siemens.com/cs/sc

Industry Online Support app

You will receive optimum support wherever you are with the "Siemens Industry Online Support" app. The app is available for iOS and Android:

support.industry.siemens.com/cs/ww/en/sc/2067

9.2 Industry Mall



The Siemens Industry Mall is the platform on which the entire Siemens Industry product portfolio is accessible. From the selection of products to the order and the delivery tracking, the Industry Mall enables the complete purchasing processing – directly and independently of time and location:

mall.industry.siemens.com

9.3 Contact persons

Siemens AG
 Digital Industries
 Factory Automation
 Production Machines
 DI FA PMA APC
 Frauenaauracher Str. 80
 91056 Erlangen, Germany

mailto: printing.converting.team.automation@siemens.com

9.4 References

Table 9-1 References

| | Subject |
|-----|---|
| \1\ | Siemens Industry Online Support https://support.industry.siemens.com |
| \2\ | Download page of the article https://support.industry.siemens.com/cs/ww/en/view/109744840 |
| \3\ | Download page of the axis FB library LAxisCtrl https://support.industry.siemens.com/cs/de/de/view/109749348 |

9.5 Documentation History

Table 9-2 History

| Version | Date | Change |
|---------|---------|--|
| V 1.0 | 04/2017 | Creation |
| V 1.1 | 08/2019 | The following increments are added: <ul style="list-style-type: none"> • Structure “axisTOs” (necessary for switching between several axis and external encoders) • Dynamic start position |

| Version | Date | Change |
|---------|---------|--|
| | | <ul style="list-style-type: none">• Skip next cut• Constant velocity at cut |
| V 1.1.1 | 04/2020 | The following increment is added: <ul style="list-style-type: none">• Several instances of flying saw are possible |
| V 1.2.0 | 03/2021 | The following increments are added (see ChangeLog): <ul style="list-style-type: none">• Velocity filters set in the technology object are taken into account• Bug Fixes were made |
| V 1.3.0 | 04/2021 | The added increments can be seen in the ChangeLog |
| V 1.3.1 | 06/2021 | The added increments can be seen in the ChangeLog |
| V 1.4.0 | 10/2022 | <ul style="list-style-type: none">- The added increments can be seen in the ChangeLog- Manual was revised and shortened |