

SERVO INVERTER

POSIDYN®

SDS 4000

Installation and Commissioning Instructions

It is essential to read and comply with these instructions prior to installation and commissioning.

MANAGEMENTSYSTEM



certified by DQS according to
ISO 9001, ISO 14001
Reg-No. 25780



1. Notes on Safety	1	10. Positioning Control	15
2. Technical Specifications	2	10.1 <i>Function Overview</i>	15
3. Physical Installation	3	10.2 <i>Connections</i>	15
3.1 <i>Installation Site</i>	3	10.3 <i>Dest. Positions and Proc. Blocks</i>	16
4. Electrical Installation	3	10.4 <i>Absolute/Relative Positioning</i>	16
4.1 <i>EMC-Compatible Installation</i>	4	10.5 <i>Commissioning</i>	16
4.2 <i>FI Circuit Breaker</i>	4	10.5.1 <i>Limited Position Range</i>	16
4.3 <i>DC Link Coupling</i>	4	10.5.2 <i>Continuous Traversing Range (Rotary Axis)</i>	17
4.4 <i>Electrical Installation</i>	4	10.6 <i>Reference Point Traversing</i>	17
4.5 <i>Motor Connection, Halting Brake, X13</i>	5	10.7 <i>Position Controller</i>	18
4.6 <i>Brake Resistor, X12</i>	5	10.8 <i>Process Block Chaining</i>	18
5. Connection Assignment	6	10.9 <i>Simple Examples</i>	19
5.1 <i>Control Portion, Terminal Strip X1</i>	7	10.10 <i>Emergency Off</i>	20
5.2 <i>X3 Service Connector (RS 232, CAN)</i>	8	10.11 <i>Ext. Rot./Lin. Path Measurement</i>	20
5.3 <i>X40 Resolver</i>	8	10.11.1 <i>Encoder</i>	21
5.4 <i>X20 Encoder In/Out (TTL)</i>	8	10.11.2 <i>Adjustment - Motor/Ext. Meas. Sys.</i>	21
5.5 <i>Encoder Input (External Encoder)</i>	8	10.11.3 <i>Ext. Encoder and Posi Parameters</i>	21
5.6 <i>X41 Sin/Cos, Absolute Value Encoder</i>	9	10.12 <i>Posi Switching Points</i>	21
6. Replacing the Inverter	10	11. Synchronous Running Elec. Gearbox	22
7. Operator Control	10	11.1 <i>Function Overview</i>	22
7.1 <i>Status Indication</i>	10	11.2 <i>Connection of Pulse Source</i>	22
7.2 <i>Controlbox</i>	10	11.3 <i>Master - Slave</i>	23
7.3 <i>Parameter Memory</i>	11	11.4 <i>Commissioning</i>	23
7.4 <i>Operation Indication</i>	10	11.5 <i>Angle Difference</i>	23
7.5 <i>Parameterization</i>	11	11.6 <i>Angle and Speed Sync. Running</i>	24
7.6 <i>Password</i>	11	11.7 <i>Emergency Off</i>	24
8. Commissioning	11	11.8 <i>Reference Point Traversing - Slave</i>	24
8.1 <i>Default Setting</i>	11	12. Technology	24
8.2 <i>Motor, Braking Resistor</i>	12	12.1 <i>PID Controller</i>	24
8.3 <i>Speed Specification</i>	12	12.2 <i>Winders</i>	25
8.3.1 <i>Speed Specification via Controlbox</i>	12	12.2.1 <i>Diameter Sensor on AE1/AE2</i>	25
8.3.2 <i>External Speed Specification</i>	12	11.2.2 <i>Indirect Tension Control at M-Max Limit</i>	25
8.3.3 <i>Speed Spec. via Potentiometer</i>	12	11.2.3 <i>Winding with Compensating Roller</i>	26
8.3.4 <i>Characteristic Curve of Ref. Value</i>	12	11.2.4 <i>Winding with Tension Sensor</i>	26
8.3.5 <i>Speed Spec. via Fixed Ref. Value</i>	12	11.2.5 <i>Compensation of Fault Variables</i>	26
8.3.6 <i>Speed Spec. via Clk Pulse Generator</i>	13	13. Parameter Description	27
8.3.7 <i>Motor Potentiometer</i>	13	14. Option Boards	53
8.3.8 <i>Frequency Reference Value</i>	13	14.1 <i>SEA 4000</i>	53
8.4 <i>Speed Controller</i>	13	15. Result Table	54
8.5 <i>Halt/Quick Stop</i>	13	16. Operating States	55
8.6 <i>Brake Control</i>	13	17. Faults/Events	56
9. Special Functions	13	STÖBER ANTRIEBSTECHNIK Deutschland	58
9.1 <i>Binary Inputs BE1 to BE4 (BE5 to BE15)</i>	13	STÖBER ANTRIEBSTECHNIK International	60
9.2 <i>Torque Limits</i>	13	18. Block Circuit Diagram - Sync. Running	62
9.3 <i>Operating Range</i>	14	19. Block Circuit Diagrams	62
9.4 <i>Parameter Record Selection</i>	14	19.1 <i>Fast Speed Ref. Value Active</i>	62
9.5 <i>Acknowledgment of Faults</i>	14	19.2 <i>Reference Value Processing</i>	63
9.6 <i>Motor Startup</i>	14	20. Parameter Table	64
		21. Accessories	66
		22. Notes	67

1. Notes on Safety



To prevent avoidable problems from occurring during commissioning and/or operation, it is essential to read and comply with this entire instruction manual before starting installation and commissioning.

Based on VDE 0160, SDS-series servo inverters are defined as electronic power equipment (BLE) for the control of power flow in high-voltage systems. They are designed exclusively to power servo machines. Handling, installation, operation and maintenance must be performed in accordance with valid and/or legal regulations, applicable standards and this technical documentation.

The user must ensure strict adherence to these standards.

The safety notes and specifications stated in additional sections (items) must be adhered to by the user.



Caution! High touch voltage! Danger of electric shock! Danger of death!

Disconnect the power plug of the servo inverter and wait at least 5 minutes after the power voltage has been switched off before opening the servo inverter to install or remove option boards. Correct configuration and installation of the inverter drive are prerequisites to correct operation of the servo inverter.

Pay particular attention to the following:

- Permissible protection class: Protective ground; operation only permitted when protective conductor is correctly connected
- Installation work may only be performed in a voltage-free state. When working on the drive, not only must the enable be blocked but also the complete drive must be disconnected from the power network. Adhere to the 5 safety regulations.
- Capacitor discharge time after disconnection from power network > 5 minutes
- Do not penetrate the interior of the device with any kind of object.
- When performing installation or other work in the switching cabinet, protect the device against falling objects (e.g., pieces of wire, flexible leads, metal parts and so on). Pieces of metal may cause a short circuit in the servo inverter.
- Before commissioning, remove all extra coverings to prevent the device from overheating.

The servo inverter must be installed in a switching cabinet which does not exceed the maximum ambient temperature (see technical data). Only copper wiring may be used. For wire cross sections, see table 310-16 of standard NEC at 60° C or 75° C.



STÖBER ANTRIEBSTECHNIK accepts no liability for damages caused by non-adherence to the instructions or applicable regulations.

Either the motor itself must be equipped with temperature monitoring, or external protection against motor overload must be used.

Only suitable for use on power networks which cannot supply more than a symmetric, nominal short-circuit current of 5000 A at 480 Volt.

POSIDYN® SDS 4000**2. Technical Specifications**


Model	Model 1				Model 2a	Model 2b
Type of device	SDS 4011	SDS 4021	SDS 4041	SDS 4071	SDS 4101	SDS 4141
Nominal connected load	1 kVA	2 kVA	4 kVA	7 kVA	10 kVA	14 kVA
Nominal current (effective value, $\pm 3\%$)	1.5 A	3 A	6 A	10 A	14 A	20 A
Max. output current (max. of approx. 5 sec, $\pm 3\%$)	3 A	6 A	12 A	20 A	28 A	40 A
Connected voltage	(L1 - L3) 3 x 230 V - 10% to 480 V + 10%, 50 to 60 Hz					
Power fuses	3 x 6 AT		3 x 10 AT		3 x 20 AT	
Conductor cross section, power connection	1.5 mm ²	1.5 mm ²	1.5 mm ²	1.5 mm ²	2.5 mm ²	4 mm ²
Conductor cross section, motor connection	1.5 mm ²	1.5 mm ²	1.5 mm ²	1.5 mm ²	2.5 mm ²	
Conductor cross section, halting brake	Min. of 0.75 mm ² (consider voltage loss)					
Conductor cross section, ext. 24 V/GND	Max. of 2.5 mm ² (consider voltage loss)					
Clock pulse frequency	8 kHz					
Braking resistance, internal	66 Ω / 80 W Max. of 10.5 kW for 1 sec		33 Ω / 200 W Max. of 21 kW for 1 sec			
Braking resistance, external* (limit data for brake chopper)	$\geq 30 \Omega$ /max. 500 W const. Max. of 21 kW for 1 sec		$\geq 30 \Omega$ / max. 1500 W const. Max. of 21 kW for 1 sec			
Switch-on threshold, brake chopper	840 to 870 V					
Switch-off threshold, brake chopper	800 to 830 V					
RFI suppression	Integrated network filter in accordance with EN 55011, class A					
Permissible length of motor cable	25 m, shielded; 25 to 100 m, shielded with output derating					
Auxiliary voltage, 24 V without brake connection	18 to 36 V, 1 A					
Auxiliary voltage, 24 V with brake connection	24 V - 0% to 24 V + 10%, 3 A					
Fuses, 24 V	Internal: 3.15 AT, external: max. of 16 AF due to conductor cross section 2.5 mm ²					
Max. output current, brake	2 A					
Protection rating/mounting position	IP20/always vertical					
Ambient temperature	0° to 45° C for nominal data Up to 55° C with power reduction of 2.5% /° C					
Humidity during operation	Relative humidity of 85%, no condensation					
Installation altitude	Up to 1000 m without restriction; 1000 to 2500 m with derating of 1.5%/100 m					
Degree of soil	Soiling degree of 2 in acc. w. EN 60204/EN 50178					
Dimensions (H x W x D), without plug (in mm)	278 x 70 x 255				278x100x255	278x115x255
Power loss	30 W	40 W	60 W	90 W	115 W	165 W
Weight (kg)	2.5				3	7.4

* External braking resistors with thermal monitoring are recommended. Mandatory for UL use!

POSIDYN® SDS 4000

- 3. Physical Installation
- 4. Electrical Installation


3 PHYSICAL INSTALLATION



3.1 INSTALLATION SITE

- Operate only in closed switching cabinet.
- Install inverter only in vertical position.
- Avoid installation over heat-producing devices.
- Ensure sufficient air circulation in switching cabinet.
- Keep installation site free of dust, corrosive fumes and all liquids.
- Avoid atmospheric humidity.
- Avoid condensation (e.g., by anti-condensation heaters).
- Use unpainted mounting plates to conform to EMC regulations.

4 ELECTRICAL INSTALLATION



4. Electrical Installation

4.1 EMC-COMPATIBLE INSTALLATION

Basic rules

- Install control and power cables separately (> 20 cm).
- Install power, encoder and motor cables in separate spaces.
- Central grounding point in immediate vicinity of the inverter. All shields and protective conductors of motor and power cables are applied here over a large area.
- Reference value cables must be shielded and, if necessary, twisted in pairs.
- Connect shield of control lines on one side to the reference ground of the reference value source (PLC, controller, etc.).

Motor cable (see accessories, chap. 21)

- Use shielded cables. Apply shield on both sides.
- Use motor derating when cables are longer than 25 m.

4.2 FI CIRCUIT BREAKER


Network phases and directly grounded conductor are connected to the protective conductor with Y capacitors. When voltage is present, a leakage current flows over these capacitors to the protective conductor. The greatest leakage current is created when a malfunction occurs (asymmetric feeding over only one phase) and power-on (sudden change in voltage). The maximum leakage current caused by asymmetric powering is 66 mA (power voltage of 400 V) for SDS inverters.

If FI circuit breakers must be used, the problem of power-on and power-off can be minimized by using selective FI circuit breakers (delayed switch-off) or FI circuit breakers with greater triggering currents (e.g., 300 or 500 mA). Use of several devices on one FI circuit breaker is not recommended.

4.3 DC LINK COUPLING


4.3.1 DIRECT COUPLING OF DEVICES

All coupled devices must be connected to one common power fuse. The fuse may not exceed 20 AT. This limits maximum possible drive power to approx. 10 kW.



4.3.2 COUPLING OF DEVICES WITH DC FUSE

Each device has its own power fuse based on its technical specifications (chap. 2). In addition, each device must be protected on the DC link (U+ and U-) with the same current strength. The fuse must be suitable for a voltage of 500 V DC.




Brake resistance for DC link coupling:

Internal brake resistors may remain active since the braking power is distributed evenly. Important: Set type of resistor **A20** correctly. Set **A38=1** for a pure DC-link-coupling feed-in without power network connection.

4.4 ELECTRICAL INSTALLATION


- Only connect inverter to three-phase, grounded, industrial power network.
- User must provide fuses for power network and 24 V supply (see technical specifications, chap. 2).
- Install power and control cables separately (> 20 cm).

Important: When installing the 24 V brake lines in the motor cable, **shield the brake lines separately** if the inverter addresses the brake directly.



Important: With direct brake control, a voltage of approx. 1.3 V occurs on the inverter (protection against pole reversal and EMC derating). However, since the halting brake requires at least 24 V - 10% = 21.6 V, use an external contact (relay) for long brake lines. The same also applies to power packs which supply less than 24 V.


4. Electrical Installation



Tip:
With **F08=0**, the brake is always released. **F08=1** activates automatic brake control by the inverter. Also consider BE function **F31=32:brakeRel ease**

Caution: Important information on motor connector

With devices delivered up to March 1999, motor connector X13 has a different orientation than the front power connectors X11 and X12.



The motor connector must be rewired when these older devices are replaced with newer ones. The old allocation is a mirror image of the new one and, if left as is, will damage inverter and motor!

Shielding for STÖBER power cables


Use the included clamp to connect the shielding with the HF reference potential (mounting plate and inverter's housing). If this is not possible, the shielding (red flexible lead) can be connected to the PE terminal of the device.

4.5 MOTOR CONNECTION, HALTING BRAKE, X13

Together with any halting brake, the motor is connected to plug connector X13 (on the bottom of the device). The inverter can directly address the halting brake. The external 24 V supply must be designed for this.

- Only use shielded cable to connect motor.
- **Apply shield on both sides.**
- On the inverter side, apply shield with a clamp over a large surface to the bare mounting plate.
- If the motor cable also contains lines to the +24 V **halting brake** and this brake is addressed by the inverter, these lines must be **shielded separately!** Connect the shields on both sides.

Terminal block




Power connector



	Power Connector	STÖBER Cable
U	1	1
V	2	2
W	6	3
⊥	⊥	⊥
+ 24 V	4	5
0 V	5	6

4.6 BRAKE RESISTOR, X12

SDS servo inverters are always equipped with a brake resistor. A jumper between R1 and R2 must be wired to activate the internal brake resistor. For technical details, see page 2. Greater brake performance requires connection of an external brake resistor. Connector X12 is used for the connection (on the bottom of the device).




	Jumper Between	Connection Between
Int. brake resistor	R1 and R2	---
Ext. brake resistor	---	R1 and U+

Lines to the external brake resistor which are longer than 30 cm must be shielded. The brake chopper triggers at a DC link voltage of 840 to 870 V. The internal brake resistors will remain active for all axes when a DC link coupling of several devices is used with the terminals U+ and U-. The brake chopper distributes the braking load evenly over all inverters (which may even have different current strengths).

The current of the internal brake resistor is monitored and protected against overload with a thermal i2t model. With the external brake resistor, we recommend using types with integrated overcurrent relays to prevent thermal damage caused by overload.

5. Connection Assignment



5. Connection Assignment


5.1 CONTROL PORTION, TERMINAL STRIP X1

Terminal	Function	Circuiting
1	AGND: Reference ground for analog signals	Reference potential for terminals X1.4 to X1.9
2	Relay 1/ready for operation Max. of 24 V DC, 42 V AC, 0.5 A	Shows readiness of the servo inverter (i.e., relay closed)
3		Function can be programmed under F10 .
4	Analog input AE1 0 to ±10 V, Ri = 20 kΩ, 14-bit resolution Ta = 1 msec	Function can be programmed under F25 . Default setting: F25=10:ref.value ; 10 V=3000 rpm (↔ D02)
5		
6	Analog input AE2 0 to ±10 V, Ri = 20 kΩ, 12-bit resolution Ta = 4 msec	Function can be programmed under F20 . Default setting: F20=0:inactive
7		
8	Analog output 1, Ta = 4 msec ±10 V, Ri = 2.2 kΩ, 10-bit resolution Calibrated at the plant for a load = 20 kΩ	Function can be programmed under F40 . Default setting: F40=4:n-motor ; 10 V=3000 rpm (↔ C01 n-Max)
9	Analog output 2, Ta = 4 msec ±10 V, Ri = 2.2 kΩ, 10-bit resolution Calibrated at the plant for load = 20 kΩ	Function can be programmed under F45 . Default setting: F45=1:l-motor ; 10 V=2 x I _{Nom} (SDS)
10	AGND: Reference ground for analog signals	Reference potential for terminals X1.4 to X1.9, internally connected with X1.1
11	Binary input BE1 * 8:halt	Inputs which can be programmed as desired. Function is specified with parameters F31 to F34 . Scanning time Ta = 4 msec. When an HTL incremental encoder is connected to BE1 and BE2, the max. input frequency is 80 kHz. With certain functions (e.g., <i>posi.next</i> , <i>posi.start</i> and <i>syncFreeRun</i>), BE1 reacts <u>without delays</u> . * Default setting of the inverter
12	Binary input BE2 * 6:dirOfRotat	
13	Binary input BE3 * 9:quick stop (with ramp)	
14	Binary input BE4 * 0:inactive	
15	Enable, Ta = 4 msec	
16	Binary output BA1 Open collector, 36 V (max.), 10 mA (max.), Ta = 4 msec Pullup resistance ≥ 3.3 kΩ	Outputs which can be programmed as desired. Function is specified with parameters F80 (BA1) and F00 (BA2).
17	Binary output BA2 Open collector, 36 V (max.), 10 mA (max.), Ta = 4 msec Pullup resistance ≥ 3.3 kΩ	
18	DGND: Digital ground	Reference potential for terminals X1.11 to X1.17

5. Connection Assignment


5.2 X3 SERVICE PLUG CONNECTOR (RS 232, CAN)

Service plug connector X3 can be used to connect a PC or the external operator unit (i.e., *Controlbox*). When a PC is connected, the same G3 cable can be used as for the POSIDRIVE® FDS 4000 frequency inverter.



Pin	1	2	3	4	5	6	7	8	9
Signal	+8V	RxD	TxD	TxD	PGND ¹	CANL	Internally connected		CANH



1) PGND ground (I/O ground) is galvanically isolated from digital DGND on plug connector X1.



5.3 X40 RESOLVER

The default setting specifies a 2-pin resolver as the motor encoder. For connection, adhere to the following points.

- Use fabricated STÖBER cables for optimum interference immunity.
- Use only resolver cables with cores which are twisted in pairs and shielded.
- Cross section: 0.14 mm² [LIY (C) Y3 (2 x 0.14) + (2 x 0.25)]
- Use 2 cores with 0.25 mm² for positor line evaluation.
- Apply outer shield on both sides. Apply inner shield only on the inverter side.
- Use exclusively sub D **plug connectors with shielded housing** (e.g., Siemens V42254-A6000-G109).
- Apply shield over a large surface on the housing of the plug connector.




Pin	1	2	3	4	5	6	7	8	9
Signal	-	PTC	S2 Sin 0V	S1 Cos0V	R1 Erreg. 0V	PTC	S4 Sin +	S3 Cos +	R2 Erreg.+
Motor ¹⁾	-	5	4	2	8	6	3	1	7
Cable ²⁾	-	Red	Brown	Green	Pink	Blue	White	Yellow	Gray

1) Pin number of the 12-pin resolver connector for the STÖBER ES motor
 2) Color when the blue STÖBER resolver cable is used

5.4 X20 ENCODER IN/OUT (TTL)

Simulation of an incremental encoder on plug connector X20 is activated with **H20=1:encoder sim**. The number of pulses can be changed with the parameter **H21**. Adhere to the following points when using encoder simulation.

- Use only suitable cables with cores which are twisted in pairs and shielded.
- On the receiver side, the lines require low-ohmic termination and differential evaluation. Recommended termination impedance: 150 Ω.
- Connect ground on pin 1 with the ground of the higher-level controller.
- Apply shield on both sides over a large surface to the housing of the plug connector.



Other possible configurations:

H20=2:encoder in; input for ext. incremental encoder (TTL)

H20=3:stepMot in; frequency + sign

(chap. 11.2)

H20=4:SSI sim; output of position in SSI format

H20=5:SSI master; connection of external SSI encoder

Pin	1	2	3	4	5	6	7
H20=0	PGND	-	-	-	-	-	-
H20=1	PGND	Zero+	Zero-	A-	A+	B+	B-
H20=2	PGND	-	-	A-	A+	B+	B-
H20=3	PGND	-	-	Freq-	Freq+	Sign+	Sign-
H20=4	PGND	-	-	CLK+	CLK-	Data+	Data-
H20=5	PGND	-	-	CLK-	CLK+	Data+	Data-

1) PGND ground (I/O ground) is galvanically isolated from digital DGND on plug connector X1.

5.5 ENCODER INPUT (EXTERNAL ENCODER)

The SDS 4000 can receive encoder signals or frequency/sign signals (stepper motor simulation) in four ways.

- HTL signals on BE1 and BE2, fmax = 80 kHz
- TTL signals (differential, RS 422) on X20, fmax = 160 kHz
- 1 V_{SS} and TTL signals on X41, fmax = 160 kHz.
- SSI signals from an external SSI encoder on X20

When an encoder is connected to BE1/BE2, **F31=14** and **F32=15** must be programmed.

Connector X20 is programmed with **H20=2:encoder in** to evaluate incremental encoders. External SSI encoders can also be connected to X20 (**H20=5:SSI master**).


Although, in contrast to X20, X41 does not offer galvanic isolation, it does provide a regulated voltage supply (5 V with sense lines) for the external encoder. For connection assignment, see the beginning of chap. 5. Connector X41 is programmed with **H40=2:encoder in** to evaluate incremental encoders.

5. Connection Assignment

Adhere to the following points.


- Only track A and track B are evaluated but not the zero track.
- BE1/BE2, X20 and X41 may not be parameterized simultaneously as the encoder input (i.e., only *one* pulse counter exists!).
- When plug connector X20 is used as the encoder input and lines exceed 1 m, a terminating impedance of 150 Ohm must be provided externally between signals A+ and A- and B+ and B-. See figure.
- Since X41 does not offer galvanic isolation, only measuring systems which are closed and powered by X41 may be connected there.
- Use double-shielded cable with cores twisted in pairs.

X20 – Encoder input (incremental encoder)



* Terminating resistor for cables longer than 1 m


BE1/BE2 encoder input



The external encoder is usually used as the signal source for synchronous operation (**G27** reference value) or for position control (**I02** posi.encoder, chap. 10.11). When stepper motor simulation is used, angle synchronous operation (**G20=2**, chap. 11) must be activated in operating mode **C60=1**.

5.6 X41 SIN/COS, ABSOLUTE VALUE ENCODER

Connector X41 is primarily used to connect multi-turn and single-turn absolute value encoders with EnDat® or HIPERFACE® interface (sin/cos encoder). An extra sin/cos track gives an excellent speed resolution for maximum running smoothness and dynamics.



Pin	1	2	3	4	5	6	7	8
Signal	B- +Sin	0V	A- +Cos	Up	Data+	-	PTC	Clock+
Motor ¹⁾	13	10	16	7	14	-	6	8
Cable ²⁾	or- ange	br/bl	yel	br/rd	gray	-	br/yel	wt/bk

Pin	9	10	11	12	13	14	15
Signal	B+ RefSin	0V Sense	A+ RefCos	Up Sense	Data-	PTC	Clock-
Motor ¹⁾	12	4	15	1	17	5	9
Cable ²⁾	red	grn/bk	grn	grn/rd	bl	br/gra	wt/yel

Italics: HIPERFACE® encoder

- The sin/cos encoder must be built onto the motor since it is also used for commutation.
- Use only original STÖBER cables for ES motors!
- Enable connector X41 with **H40=1:SinCos in**.
- Activate motor control with **B26=3:X41**.
- The fault "37:n-feedback" may occur during parameterization. This fault can only be acknowledged by turning the power and 24 V off (save parameters before with **A00=1!**).
- Resolvers and sin/cos encoders cannot be used at the same time.
- Simultaneous use of sin/cos encoders with external incremental encoders is not possible.
- Simultaneous use of sin/cos encoders with frequency specified externally (synchronous operation, stepper motor simulation) is not possible.
- Sin/cos and SSI encoders or SSI simulation on X20 can be used at the same time.
- Use of SSI encoder as master for synchronous operation with sin/cos encoder on the motor is under preparation.
- SSI simulation on X20 is available with sin/cos encoders.

A continuous zero-point setting is possible with all available reference traversing modes (e.g., mode **I30=3:def.home**). The inverter is equipped with an electronic gearbox (safe against power failure) which permits absolute position acquisition over 4096 x 64 = 262,144 encoder revolutions for linear axes, or an unlimited traversing area for continuous axes with any gearbox. When this feature is used, the zero position only has to be re-referenced when the inverter is changed.

H20=4:SSI sim. simulates the signals of an SSI encoder on X20. This is particularly useful when the motor is controlled with an absolute value encoder with sin/cos track. The absolute angle and the multi-turn information can then be obtained from there. **H60** can be used to switch the code between "0:gray" and "1:binary." The information is output in the following format: 12 bits multi-turn, 12 bits within one motor revolution, the 25th bit is always 0.

6. Replacing the inverter

7. Operator Control


6 REPLACING THE INVERTER

Changing from version 4.4 to 4.5 of the software creates no serious incompatibilities.

7 OPERATOR CONTROL


There are two ways to control and program the SDS servo inverter.

- External Controlbox operator unit
- FDS PC software



7.1 STATUS INDICATION

The SDS servo inverter itself is only equipped with a three-position status display, showing the operational status (e.g., "rdy" for ready) or the flashing number of a fault which has occurred (e.g., "E31" for fault 31:short/ground). Controlbox offers a plain-text display with additional diagnostic capabilities (see chap. 16 + 17).



Operational states	
dir	Illegal direction of rotation. Specified direction of rotation contradicts the permissible direction of rotation in C02 .
EnA	Turned on. Only for control via fieldbus (DRIVECOM profile)
HLt	Halt signal active (e.g., during manual traversing)
inH.	Switch-on disable - Inverter is powered with +24 V but the network power is missing.
inH	Switch-on disable - Enable was active during power-on and <i>Autostart</i> was deactivated by A34=0 . Inverter expects a change from H to L level on enable input X1.15.
i2t	i2t message. Current limitation due to overload.
PoS	Positioning mode. Drive is stationary.
rEF	Reference point traversing
rdy	Ready for operation (not enabled)
run	Drive is enabled.
tSt	Self test and calibration after +24 V becomes available on X2. Standard devices show the software version after the 24 V power is turned on. Customized devices with modifications indicate tSt . For complete version designation, see parameter E50 .
OFF	FDS Tool has removed the enable so parameterization can be performed. Enable again with FDS Tool or turn 24 V OFF-ON to resume operation.
StP	Limit switch is active.

7.2 CONTROLBOX

As an external operator unit, Controlbox offers an easy-to-use menu system in plain text. It contains memory space for the parameters of up to 7 SDS servo inverters, See chap. 7.5. Its use is fully compatible with STÖBER FDS 4000 frequency inverters. Controlbox is available in two models: Controlbox in the hand-held housing and Controlbox in the DIN built-in housing (96 x 96 mm).

In addition, the Simubox.exe program is available to simulate Controlbox on a PC.

These three keys are available for commissioning.

Switches to local operator control and back. The drive stops (internal enable = off). An **I** appears on the bottom right of the display. **A55** (manual key function) must be active.

Enable = turn on with local operator control. The drive is in the state 5:halt and can be controlled with the arrow keys and .

Enable = off with local operator control
If not already active, local operator control is activated (i.e., the drive stops).

7.3 PARAMETER MEMORY

Controlbox offers memory space for the parameters of up to 7 SDS servo inverters. The inverter data are written in Controlbox as shown below.

- Select the memory location number (1 to 7) in **A03** (write Parabox). The data record name is indicated.
- Press the key.

The data are read from Controlbox to the inverter in a similar manner.


- The memory location number in **A01** (read Parabox & store)
- Press the key.

The data are not automatically stored with **A40** (read Parabox).

Direct exchange of parameters between Controlbox and a PC is possible.

7.4 OPERATION INDICATION

In its default setting, the visible *operation indication* on the display of a Controlbox is set up as shown below.




All possible operational states are listed in chap. 16. When is on, the inverter is using parameter record no. 2. No special indication is provided when parameter record no. 1 is active (default setting). appears when the brake chopper is activated.

C51 can be used to convert the speed to gear slow down, for instance. The measured actual speed is indicated.

The first line of the display can also be customized. A variable selected via **C50** (e.g., power) is divided by **C51** and provided with the unit in **C53** (e.g., "items/min"). The unit can only be specified via FDS Tool. The number of positions after the decimal point is provided by **C52**.


8. Commissioning

In position mode (C60=2), the first line shows the position. The second line shows the status.



7.5 PARAMETERIZATION


- Return to prev. menu level
- Reject changes
- Acknowledgement of malfunctions (A31=1)
- Select various menu levels
- Accept changes



- Group selection
- Parameter selection
- Edit parameters


To program, press the [#] key (Enter). The menu consists of several **groups** which are identified with the letters **A, B, C** and so on. Select the groups with the arrow keys (i.e., [Left] and [Right]). Press the [#] key again to access the parameters of the selected group.

The parameters are designated with the group letters and a number (e.g., **A10** or **D02**).



Parameters are selected with the [Up] and [Down] keys. To change a parameter, press the [#] key again. The flashing value can now be changed with [Up] and [Down]. The changes take effect immediately. To retain the changed value, press the [#] key. To reject the change, press the [Esc] key. To return from parameter selection to the group letters, press [Esc]. To return to the status display, press [Esc] again.

Parameter changes must be saved with A00=1 (save parameters) before the device is turned off.



After power-on, the inverter only shows the most important parameters which are required for commissioning. The *extended menu level* is activated with **A10=1** for the solution of complex drive tasks.

A10=2:service; Access to rarely used service parameters. Both the normal menu and the expanded menu do not show parameters which are not related to the current task.

Example: When a predefined STÖBER motor (e.g., ES 44) is selected in parameter **B00** (motor type), parameters **B10** to **B17** (poles to M0) are not shown.

Approximately 50 sec after the last key was pressed, the device returns automatically to the status display. This return can be prevented with **A15=0** (auto return inactive).

Fieldbus: Most of the parameters pertaining to the fieldbus can only be set on the PC with FDS Tool.

7.6 PASSWORD

The parameters can be protected against unauthorized change. To do this, enter a password (an up to 4-digit number other than zero) in parameter **A14**, and save it with **A00=1**. Password protection is inactive if **A14=0**. Parameter **A14** can only be accessed in the extended menu with **A10=1**.

On a protected device, the parameters can only be changed after the correct password has been entered in **A13**.

8 COMMISSIONING

8.1 DEFAULT SETTING

To obtain the default setting, set parameter **A04=1**. The default settings are listed below.

- Speed operating mode
- Speed reference value via AE1 (fast reference value **D99=1**)
- 10 V = 3000 rpm
- Encoder output X20: 1024 imp./U.
- Ramps: Not active
- Binary input 1: Halt (ramp inactive)
- Binary input 2: Direction of rotation

8. Commissioning

- Binary input 3: Quick stop
- Analog output 1: n-motor
- Analog output 2: l-motor
- Holding brake is not addressed.

☞ The expanded menu is activated with **A10**=1.

8.2 MOTOR, BRAKING RESISTOR

The motor must be parameterized before the first run. With STÖBER ES motors, this is particularly easy thanks to the integrated motor data base.

- In **B00**, select the motor type (e.g., 64:ES44).
- In **B02**, enter the "EMK" constant (standard = 110 V).
- In **B26**, enter the motor encoder (standard = resolver).
- When a holding brake is to be addressed, set **F08**=1, and enter the application and release time in **F06** and **F07**.
- If an external fan exists, set **B03**=1.
- With external braking resistor, set the type in **A20**.
- Torque limits **C03** and **C04** must be adjusted to the loadability of the mechanical parts (i.e., gear box). **C03** and **C04** are percentages relative to standstill torque M0 of the motor. Limit **C04** is used for quick stop, for example. Usually

$$C03 = C04 \leq M_{2B_gearbox} / M_{0_motor} / i \quad (*)$$

must be set (M_{2B} = max. acceleration torque of the gear box, i = transmission). Starting with the 1999 edition, the SMS catalog lists in column S_{C03} the value (*) to be entered as a suggestion. For more information on torque limits, see chapter 9.2.

This can be monitored with a phase test using **B40**=1 (procedure: enable off; **B40**=1; enable on; enable off again when finished). **Caution:** The drive must be decoupled from the load since movement takes place. For details, see **B40** in the parameter list.

8.3 SPEED SPECIFICATION

There are two methods of specifying speed.

- Fast reference value **D99**=1:active. High-speed scan (i.e. 1 msec) of analog input AE1 with minimal functionality (e.g., for a host position controller).
- Fast reference value **D99**=0:inactive. Convenient functionality including fixed reference values, reference value correction via a second analog input, and much more. Scan time is 4 msec.

8.3.1 SPEED SPECIFICATION VIA CONTROLBOX

A trial run can also be performed with Controlbox without external circuiting. To do this, proceed as shown below.


1. Press the ☞ key (on-site operation).
2. Grant enable with "I."
3. Stepping mode (speed **A51**) can be used with the arrow keys.

When a constant speed reference value is required:

4. Enter starting reference value in **A51** (usually 0 rpm).
5. Set commissioning mode to **A50**=1:active.
6. Activate enable X1.15.
7. Specify speed reference value in **A51**. (Value must flash.)
8. Deactivate enable again. Do not forget to set **A50** to "0:inactive" again for normal speed reference value.

8.3.2 EXTERNAL SPEED SPECIFICATION


- Connect speed reference value to analog input AE1.
- Enter speed at 10 V in parameter **D02**.
- When higher-level position control is being used, **D02** must exceed the maximum speed actually required by at least 10% (i.e., control reserve).
- Any offset for the analog input can be compensated for with **D06**.
- If required, program ramps with **D00** and **D01**.



8.3.3 SPEED SPECIFICATION VIA POTENTIOMETER


Although the SDS servo inverter does not have a ± 10 V reference voltage, the analog outputs can be programmed to +10 V or -10 V. Caution: $R_i = 2.2$ k Ω .

- **F40**=7:+100% for +10 V on analog output 1
- **F45**=8:-100% for -10 V on analog output 2
- Set **F47** (analog output 2 factor) = 100%



8.3.4 CHARACTERISTIC CURVE OF REF. VALUE

With fast reference value (**D99**=1) active, the reference value must be available on AE1. With **D99**=0, the (main) reference value can be available on either AE1 or AE2, but the AE function (i.e., either **F25** or **F20**) must be 10:reference value (default setting for AE1). The speed is calibrated with the parameters **D06** (RV offset) and **D02** (speed at maximum reference value). Parameter **D03** (maximum reference value) is helpful, for example, when the higher-level controller can output a maximum of 5 V (i.e., **D03**=50% would then have to be entered).



8.3.5 SPEED SPECIFICATION VIA FIXED REF. VALUE

With **D99**=0 (fast reference value inactive), 8 fixed ref. values (FSW) are available with the corresponding ramps in group **D**. Binary coding via signals RV-select 0 to RV-select 2 (param. **F31** to **F34**) is used for the selection. The combination "000" corresponds to the conventional analog reference value.

9. special functions

8.3.6 SPEED SPECIFICATION VIA CLOCK PULSE GENERATOR

A clock pulse generator is available to optimize the speed controller.

- Enter desired speed in **A51** (e.g., 50 rpm).
- Activate clock pulse generator with **D93=1**.
- Enter clock pulse cycle in **D94** (e.g., 0.5 sec).
- Activate enable.

The drive switches the speed between **+A51** and **-A51** with cycle **D94**.

8.3.7 MOTOR POTENTIOMETER

The "motorpoti function" can be used to steplessly increase or decrease the motor speed via two binary inputs.

- Two binary inputs are programmed to "4: motorpoti up" or "5: motorpoti dwn" via **F31** to **F34**.
- The "motorpoti function" is activated with **D90=1**.
- When the key is pressed, the speed is changed in accordance with ramps in **D00** and **D01**. When the "motorpoti function" is active (**D90=1**), most of the parameters of group **D** (reference values) are not indicated.
- **D90=2** causes the motor potentiometer to be added to the normal reference value.
- The reference value generated by the motor potentiometer is set to 0 if both binary inputs are high.
- With **D91=1**, the ref. value is saved in non-volatile memory.
- With **D91=0**, a low level on the enable deletes the motor potentiometer reference value.

☞ The motor potentiometer function is not available when **D99=1** (fast reference value).

8.3.8 FREQUENCY REFERENCE VALUE

There are two ways to accept the frequency reference value.


- Incremental encoder, tracks A and B
- Stepper motor signal, frequency + sign

For connection, see chapters 4 and 5. The software must be programmed to "el. gear," as described in chapter 11.

8.4 SPEED CONTROLLER

The speed controller is an ideal PI controller with reference value smoothing. With STÖBER ES motors, the optimum function of the speed controller is ensured by the default setting. The necessity of controller adjustment (parameters **C31**, **C32** and **C33**) is usually restricted to:

- Great external moments of inertia (**C31** ↑, **C32** ↓, **C33** ↑)
- Mechanical parts with oscillation capability (**C31** ↓, **C33** ↑)



8.5 HALT/QUICK STOP

In the default setting, binary input BE1 is programmed to **F31=8:halt**. In the default setting, the halt is performed without ramp since **D01=0** sec is preset. A separate deceleration ramp can be implemented with the function "9: quick stop" (**D81** Decel-S). In the default setting, BE3 is programmed to **F33=9:quick stop**.

With operational mode "position," the ramp function is always active. The process block Decel ramp takes effect with halt. Max. acceleration **I11** takes effect with quick stop.

8.6 BRAKE CONTROL

A +24 halting brake (terminals B+ and B- on motor plug connector X13) is activated with **F08=1**.

The brake is applied under the following conditions.

- Removal of the enable. Watch **F38=1**.
- Halt. One BE must be programmed to HALT (e.g., **F31=8**).
- Quick stop. One BE must be programmed to quick halt (e.g., **F31=9**).
- Fault. Watch **F38=2**.
- For specific process block positions, see group **L**.

The brake can be released manually with:

- **F08=0**
- With the BE function "32: brake.Release"

The SDS 4000 software provides complete brake control for lifting systems. Release time **F06** and application time **F07** of the brake must be specified for this.

When one of the above events occurs, the drive remains under the controller for the time **F07** after which the motor goes dead. Startup is delayed by the time **F06**.


9 SPECIAL FUNCTIONS

9.1 BINARY INPUTS BE1 TO BE4 (BE5 TO BE15)

With the default setting, the binary inputs which can be programmed as desired have the following meaning.

- BE1 = 8: Halt
- BE2 = 6: Direction of rotation (left/right)
- BE3 = 9: Quick stop
- BE4 = 0: Inactive

Option board *SEA-4000* offers 10 additional binary inputs. The function of the binary inputs is specified via the parameters **F31** to **F34**, and **F60** to **F69** in the extended menu (**A10=1**).



When several inputs are connected to one function, the signals are either AND or OR-linked (**F30** BE-logic). Functions without a connection to a BE signal are provided internally with an L-level signal.

9.2 TORQUE LIMITS

There are several methods of limiting motor torque.

- In the default setting, **C03** (M-Max 1) is the current torque limit in % of motor standstill torque **M0**.

9. special functions

- A binary input (assign BE funct. "10:torque select" via one of the param. **F31** to **F34**) can be used to switch between the two torque limits **C03** (M-Max 1) and **C04** (M-Max 2).
- Analog input AE2 can also be used to limit torque. Set parameter **F20**=2.10 V corresponds to 100% motor standstill torque M0. Other scaling is available via **F22** (AE2 gain).
- With quick stop, **C04** always takes effect.

The actually effective torque limit is calculated from the minimum of the various limit values. It can be scanned in parameter **E62**. Maximum available torque is always limited by the maximum inverter current.

9.3 OPERATING RANGE

Freely programmable comparators can be used to simultaneously monitor 3 measured values (i.e., "operating range"). The first 2 values (speed and torque) are fixed. The third value can be selected as desired with **C47**. The limit values are specified with the following parameters.

- **C41, C42**: n-Min, n-Max
- **C43, C44**: M-Min, M-Max
- **C45, C46**: Measured value "X" (specified in **C47**)

C48=1 monitors the absolute value of measured value "X" (**C47**). **C48**=0 also includes the sign. Parameter **C49** specifies whether monitoring is also to be continued during acceleration phases and enable-off. When at least one of the limits is exceeded, this can be signaled on a binary output with the "6:operation range" function (e.g., **F00**=6). Another use is the control of process-block chaining (cf. **J17**=4).

If only one or two of these range monitoring options are used, the limits of the unused ranges must be set to their limit values (e.g., **C43**=0% and **C44**=400% when torque monitoring is not required).

9.4 PARAMETER RECORD SELECTION

The SDS inverter supports two separate parameter records. Specification of the active parameter record is performed in one of the following ways.


- Externally via a binary input (**A41**=0)
- Internally via a keyboard (**A41**=1 or 2)

The active parameter record is indicated in **E84**. To specify via a binary input, one of the parameters **F31** to **F35** must be set to "11:paraSet-select" in both parameter records. Selection never takes place unless the power section is deactivated.

The parameters of both parameter records can be indicated and programmed regardless of which parameter record is currently active. **A11** (paraSet Edit) is used to specify the parameter record (1 or 2) to be edited. When parameters of the 2nd record are involved (**A11**=2), a **E** is indicated to the right of the parameter number.

Certain parameters (e.g., operation input, **A30**) are only available once, and a **E** is then not indicated next to the parameter number. This applies to all parameters of group **A**, the display parameters of group **E** (e.g., torque, utilization and similar), and positioning (groups **I, J, L** and **N**).

Example of time behavior with quick stop for enable-off (**F38**=1, for enable see also **F31**=11):



Parameter records can be copied via **A42** and **A43** (copy paraSet). **A42**: copy paraSet 1 > 2 to "1:active" overwrites parameter record 2 with the values of parameter record 1.

Usually, the first parameter record should be set up first. The parameters are then copied to parameter record 2 with **A42**=1 (active). **A11**=2 is then used to switch to parameter record 2 and edit the necessary values there. After completion, all parameters are saved with **A00**=1.

Remember: When the mode (**C60**) is switched from position to speed, the actual position during **C60**=1 is only partially included. This means the reference position is lost when you switch back (**I86**→0).

With electronic gear boxes, the internal variables like the current angle of deviation are retained when a parameter record is switched (prerequisite: **C60** remains the same). However, the parameters of group **G..** are switched.

9.5 ACKNOWLEDGMENT OF FAULTS

The table of possible faults is located on page 48. Faults are acknowledged in the following ways.

- **Enable:** Change from L to H level on the enable input, and then back to L. Always available.
 - **Binary input (F31 to F34=13)**
 - **[Esc]** key (only when **A31**=1) and only in the display
 - **Auto reset** (only when **A32**=1)
- Caution!** Drive starts up immediately.

Parameters **E40** and **E41** can be used to scan the last 10 faults. Value 1 represents the last fault. FDS Tool can be used to define the inverter reaction (e.g., fault, warning, message or nothing) to certain events (e.g., overload, excessive temperature, and operating range) as desired.

The fault "37:n-feedback" can only be acknowledged by turning the 24 V supply off and on.

9.6 MOTOR STARTUP

- **A34**=0 (auto-start inactive) in the default setting prevents the motor from starting up by itself after the power is turned on. Cf. operation status "12:inhibited" on page 45. Before activating auto start (**A34**=1), check to determine whether safety requirements permit an automation restart.

10. Positioning control

10 POSITIONING CONTROL

The basic model of the SDS 4000 servo inverter offers integrated positioning control.

Since the capabilities of standard devices are limited by the number of inputs available, use of option board *SEA-4000* or digital communication (e.g., RS 232, CAN bus and PROFIBUS-DP) is recommended for solving typical positioning tasks.

10.1 FUNCTION OVERVIEW

- 32 positions can be programmed as 32 process blocks.
- Continuous position control with following error monitoring
- Parameterization in units (e.g., degrees, mm)
- Resumption of interrupted process blocks possible
- Change in destination possible during traversing
- Reference point travel with several modes
- Sequence programming possible via process block chaining (e.g., "Go to pos. 1, wait 2 sec, go on to pos. 2, wait for signal and return")
- Tip mode (inching)
- Teach-in function
- Speed override via analog input possible
- Any gear ratios are calculated with fractions without rounding errors. No drifting with continuous axes.
- Continuous referencing for continuous axes
- "Electrical cam" function switches digital output within programmed position range.
- Hardware and software limit switch
- Rotary attachment function
- Path specification via analog input possible
- Brake control for lifting systems
- Positioning with absolute value encoders (also continuous mode)


10.2 CONNECTIONS

The standard device without option board is used for simple applications.

Option board SEA 4000 is used for more demanding tasks requiring more binary inputs. The *SEA 4000* expansion board offers 10 additional binary inputs and 5 binary outputs.

An analog input can be used to adjust positioning speed steplessly. Called "speed override," this function is not only useful during commissioning but also for tipping mode, changes in the number of pulses of a machine, and so on.

Below is a typical configuration with option.



The following functions for binary inputs (parameters **F31** to **F34** and **F60** to **F69**) are important:

- **RV-select0 to 4:** Binary coded position selection. Process block 1 is selected with "00000," and process block 32 is selected with "11111."
- **8:halt:** Rising edge interrupts running motion with the current process block ramp. Since tip mode (i.e., inching) via binary inputs is not possible unless halt is active, halt switches between *tip* and *automatic* operation.
- **9:quick stop:** Rising edge interrupts positioning with maximum acceleration **I11**.
- **16:posi.step:** When a chain of process blocks is being used, *posi.step* starts the consecutive process blocks. A movement which is in progress is not interrupted.
- **19:posi.start:** Starts the just selected process block. A movement which is in progress is always interrupted.
- **20:posi.next:** Only for chained process blocks. If programmed appropriately (cf. **J17=3**), immediately concludes the running process block, and starts the next one. A remaining path which is to be traveled after *posi.next* occurs can be defined. See chapter 10.8.
- **17:tip+, 18:tip-:** Tip mode (i.e., inching)
- **21:stop+, 22:stop-:** Limit switch
- **23:reference input:** Reference switch connection
- **24:start reference:** Starts reference point traversing
- **25:teach-in:** Actual position is assumed in the just selected process block.

☞ The binary inputs can be inverted via **F51** to **F54** and **F70** to **F73**. Removal of the **enable** always causes a quick stop with maximum acceleration **I11**.

Analog inputs AE2 and AE1 (par. F20 and F25)

- **1:additional RV:** Relative traversing paths are multiplied by (100% + level). Example: 0 V → no additional reference value (i.e., 100% of the traversing path).
- **4:RV-factor:** Relative traversing paths are multiplied by the level. Example: 0 V → no movement (i.e., 0% of the traversing path).
- **5:override:** The programmed positioning speed can be changed online via potentiometer ("speed override" function for CNC controllers), for example.
- **6:posi. offset:** An offset can be added to the current position online via AE2. Cf. parameter **I70**.


Binary outputs (par. F00, F80, F81, ...)

- **3:Ref Val reached:** Location in position window **I22**. Signal appears when drive "*in position*."
- **8:electrical cam:** Signal appears when the actual position is located between parameters **I60** and **I61**. Signal is used as message to other modules, for example.
- **9:Following error:** Signal appears when the maximum following error in **I21** is exceeded.
- **10:Position active:** Drive is in position control. No process block and no process block chain being processed.
- **13:referenced:** Drive is referenced.
- **19:s-memory1 to 21:s-memory3:** Output the memory locations set by the *posi* switching points during process-block movements (see chap. 10.12).
- **23:RV-ackn.0 to 25:RV-ackn.4:** Binary coded response message from the active **I82** process block. Cf. diagram in chap. 10.3.

10. Positioning control

10.3 DESTINATION POSITIONS AND PROCESS BLOCKS

Each position to be approached to is described by several parameters. Together these parameters make up a process block. Since 32 process blocks are available, 32 separate positions or paths can be traversed. Currently, only the first 8 process blocks can be accessed via Controlbox. Process block no. 1 is described by parameters **J10** to **J18**, while the second process block is described by parameters **J20** to **J28**, and so on.



Process blocks 9 to 32 can only be programmed via FDS Tool or via fieldbus.

A process block can be selected as shown below.


- Binary coded via binary inputs *RV-select0* to *RV-select4*. The binary combination "00000" selects process block no. 1, while "11111" selects process block no. 32. Selection via binary inputs is not possible unless **J02**=0.
- Parameter **J02** if not equal zero here.

The **response message** of the current process block appears:

- In parameter **I82** ("active process block")
 - In the 2nd line of the operational indication
- It is binary-coded from binary outputs "23:RV-ackn.0" to "27:RV-ackn.4." The selected process block is shown inverted until the movement starts.

When a process block starts, the active block is not shown inverted (binary-coded like *RV-select* signals) as long as *posi.start*, *posi.step* or *posi.next* is queued.

When a process block cannot be started (e.g., see "51:refused"), the selected block continues to be shown inverted. This happens even when a movement is terminated.



- ☞ When the position is specified directly via **fieldbus**, process block 1 (**J10**) receives special treatment. The inverter does not acknowledge the write routine until all internal conversions have been completed and the inverter is ready to start. The parameter **E124** ("start.pos 1") is also available from the fieldbus. **J10** is written here and, after conversion, is immediately started automatically. The output signal "32:param.active" signals the completion of a parameter conversion.

10.4 ABSOLUTE/RELATIVE POSITIONING

One of 4 possible traversing methods (parameters **J11**, **J21**, **J31** and so on) can be assigned to each process block.

- Relative
- Absolute
- Continuous, positive
- Continuous, negative

A **relative** path always refers to the current location (chain dimensions).

An **absolute** position refers to a fixed reference point (i.e., machine zero point) which is determined with *reference traversing*. See chapter 10.6. For this reason, an absolute position always requires reference traversing. Any start commands given without reference traversing are answered by the inverter with "51:refused".

When a process block is defined as **continuous** and a start command is given, the axis moves in the specified direction until a signal arrives from the outside (e.g., *posi.next* or *posi.start*). The speed can be adjusted via analog input AE2. (Set the AE2 function **F20**=5:Override for this.)


Successful conclusion of a movement is signaled via the output signal "reference value-reached" (**F00**=3 and **F80**=3). This signal appears when the actual position lands in the **position window** (destination \pm **I22**) for the first time. The signal is not withdrawn until the next traversing command is given.

10.5 COMMISSIONING

Before positioning control is activated, speed control must be commissioned and, if necessary, optimized with FDS Scope. Positioning control is activated with


C60=2:position

The **status indicator** changes and displays the actual position in the first line.



Important: If you want to change the location of the decimal point in the position display via **I06** (**I06**=decimal point shift), do this at the beginning of commissioning since the significance of all positions is changed.

10.5.1 LIMITED POSITION RANGE




Limited traversing range means that the permissible area of movement is restricted by end stops or similar. Safety requires that limit switches be provided. If the inverter is not equipped with a sufficient number of free inputs (i.e., operation without an option board), the limit switches must be evaluated by a higher level controller. The primary parameters are listed below:

- **I00**=0 Limited traversing range

10. Positioning control

- **I05:** Unit of measurement (e.g., mm, degrees (°), inch)
- **I06:** Number of decimal places
- **I07:** Distance per motor revolution (e.g., mm/U)
- **I10:** Maximum speed (e.g., mm/sec)
- **I11:** Maximum acceleration (e.g., mm/sec²)
- **I12:** Tip mode speed

Important: Since some parameters in groups I and J (e.g., paths or accelerations) may assume very large values, the  keys can be used to directly select the tens exponent to be changed. Only the individual digit flashes and not the entire number. The   keys can be used to increment/decrement the value by the selected tens exponent:



Single digit flashes.
Change with  
Select digits with  

 Before starting initial tests, check the limit switches, and decouple the drive from the machine if necessary.

The enable can now be activated as the first test. The display shows

17:posi.active


The position control loop functions, and the current position is maintained. During the next step, the drive is moved via **tip mode (i.e., inching mode)**. Set parameter **J03=1** for this. The   keys can be used to traverse the drive.

 The speed can also be changed during traversing via analog input AE2 (**F20=5**).

The next step is the commissioning of reference traversing. See chapter 10.6. **Software limit switches I50 and I51** can be programmed with a referenced axis (**I86=1**). The software limit switches prevent movement to positions outside **I50** and **I51**.

A short relative movement (**J11=0**) can be specified in **J10** (destination position process block 1) for testing purposes. The speed is entered in **J12**, while the ramps are entered in **J13** and **J14**. **J00=1** can be used to start and monitor the movement. Do not forget the enable.

10.5.2 CONTINUOUS TRAVERSING RANGE (ROTARY AXIS)



The most important feature of a continuous traversing area is the cyclic repetition of certain positions during movement in one direction (e.g., hand on a clock).

Gear ratio: Parameters **I07** and **I08** permit precise specification of the gear ratio (i.e., based on the number of teeth). This prevents a path drift with relative positioning. Cf. examples in chapter 10.9.

Rotary axis function: Selection of **I00=1:unlimited** means that the actual position is only counted up to *circular length I01* (e.g., 360°). After this value, counting begins again at zero. If both directions are permitted, the movement progresses from

point A to point B (i.e., absolute destination specification) over the shortest path (i.e., **path optimization**).

Direction of rotation: If both directions are permitted (**I04=0**), the movement from A to B is performed over the shortest path when absolute destination specification is used (**I03=1, path optimization active**). However, with block changes on the fly, the original direction of rotation is retained. Limitation of the permissible direction of rotation **I04** affects all process blocks and manual traversing. An alternate method is to use **I03=0** to deactivate path optimization. Remember, however, that, when you want to approach an absolute destination in the *negative* direction of rotation, you must enter the destination with a *negative sign* (in connection with the modulo calculation). Example: After you enter -270°, the drive moves to position 90° *rotating counterclockwise*.

A short relative movement (**J11=0**) can be specified for testing purposes in **J10** (destination position, process block 1). **J00=1** can be used to start and monitor the movement.

10.6 REFERENCE POINT TRAVERSING

When the 24 V supply voltage is turned on, the actual position is unknown. A defined preliminary position is achieved with *reference traversing*. Absolute movements can only be performed in referenced status. The referenced state is signaled with **I86=1** and can be output on the binary output.

Reference point traversing is parameterized with **I30** to **I38**. The primary parameters are listed below.

- **I30:** Type of reference point traversing
- **I31:** Direction of reference point traversing
- **I32:** High-speed reference point traversing
- **I33:** Low-speed reference point traversing
- **I35:** Zero-pulse of the motor encoder
- **I37:** Automatic reference point traversing at power-on

There are three ways to start reference point traversing.

- Automatically (**I37=1** or 2)
- Signal on binary input (**F31** to **F34=24**)
- Inching with **J05=1**

If only one direction (**I04>0**) is permitted, reference point traversing is performed from the beginning with speed **I33**. Reference traversing type **I30** specifies the required initiators or the functions for binary inputs. **I31** is used to determine the (search) direction when reference point traversing is started. If the reference switch (or limit switch) is active, the direction is reversed. Cf. example 2 further down. The correct value for **I31** can be tested by inching the axis (parameter **J03**), for example. The status of the binary inputs can be scanned in **E19**.

Specification of two speeds (i.e., **I32** and **I33**) is primarily an advantage for long linear axes.

The **acceleration** during reference point traversing is ½ of the maximum acceleration in **I11**. When the reference point is detected, the actual position is set to **I34** (i.e., reference position), and the drive brakes until it is at a standstill. The distance required for reversal or braking is generally


$$\text{Distance} = \frac{1 v^2}{2a}$$

With v: Speed
a: Acceleration (**I11/2** here).

10. Positioning control


After reference point traversing has been concluded, the drive remains where it is after the required braking distance ($I33^2/I11$) and does not return to the reference position. Cf. above. The AE2 "override" function ($F20=5$) changes the speed and also the braking distance.

Example 1: I30=0:ref.input I31=0:positive




Since the reference switch divides the total traversing area into two halves, no other switches are required.

Example 2: I30=0:ref.input, I31=0:positive




The direction defined in I31 is reversed if the reference switch is active at the beginning.

Example 3: I30=0:ref.input, I31=0:positive



The reference switch (i.e., cam) only reacts briefly. A limit switch is used for the reversal.

Example 4: I30=1:limit.input I31=0:positive




A limit switch can be used for referencing instead of a reference switch.

When the power or the external 24 V voltage supply fails, the information on the reference position is lost. After power returns, I37=1 is used to automatically trigger reference point traversing with the first start command (i.e., *posi.start* or *posi.step*).

After a reference point traversing procedure has been concluded, you can automatically move to any initial position by programming parameter I38 (*ref. block*) to the number of the parameter record to be approached.

10.7 POSITION CONTROLLER

To minimize following error deviation (i.e., difference between reference value and actual position), the SDS uses speed precontrol (speed feed forward). The maximum permissible following error deviation specified in I21 is continuously monitored. The position controller is running continuously during the entire movement.



• H23 (X20 gear ratio): Example of position control using X20

The gain of position control I20 (i.e., the "stiffness" of control) is called the "Kv factor."

The parameter I16 (S-ramp) can be used to parameterize "joltless" traversing profiles and prevent high-frequency excitation due to a low pass. The time constant I16 corresponds to a low-pass limit frequency of $f_g=2\pi/I16$.

10.8 PROCESS BLOCK CHAINING

The "next block" parameters J16, J26, J36 and so on can be used to chain process blocks into sequences. For example, at the end of one process block, this can be used to automatically move to an additional position (i.e., next block). The following parameters apply to the 1st process block.

- J16 next block. If J16=0, then no chaining.
- J17 next start. Specifies how next block J16 is to be started.
- J18 delay. Applies when J17=1:with delay

10. Positioning control

For details on **J17**, see the parameter table.

Example 1: With a rotary attachment, 60° steps are performed in a continuous cycle with 1-sec pauses in between.

Solution: **J10**=60° (Path)
J11=0:relative (Position mode)
J16=1 (Next block no. 1)
J17=1:with delay (Next start with delay)
J18=1.000 sec (delay of 1 sec)

☞ Process block no. 1 starts itself.


Example 2: Three fixed positions are always traversed in the same order.

Solution: **J10, J20, J30**=Destination specification
J11=J21=J31=1:absolute
J16=2, **J26**=3, **J36**=1 (chaining)
J17=J27=J37=0:posi.step

☞ The movements are triggered by the rising edge of the *posi.step* signal.

Example 3: A conveyor belt is to stop after exactly 100 mm following a sensor signal.

Solution: **J11**=2:endless positive
J16=2 (Next block no. 2)
J17=3:posi.next (Next start)
J20=100 mm
J21=0:relative



☞ The *posi.start* signal starts process block no. 1. The drive continues to run until the rising edge of the *posi.next* signal after which a branch is made to process block no. 2. When *posi.next* is connected to BE1, the reaction occurs without a delay time. If the **J17**=3:posi.next setting is not made, *posi.next* is ignored! Cf. example 4.


Example 4: Positioning of a shelf handling device. The exact destination position is specified by a light barrier which is triggered briefly at each shelf. Until just before the destination, the signals of the light barrier must be ignored. We will assume that the destination is located between 5.1 m and 5.4 m.

Solution:

The approximate position is traveled to with block no. 1.
J10=5.1m (Approximate position)
J11=1:absolute
J16=2 (Next block no. 2)
J17=2:no stop (Next start)

Posi.next is activated in block 2 (**J27**).
J20=5.4 m (Maximum position)
J21=1:absolute
J26=3 (Next block no. 3)
J27=3:posi.next (Next start)

The braking distance is defined in block 3.
J30=0.05 m (Braking distance)
J31=0:relative



☞ Process block no. 1 is started with *posi.start*. Just before the probable destination and without an intermediate stop, a switch is made to process block no. 2 where the *posi.next* signal is armed. Process block no. 3 is triggered with *posi.next*, and the braking distance specified in **J30** is executed. If the *posi.next* signal fails to appear (e.g., light barrier is defective), the drive stops at position **J20**.

Tips:

- An operational status of **17:posi.active** indicated on the display means that no process block and no chain of process blocks (i.e., sequential program) is being executed at the moment. The drive is under position control. The *posi.start* and *posi.step* signals have the same effect here.
- **I82** indicates the number of the process block currently being processed. **I82**=0 means that no process block is being processed.
- The inverter assumes the basic state "17:posi.active" when the enable is turned off and on.
- The "17:posi.active" state can also be output on BA1 or BA2.

10.9 SIMPLE EXAMPLES

Without the option board, 4 digital inputs are available.

Example 1: Belt drive (i.e., endless movement). Four different feed lengths are traversed relatively.

Solution: BE1: RV-select0 (**F31**=1)
 BE2: RV-select1 (**F32**=2)
 BE3: posi.start (**F33**=19)

BE1	BE2	Block	Process Block Parameter
0	0	1	J10,J12,J13,J14
1	0	2	J20,J22,J23,J24
0	1	3	J30,J32,J33,J34
1	1	4	J40,J42,J43,J44

☞ The traversing method (e.g., **J11, J21, J31** and so on) remains set to "0:relative" for all blocks. The selected process block is indicated in **I83**.

Example 2: Linear axis with end stops. Two fixed positions are traversed absolutely.

Solution: BE1: RV-select0 (**F31**=1)
 BE2: posi.start (**F32**=19)
 BE3: ref.input (**F33**=23)

BE1	Position	Process Block Parameter
0	1	J10,J12,J13,J14
1	2	J10,J12,J13,J14

☞ The traversing method (**J11** and **J21**) for both process blocks is "1:absolute." After power-on, reference point traversing is automatically executed by **I37**=1 with the first *posi.start* command. The reference switch must have the characteristics shown in example 1 of chapter 10.6.

10. Positioning control


Example 3: Belt drive (endless movement) with stop at pulse (i.e., defined braking distance)

Solution: BE1: posi.start (F31=19)
 BE3: posi.next (F33=20)
 J11=2: endless positive
 J17=3: posi.next
 J20=...(braking distance)

☞ We recommend applying the *posi.next* signal to BE1 (F31=20) so that the delay time of 4 msec is omitted. Evaluation of *posi.next* is activated with J17=3.


For additional details on *posi.next*, see chapter 10.8 (chaining of process blocks).

Example 4: A rotary attachment is to be positioned continuously and without drift in 60° increments. A STÖBER K302 0170 with $i=16.939393...$ is to be used as the gearbox. The exact ratio is $i=3354/198$.




Solution: The rotary attachment rotates precisely $360^\circ \times 198 / 3354$ per motor revolution. Thus, I07=71280, and I08=3354. The path is programmed in degrees (J10=60°). The circular length I01 is 360° .

Example 5: A toothed belt drive is to move continuously and without drift in fixed increments (41 catches per circular length). The toothed disk has 23 teeth, while the belt has 917 teeth. For gearbox, see above.



Solution: To obtain a precise solution, $1/41$ of the circular length is taken as the unit of distance (I05=0). One unit of distance is exactly one catch. The belt drive rotates precisely $198 / 3354 \times 23 \times 41 / 917$ units of distance per motor revolution. Thus, I07=186714, and I08=3075618. The path is programmed in units of distance= $1/41$ of the circular length. The circular length I01 is 41 units.

Example 6: A conveyor belt drive with slip is to move in fixed increments continuously and without drift. Exactly 41 catches are distributed over a circular length of 4 m.




Solution: The distance per motor revolution is $2\pi R/i$. Thus I07=37.09 mm/R. Drift is prevented by continuous referencing (I36=1) or the *posi.next* signal.

Important: The distance to be traveled (e.g., J10) multiplied by the number of catches (41) must precisely equal the circular length I01. If not, the drive will drift away even with continuous referencing. If necessary, I01 and

I07 must be adjusted accordingly. The reference switch should be located between two catches. **Important:** When continuous referencing I36=1 is used, I07 must always be rounded off to the next higher number.

Example 7: Screw/press controller
 Starting at a certain position, the torque is to be monitored. When a limit is exceeded, a return to the start position is made.

Solution: The first part of the movement is handled by process block no. 1. Without stopping, the system switches to process block no. 2 before the end position (J16=2) and J17=2). The speed remains the same (J12=J22). When the torque limit (working area) specified by C44 is exceeded, the system switches to process block no. 3 (J26=3 and J27=4). In our example, the working area is limited by the maximum torque C44.




10.10 EMERGENCY OFF

When 24 V is provided via an option board, a movement which is interrupted by an emergency off can be continued and completed under the following conditions.

- The HALT signal becomes active at least 4 msec before the enable is removed.
- The HALT signal remains present until power returns and the enable is active.

Another method of interrupting and continuing a process block is to use the following sequence of signals.

EMERGENCY OFF Operation




Parameter I19=1 can be used to specify that an enable-off will lead to "23:interrupted." The interrupted process block can then be completed with *posi.step*. With the default setting (I19=0), removal of the enable causes sequence control to be reset (status "17:posi.active"). Process blocks with chaining "without a stop" (J17=2) can only be terminated (status "17:posi.active").

10.11 EXT. ROTARY/LINEAR PATH MEASUREMENT

When an "external" measuring system is mounted directly on the machine for positioning, this measuring system controls

10. Positioning control

the position. The motor is controlled with its own encoder (standard procedure).



Important: The external measuring system must be able to supply at least 30 measuring increments per revolution - as converted to the motor shaft.

10.11.1 ENCODER

The encoder for position control is selected with **I02** while the encoder for motor control is selected with **B26**. The following table lists the possible interfaces with the inverter's supply voltages U_B and the parameters for the number of increments (inc/R) and the gear ratios between motor and encoder ($gear-i$).

	Remarks	U_B	Inc/R	Gear-i
X20	TTL incremental encoder, SSI encoder	-	H22	H23
BE	HTL incremental encoder	-	F36	F39
X41	TTL incremental encoder (no galv. isolation)	5 V	H41	H42

10.11.2 ADJUSTMENT - MOTOR/EXT. MEAS. SYSTEM

The movement of the external measuring system must be converted to the motor shaft. First, the increments of the encoder and its gear ratio must be parameterized. This requires two steps as illustrated with the example of an external encoder on X20 (set **H20=2:encoder in**, chap. 14).

- 1) Determine the number of **measuring increments per motor revolution**. (1 measuring increment = 1 increment on the scale or 1 increment of a rotating encoder).
Example: A measuring increment of 0.07 mm and a spindle incline of 20 mm/R equals $20/0.07 = 285.71$ measuring increments per motor revolution.

- 2a) **Incremental measuring system:** The number of increments per motor revolution is rounded to a whole number ("round" function in the formula below) and parameterized as encoder increment **H22¹** (example for input X20).

$$H22 = \text{Round}(\text{measuring increments per motor revolution})$$

The rounding error is offset by the "gear ratio" of the encoder (**H23 gear-i**).

$$H23 = \frac{H22}{\text{Meas. increments per motor rev.}}$$

- 2b) **SSI measuring system:** There are two different cases.

- a) Measuring increments per revolution $> 128 \cdot N$
- b) Measuring increments per revolution $\leq 128 \cdot N$

With $N=1$ for 24-bit encoders and $N=2$ for 25-bit encoders

Case a: Only **H23** (gear-i) has to be adjusted.

$$H23 = \frac{N \times 4096}{\text{Meas. increments per motor rev.}}$$


¹ If the calculation $H22 < 30$, $H22=30$ must be set. The difference is offset by calculation of **H23**.

Case b: **H22¹** (X20 increments) also has to be adjusted.

$$H22 = \text{Round}(\text{meas. increments per motor revolution} / (4 \cdot N))$$

$$H23 = \frac{4 \times N \times H22}{\text{Meas. increments per motor rev.}}$$

Example: If a 24-bit SSI measuring system has 43.6 measuring increments per motor revolution, this gives $\text{Round}(43.6/4)=11^1$. Then $H22=30$ and $H23 = (4 \cdot 30/43.6) = 2.752$ must be set.



10.11.3 EXTERNAL ENCODER AND POSI PARAMETERS

The encoder for position control is selected with **I02**. **I07/I08** specify the distance per encoder revolution (!) with mathematic precision. With linear measuring systems, one "encoder revolution" is provided by the rounded increment number (e.g., in **H22**) determined in chap. 10.11.2. With a measuring increment of 0.07 mm and a spindle incline of 20 mm/R, $H22 = \text{round}(20/0.07) = 286$. Thus, one "encoder revolution" = $286 \cdot 0.07 = 20.02$ mm, and **I07** = 20.02 mm, **I08** = 1R.

To prevent oscillations due to friction or play in the physical devices, deadband **I23** can be used to deactivate position control within a narrow area.

10.12 POSI SWITCHING POINTS

Posi switching points can be used to generate signals on the binary outputs during the movement. In contrast to the "electric cam" which is always active between positions **I50** and **I51**, posi switching points are only evaluated during the running process blocks (movement) in which they were activated (**L11**, **L12**).

There are 4 posi switching points - S1 to S4. Each of these switching points can be used in several process blocks. Up to two switching points can be selected in one process block. Two switching points are selected for process block no. 1 with the parameters **L11** and **L12**, as shown below.

Parameter	Possible Selection Values
L11	Switch A
L12	Switch B

The characteristics of the switching points are specified in group **N..**. For instance, the first switching point (S1) is described with **N10** ... **N14**.

Parameter	Possible Selection Values
N10	s1-position Example: 113.00 mm
N11	s1-method "0: absolute", "1: rel. to start" or "2: rel. to end"
N12	s1-memory1 Selection for each: "0: inactive", "1: set", "2: clear", "3: toggle"
N13	s1-memory2
N14	s1-memory3


* Toggle = change state each time level changes (i.e., "L" -> "H" -> "L" -> "H" and so on)

11. Synchronous running, elec. gearbox

Definition of the switching-point position can be absolute (e.g., 1250.0 mm) or relative to the beginning or end of the running process block (**N10**, **N11**).

The switching points have no direct effect on the outputs. Instead, up to 3 **switch memories** can be set, cleared or toggled in each switching point. Each binary output can be programmed to one of these three switch memories.

F80=20:s-memory2 outputs switch memory 2 to output BA1.



Example 1: In process block 2, binary output 2 (relay 2) is to be set 150 mm before the target position, and reset when the target position is reached.

Solution: Two switch points (S1 and S2) are required. Switch point S1 activates switch memory 1 (s-memory1). Switch point S2 deactivates the same memory.

Switch Point S1	Switch Point S2
N10=150 mm	N20=0 mm
N11=2:rel.to endpos	N21=1:rel.to endpos
N12=1:set s-memory1	N22=2:clear s-memory1


Switching points S1 and S2 are assigned to process block 2 in group L..

L21 = switch S1, **L22** = switch S2

Output BA2 is assigned to s-memory1 with **F00=19**.

Example 2: A paint pistol is moving back and forth between two points and is to be turned on and off by the inverter with binary output BA1. Since the pistol's reactions are slow, it must be turned on (after the start of the process block) in advance at distance **a** and turned off at distance **b** before the end of the process block.

Solution: Two process blocks (position up, position down) and two switch points are required. The first switch point activates switch memory 1 ("s-memory1"). The second switch point deactivates the same memory.



Switch Point S1	Switch Point S2
N10=a (distance a)	N20=b (distance b)
N11=1:rel.to start	N21=2:rel.to endpos
N12=1:set s-memory1	N22=2:clear (s-memory1)

The same switching points are parameterized in both process blocks.

Process Block 1	Process Block 2
L11 = Switch point S1	L21 = Switch point S1
L12 = Switch point S2	L22 = Switch point S2

Output BA1 is assigned to s-memory-1 with **F80=19**.

11 SYNCHRONOUS RUNNING, ELEC. GEARBOX

Using the synchronous running functionality, you can precisely synchronize two shafts. Different gear ratios are calculated without rounding errors. An incremental encoder of a master drive is used as the master, for example, but frequency/sign signals (i.e., stepper motor simulation) can also be processed.

11.1 FUNCTION OVERVIEW

- Precise speed and angle ratio
- Gear ratio can be set as fraction.
- Following error monitoring
- Free wheeling via binary input
- Precontrol (speed feed forward) for high dynamics
- No stationary angle error
- Angle offset via binary inputs
- Fine adjustment of the gear ratio possible via AE2
- Master signals as incremental encoder (tracks A and B) or stepper motor (frequency and sign)

The **block circuit diagram** for synchronous running is shown in chapter 18.

11.2 CONNECTION OF PULSE SOURCE

The reference value can be received in the form of impulses in one of the following ways.


- Track A + B of an incremental encoder
- Direction + frequency (stepper motor simulation)

Pulse processing is performed by the "electronic gear" function (**G20 > 0**) in mode **C60=1:speed**. The fast reference value must be **off** (**D99=0**).

Both HTL (24 V) and TTL (5 V differential in accordance with RS 422) signals are processed.

HTL signals:


- Use BE1 and BE2 (X1.11 and X1.12).
- Set **F31=14**, **F32=15** for incremental encoder.
- Set **F31=15**, **F32=14** for stepper motor simulation.
- Enter resolution (pulses/revolution) in **F36**.
- Set master encoder **G27=0:BE encoder**. (Activate synchronous run with **G20** before.)





TTL signals:

- Use plug connector X20. Remember terminal resistance for cables longer than 1 m.
- Set **H20=2:encoder in** for incremental encoder.
- Set **H20=3:stepMot in** for stepper motor simulation.
- Enter resolution (pulses/revolution) in **H22**.
- Set master encoder **G27=1:X20**. (Activate synchronous run with **G20** before.)
- X41 can also be used instead of X20. See chap. 5.5

11. Synchronous running, elec. gearbox



A finished, cascadeable master slave connection (ID no. 42940) can be used to pass the pulses from one SDS to the next. The cable length has been optimized for inverters up to 20 A (SDS 4141).



11.3 MASTER – SLAVE

When two SDS 4000 inverters are coupled as master-slave, signals of the encoder simulation on plug connector X20 are connected to the same plug connector of the next inverter.

Master:

- Set encoder simulation on X20 with **H20=1**.
- If necessary, change number of increments in **H21**.

Slave:

- Deactivate fast reference value with **D99=0**.
- Set **H20=2:encoder in**.
- Set the number of pulses/revolution in **H22** for the master (i.e., **H22** on slave = **H21** on master).
- Activate angle synchronous run with **G20=2**.
- Set master encoder to **G27=1:X20**.
- Set slave/master speed ratio in **G22/G21**.
- If necessary, change direction of revolution in **D92**.

The primary functions are listed below.

Binary inputs (parameters **F31** to **F34**)

- **12:ext fault**;
- **17:tip +**; The slave is shifted in the positive direction in relation to the master. The speed is the result of the current speed reference value (AE1 or fixed reference value).
- **18:tip -**; Same as "17:tip +" but in the negative direction.
- **27:syncFreeRun**; Switch off synchronous running to run the drive with the analog reference value, for example.
- **28:syncReset**; Current synchronous difference **G29** is reset.

Binary outputs (parameters **F00** and **F80, F81**)

- **12:sync.diff.**; The synchronous difference exceeds limit value **G24**.

Analog inputs AE2 (parameter **F20, F25**)

- **5:override.**; The gear ratio is affected during operation (i.e., change every 250 msec).
- **13:Sync.offset**; Slave position is changed via analog voltage (100% = **G38**).
- **14:Sync. n-RV**; External speed feed forward with analog reference value

11.4 COMMISSIONING

- Commission master and slave separately (speed control). Parameters **F26, F36** and **H22** are important.
- Configure the encoder input/master on the slave (**F31=14** and **F32=15** or **H20=2**).
- On the slave, speed synchronous running is activated with **G20=1**, and the angle synchronous running is activated with **G20=2**.
- On the slave, enter the number of encoder increments of the master (**F36** or **H22**).
- On the slave, specify the speed ratio (**G22/G21**).
- Direction of rotation can be changed with **D92**.

The master often requires no further parameterization.

11.5 ANGLE DIFFERENCE

The current difference between master and slave is indicated in **G29**. The angle of difference is reset when:

- When voltage is turned on (power and 24 V) if **G20<3**
- Always for BE function "28:SyncReset"
- For enable, halt and quick stop. See **G25**.
- For BE function "27:SyncFreeRun." See **G25**.

The angle controller multiplies angle difference **G29** by **G23** (Kp.). The resulting speed offset is limited to $\pm G26$ (n-correction-Max).

A continuous angle shift between master and slave can be implemented with the BE functions *Tip +* and *Tip -*. The speed difference is the current speed reference value (i.e., analog input AE1 or the fixed reference value). Another way to shift the angle is the AE function "13:synchron-offset."

The **dynamic angle difference** during acceleration is reduced with **speed feed forward**.

- Usually, the master increments are differentiated and added as *speed feed forward* to the speed reference value.

Advantage: No extra wiring required

Disadvantage: The master must move first before the slave can react. The speed obtained by differentiation is smoothed with a low pass. ($T = G22/G21 * F36/H22 * 4$ msec if **G27=0:BE-encoder**. Otherwise $T = G22/G21 * H22/F36 * 4$ msec. In addition: $T \geq 16$ msec).

- The "14:Synchron reference value" function can be used to directly switch the speed reference value (post ramp) from the master to the analog input of the slave (**F20=14**). The

12. Technology

function of the analog output **F40=11:E07 n-postRmp** can be used for this with the master. No ramp can be parameterized on the slave for the external precontrol (speed feed forward). If the analog reference value is circuited in parallel on master and slave, no ramps may be active on the master.

11.6 ANGLE AND SPEED SYNCHRONOUS RUNNING

With *angle* synchronous running (**G20=2**), all angle deviations are acquired and adjusted. However, this is not always desired. In *speed* synchronous running mode (**G20=1**), the angle controller can be partially or completely deactivated.

The following setting is used to limit angle difference **G29** to the value **G24**.

- G20=1: speed synchron run**
- G23>0 (Kp synchronous running)**

Although the speed ratio is precisely adhered to, the slave never attempts to catch up with an angle difference over **G24**. This is similar to a mechanical safety notching coupling.

Make the following selection for pure speed synchronous running.

G24=0

The speed ratio is not mathematically precise.

11.7 EMERGENCY OFF

The following measures are helpful in minimizing divergence of master and slave when the power goes off.

- Select master low voltage limit **A35** higher than that of the slave.
- Set master quick stop to **F38=2**.
- Couple DC links between master and slave.
- Adapt master quick stop ramp (**D81**) and torque limits (**C04**) on the master and slave to the mass ratios.


Turning off the power while the enable is active causes the fault "46:low voltage." After power returns, a device initialization is performed which may take several seconds.

- + We recommend removing the enable at the same time the power is removed so that the inverter does not go into "fault mode".

11.8 REFERENCE POINT TRAVERSING - SLAVE

Reference point traversing permits you to automatically put the slave into a defined initial position.

Reference point traversing is specified with parameters **G31** to **G35**. Reference point traversing is started with a binary input (function **F31=24:Start ref.**).




The drive moves at speed **G32** in direction **G31** until the reference switch (reference input) on a BE becomes active (function **F31=23:Ref.input**). The angle deviation is reset, and the drive halts.

If only one direction of revolution is permitted (**C02**), the drive moves in direction **C02** at speed **G33** until the *rising* edge of the reference switch. The reference direction (**G31**) is ignored in this case.

12 TECHNOLOGY

12.1 PID CONTROLLER

The PID controller on analog input AE2 can be used as a technology controller for compensating rollers, pressure, throughput and similar. It is activated with **G00=1**.



There are four ways to compare reference and actual values.

- Use of differential input AE2. The two signals are connected to "+" and "-" in relation to analog ground.
- A fixed reference value can be defined in **F21** (AE2 offset).
- AE1 can be programmed to **F25=11:PID-reference**.
- PID-reference via fieldbus (**E121**)

The low pass filter (smoothing, time constant **F23**) suppresses undesired high-frequency oscillations. The output of the PID controller is usually used as an additional reference value (**F20=1**). The binary input function "26:disable PID" (**F31** to **F35**) deactivates the controller. The controller output (i.e., adjustment variable) can be limited by **G04** and **G05**. Active limitation can be signaled on relay 2 (**F00=11**), for example. This can be used to indicate a malfunction in the process (e.g., tearing of wound material).

Important: Enable-off sets the output of the PID controller and the I portion to zero.

12. Technology

12.2 WINDERS

The standard inverter software contains functions for solving simple winding tasks (i.e., reel drives). The following tasks are supported.

Task	Task
1	Winding with diameter sensor at constant speed $v = \text{const}$
2	Winding with indirect tension control at the M-max. limit
3	Winding with compensating rollers via speed offset and PID controller on AE2
4	Winding with direct tension control with tension sensor on AE2

When a material is wound and unwound, the speed progresses in reverse proportion to the diameter ($n \sim 1/D$). If there is no diameter sensor (tasks 2 to 4), the diameter is calculated by the inverter as $D \sim v\text{-master} / n\text{-motor}$ ($G11=1$) or obtained by integration of the roller deviation ($G11=2$). The maximum change in speed of the diameter is provided by $G16$. The current diameter is indicated in parameter $G19$ (actual winding diameter). This can be output on the monitor output with $F40=5$. Depending on the task, the winding drive uses the following modes.

- Speed-controlled, $G10=1:n$ mode (tasks 1 + 3)
- At the M-max. limit, $G10=2:M\text{-Max}$ mode (tasks 2 + 4)

12.2.1 DIAMETER SENSOR ON AE1/AE2


Winders or unwinders with constant circumferential speed. The diameter sensor is connected to the analog input. The primary parameters are listed below.

- $F20=7$:wind.diameter (for AE1: $F25$)
- $G10=1:n$ mode
- $G11=0$:AE2-measured
- $G12$ winder D-Min., $G13$ winder D-Max.

Parameters $F21$ and $F22$ are used to assign the values $D\text{-Min.}$ and $D\text{-Max.}$ to the related sensor voltages $U\text{-Min.}$ and $U\text{-Max.}$

- $F21 = -U\text{-Min.} \div 10\text{ V} \times 100\%$ (AE2 offset)
- $F22 = 10\text{ V} \div (U\text{-Max.} - U\text{-Min.}) \times 100\%$ (AE2 gain)

Since the reference value decreases with increasing diameter in accordance with the reciprocal value $1/D$, the master reference value is the highest possible speed with an empty roll.




12.2.2 INDIRECT TENSION CONTROL AT M-MAX LIMIT

Winders or unwinders with constant tension without extra sensors. The winding speed is specified by a master drive. The master reference value must be such that it precisely corresponds to the motor speed required there for $D\text{-Min.}$ (i.e., empty roll). The master reference value must always be positive. See $E10$ (AE1 level). If necessary, the direction of motor revolution must be adjusted with $D92$. The winding drive calculates the diameter in accordance with $D \sim v\text{-master} \div n\text{-motor}$ and affects the torque limit in proportion to D . The torque limit on AE2 or $C03$ is the greatest possible torque with a full roll. The primary parameters are listed below:

- $G10=2:M\text{-Max}$ mode
- $G11=1:n\text{-line}/n\text{-motor}$
- $G12$ Winding $D\text{-Min.}$, $G13$ winding $D\text{-Max.}$
- $G14$ Winding $D\text{-ini}$
- $F20=2$:torque-limit or $C03$
- $D92$ Reference value negation
- $G15$ Override reference value

The speed reference value of a winder must always be greater than the master reference value so that the drive runs at the torque limit. This is ensured with the override reference value $G15$ which is added to the master reference value. In contrast, an unwinder should never be allowed to start running automatically in the direction of unwinding. For this reason, the master reference value of AE1 is never provided unless it is positive.

Override reference value $G15$ ensures that the material is tensed when the master reference value = 0 (i.e., the unwinder attempts to rotate slowly against the direction of winding). The direction of motor revolution can be adjusted with $D92$ or via a binary input. Cf. $F31=6$. The following figure illustrates how this process functions.



Before the winding process starts, the initial diameter must be set to $G14$ via a binary input (e.g., $F31=29$ for BE1). When

12. Technology

the power is turned off, the current diameter (*D-act*) is saved in non-volatile memory.


Incorrect calibration of the master reference value will cause *D-act* to drift away. If the master reference value is too high (e.g., due to **D02** being too high), *D-act* will also be too high! **G17** can be used to parameterize *tension reduction* with increasing diameter.

12.2.3 WINDING WITH COMPENSATING ROLLER

Winders or unwinders with constant tension provided by a compensating roller. The position of the compensating roller is measured and controlled via a PID controller on AE2. The winding speed is specified by a master drive. The winding drive calculates the diameter in accordance with $D \sim v\text{-master} / n\text{-motor}$ and multiplies both the master reference value and the offset reference value by $1/D$. The primary parameters are listed below.

- **G10**=1:n mode
- **G11**=1:n-line/n-motor
- **G12** Winding D-Min., **G13** winding D-Max
- **G14** Winding D-ini
- **G00**=1 (PID controller active)
- **G01** PID controller Kp, **G02** PID controller Ki
- **F20**=1:additional reference value

Block circuit diagram:




Instead of using **G11**=1:n-line/n-motor to calculate the diameter, **G11**=2:roller can also be used for a compensating roller. The deviation of the roller is measured with an analog input (**F20**=12:wind.roller). A speed feedback is not required. Integration of the diameter is controlled by the positive or negative deviation of the roller.

12.2.4 WINDING WITH TENSION SENSOR

Tasks similar to winding with compensating roller but with the following differences.

- **G10**=2:M-Max mode
- **F20**=2: torque-limit
- **G15** Override reference value

When winding with tension sensors, it is often a good idea to use an external PID controller with integration and precontrol (speed feed forward) of the tension reference value.



12.2.5 COMPENSATION OF FAULT VARIABLES

The effects of friction and inertia on the traction can be compensated for. The torque limit is offset by the friction used with **G40** and **G41**.

Compensation of inertia: The inertia torque of the full roll at D-Max must be converted to the motor shaft and entered in **C30** as a ratio of the inertia torque of the motor. The acceleration is obtained by differentiation of the encoder signal. The result can be smoothed with **G42**.

The variable diameter may also affect the gain of the speed controller. The gain between **C31*****C35** at D-Min and **C31** at D-Max changes in proportion to the square of the diameter. The I portion is affected in the same way.

13. Parameter Description

A.. Inverter		E
Para. No.	Description	
A00 ¹⁾	Save parameter: 0: inactive; 1: The parameters of both parameter records are saved in non-volatile memory. Saving is triggered when the value changes from 0 to 1. " A02 check parameter " is then performed automatically.	
A01•	Read parabox & save: Read parameters from Controlbox and save in non-volatile memory. The inverter recognizes automatically what is connected to X3. With Controlbox : First select desired data record (1 to 7), and then press # . " A02 check parameter " is started automatically. When read errors occur (e.g., Parabox disconnected while being read accessed), all parameters are rejected, and the settings last saved with A00 are restored. 0: inactive; 1: active; 1 to 7 for Controlbox (number of the data record)	
A02 ¹⁾	Check parameter: Parameterization is checked for correctness. For possible results, see chap. 15. 0: inactive; 1: active; Parameters of the parameter record to be edited (see A11) are checked for the following. - Adherence to the value range - Correct programming of the binary inputs (F31 to F35)	
A03 ¹⁾	Write to Parabox: Write data of the inverter to external data medium (Parabox, Controlbox) 0: inactive; 1 to 7; The parameters of both parameter records are copied from the inverter to Parabox (Controlbox). For handling, see A01 .	
A04• ¹⁾	Default settings: All parameters are reset to their default settings. 0: inactive; 1: active; The procedure is triggered when the value changes from 0 to 1.	
A10	Menu level: Specifies the parameters which can be accessed by the user 0: standard; Parameters which can be accessed are highlighted in gray in the parameter table (see chap. 21). All parameters remain in effect including those in the "1:extended" menu level. 1: extended; Access to all parameters which can be set 2: service; Access to rarely used service parameters. Small print (e.g., A37).	
A11	Parameter set edit: Specifies the parameter record to be edited. The parameter record to be edited (A11) and the active parameter record (status indication) do not have to be identical. For example, parameter record 1 can be edited while the inverter continues operation with parameter record 2. See also chapter 9.4. 1: parameter set 1; Parameter record 1 is edited. 2: parameter set 2; Parameter record 2 is edited.	
A12	Language: When the language is changed, FDS-Tool-specific texts U22 , U32 , U42 and U52 are reset to the default setting. This also applies to C53 and I09 . 0: deutsch; 1: english;	
A13	Set password: Password is requested. If a password is defined in A14 , this must be entered here before parameters can be changed. See chapter 7.3.	
A14	Edit password: Definition and modification of the password. 0 means that no password has been set. All other values are valid passwords. See chapter 7.3. A defined password can only be read out via FDS Tool.	
A15	Auto-return: Permits automatic return from the menu to the status indication. In edit mode (i.e., the edited parameter is flashing), there is no automatic return to the status indication. 0: inactive; 1: active; If 50 seconds pass without a key being pressed, the display jumps back to the status indication.	
A20	Braking resistor type: Specification of the braking resistor type 19:inactive; Brake transistor deactivated. Too much braking force causes fault "36:overcurrent." 20: Internal; Integrated braking resistor. See page 2 of technical data. 21: User defined; Any external braking resistor. See A21 , A22 and A23 . 22: 80Ohm0.3kW 23: 80Ohm0.6kW 24: 30Ohm0.6kW 25: 30Ohm1.0kW 26: 30Ohm1.2kW 27:30Ohm2.5kW	A thermal model monitors the max. permissible power which can be led off via the braking resistor. This protects the braking resistor against thermal overload. A thermal overload causes the fault "42:tempBrakeRes."
A21	Brake resistor resist.: Only with A20 =1 (user defined), resistance value of the braking resistor used Value range in Ω : Depends on type, up to 600	
A22	Braking resistor rating: Only with A20 =1 (user defined), capacity of the braking resistor used Value range in kW: 0 to ..., depends on type	

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90**≠1
- Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:extended or **A10**=2:service.
- E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

A.. Inverter		E
Para. No.	Description	
A23	Braking resistor therm.: Only with A20=1 (user defined), thermal time constant of the braking resistor <i>Value range in sec:</i> 0.1 to <u>40</u> to 100	
A30•	Operation input: Specifies the origin of the control signals (i.e., enable, direction of rotation and ref. value) <i>0:</i> control interface (X1); Control signals (e.g., enable and so on) are generated via the X1 terminals. All binary inputs must be programmed accordingly. Fieldbus operation without <i>Drivocom</i> profile. <i>1:</i> serial (X3); Control signals (e.g., enable and so on) are generated from the PC (FDS Tool software). The inverter is connected to the PC via sub D plug connector X3 (RS 232-C interface). See chapter 9.9. Remote control via the PC requires that the enable input (X1) be high. <i>2:</i> inactive; <i>3:</i> SDP 4000; Control of the device via PROFIBUS-DP. This requires the PROFIBUS-DP option board. <i>4:</i> CAN-bus; Control of the device via CANopen with the integrated CAN bus interface which is standard. The following applies to both settings (i.e., " <i>3: Profibus-DP</i> " and " <i>4: CAN-bus</i> "). The servo inverter is put into a drive-compatible mode for device control. This control is performed exclusively either via the selected fieldbus (requires that all parameters for the function of the binary and analog inputs F20 , F31 , F32 , F33 and so on be set to inactive) or in mixed operation with these inputs. The high level must always be present on the enable input.	
A31	Esc-reset: Use the [Esc] key to acknowledge faults while they are being indicated. <i>0:</i> inactive; <i>1:</i> active; Faults can be acknowledged with [Esc] .	
A32	Auto-reset: Faults which occur are acknowledged automatically. <i>0:</i> inactive; <i>1:</i> active; The inverter acknowledges some faults automatically. See chapter 17. Faults can be automatically acknowledged successfully three times within a time period of 15 minutes (default setting). A fourth fault is not acknowledged automatically. Instead, relay 1 opens, and the fault must be acknowledged in some other way (i.e., enable, binary input F31 to F35=13 , or [Esc] key A31). The automatic acknowledgment counter is reset. After three unsuccessful attempts at acknowledgment, the inverter ignores automatic acknowledgment and malfunctions. The time period for automatic acknowledgment can be parameterized from 1 to 255 min in A33 .	
A33	Time auto-reset: Time period for automatic acknowledgment. See A32 . <i>Value range in min:</i> 1 to <u>15</u> to 255	
A34	Auto-start: Before you activate auto-start A34=1 , check to determine whether safety requirements permit an automatic restart. <i>0:</i> inactive; After power-on, the enable must change from L level to H level to enable the drive (→ message " <i>12:inhibited</i> "). This prevents the motor from starting up unintentionally (i.e., machine safety). <i>1:</i> active; When auto-start is active, the drive can start running immediately (if enabled) after the power is turned on.	
A35	Low voltage limit: If the inverter is enabled and the DC-link voltage is less than the value set here, the inverter assumes fault " <i>46:low voltage</i> ." A35 should usually be approx. 85% of the power voltage present to offset possible failure of a power phase. <i>Value range in V:</i> 150 to <u>350</u> to 570	
A36	Mains voltage: Maximum voltage provided to the motor by the inverter. Usually the power voltage. Starting at this voltage, the motor runs in the field weakening range. <i>Value range in V:</i> 140 to 400 to 480	
A37	Reset memorized values: The six different following error counters E33 to E38 (e.g., maximum current, maximum temperature and so on) are reset.	
A38	DC power-input: <i>0:</i> inactive; <i>1:</i> active;	
A40• ¹⁾	Read parabox: Read parameters from a Controlbox <i>without</i> automatic storage. <i>0:</i> inactive; <i>1 to 13:</i> active; For function, cf. A01 .	
A41	Select parameter set: Two parameter records are available. These can be selected via the binary inputs or directly via A41 . The selected parameter record does not become active until the enable has been removed and after a maximum of 300 msec have passed. Some parameters retain their validity in both parameter record 1 and parameter record 2 (e.g., the posi. parameters in I , J and L). Parameters which can be programmed separately in parameter record 2 are indicated by a E between the coordinate and parameter name. See chapter 7.1. <i>0:</i> external; The active parameter record is selected via binary inputs BE1 to BE5. At least one of the parameters F30 to F35 must be set to 11 (<i>parameter set-select</i>) in both parameter records. Parameter record 1 is	

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90≠1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

B.. Motor		E
Para. No.	Description	
B00•	<p>Motor-type: Motor selection from the motor data base. The STÖBER system motor used is specified with B00=61 to 69. B00=60 (user defined) is used for special windings or motors of other manufacturers.</p> <p>60: user defined 62: ES 33 64: ES 44 66: ES 54 68: ES 74 61: ES 32 63: ES 42 65: ES 52 67: ES 72 69: ES 76</p> <p>The EMC voltage constant must be entered in B02. An "*" on the display means that at least one of the parameters (B53, B64 and B65) differs from the default setting of the STÖBER motor data base.</p>	√
B02	<p>EMC-constant: Specifies the peak value of inducted voltage between two phases at 1000 rpm. Value range in V: 5 to 110 to 3000</p>	√
B03	<p>Motor fan: Only when B00 > 60 (STÖBER motors). The thermally permissible motor torque is increased (i2t model of the motor). B03=1 thus also increases the torque limits since M-Max limits C03 and C04 are specified relative to motor standstill torque M0. To prevent overloading a gearbox after installing a motor fan retroactively, C03/C04 must be adjusted to the new M0. See catalog or name plate.</p> <p>0: inactive; 1: active;</p>	√
B10•	<p>Poles: Calculated from the nominal speed of the motor $p=2 \times (f \times 60/n_{Nom})$. Internally, the controller works with frequencies. Correct speed indication requires entry of the number of poles. Value range: 2 to 6 to 16</p>	√
B11•	<p>P-nominal: Nominal power as per nameplate Value range in kW: 0.12 to (depends on type)</p>	√
B12	<p>I-nominal: Nominal current as per nameplate. Value range in A: 0 to (depends on type)</p>	√
B13	<p>n-nominal: Nominal speed as per nameplate Value range in rpm: 0 to depends on type to 6000</p>	√
B17	<p>M0 (standstill): Standstill torque M0 as shown on name plate. Reference value for M-max limits C03 and C04. Value range in Nm: 0 to (depends on type) to 327.67</p>	√
B26•	<p>Motor-encoder: B26 specifies which encoder input will be used for motor control. The encoder increments are specified with F36 or H22. Regardless of B26, the master encoder is set for synchronous operation (G20=1) with G27 and the POSI encoder (C60=2) is set with I02.</p> <p>2: resolver (X40); Standard for STÖBER ES motors 3: X41 (SinCos); Single and multi-turn, absolute-value encoders with sin/cos track</p>	√
B40• ¹⁾	<p>Phase test: 0: inactive; 1: active; Tests motor symmetry in increments of 60°. The following points are checked.</p> <ul style="list-style-type: none"> - Connection of phases U, V and W - Motor and resolver pole number - Phase position of resolver or sin/cos encoder - Symmetry of the winding resistors of the phases U, V and W. If a winding resistor deviates by ±10%, the inverter reports "19:symmetry." <p>The function is started when the level on the input enable (X1.9) changes from low to high. Exiting the parameter requires another low signal on the enable.</p>	
B41• ¹⁾	<p>Autotuning: 0: inactive; 1: active; Winding resistors of the motor are measured. The function is started when the level on the input enable (X1.9) changes from low to high. Exiting the parameter requires another low signal on the enable.</p> <p>A00=1 saves the measuring results in non-volatile memory. B00=60, autotuning of the motor is essential! Important for optimum coordination between inverter and motor. B00=61 to 69, autotuning of the motor is not required.</p>	
B53	<p>R1-motor: Stator resistance (Ru-v) of the motor winding. Only entered for non STÖBER motors. Value range in Ω: 0.01 to depends on type to 327.67</p>	√
B64	<p>Ki-IQ (torque): Integral gain of the torque controller. Value range in %: 0 to depends on type to 400</p>	√
B65	<p>Kp-IQ (torque): Proportional gain of the torque controller. Value range in %: 0 to depends on type to 400</p>	√

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90≠1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

C.. Machine		E
Para. No.	Description	
C00	n-Min: Only if C60 ≠2 (run mode≠position). Minimum permissible speed. The speed refers to the motor shaft speed. Reference values less than n-Min are ignored and raised to n-Min. <i>Value range in rpm: 0 to C01</i>	√
C01	n-Max: Maximum permissible speed. The speed refers to the motor shaft speed. Reference values over n-Max are ignored and limited to n-Max. <i>Value range in rpm: C00 to 3000 to 6000</i>	√
C02•	Permitted. direction of rotat.: Only if C60 ≠2 (run mode≠position). Determines the permissible direction of rotation. The direction of rotation can be specified via the binary inputs. <i>0: clockwise & counter-clockwise; 1: clockwise; 2: counter-clockwise;</i>	√
C03	M-Max 1: Maximum torque in % of motor zero current. The active torque limit can be further reduced with an analog input (see F25 =2). If the maximum torque is exceeded, the controller responds with the message "47:drive overload." See also remarks for C04 . <i>Value range in %: 0 to 150 to 400 (and any M-Max signal present on analog input-AE function "2:Torque limit")</i>	√
C04	M-Max 2: Additional torque limit. You can switch between C03 and C04 with a binary input (F3 ..=10:torque select). See chap. 9.2. Remarks: Since C04 is always active for a quick stop , C04 ≥ C03 should usually apply! <i>Value range in %: 0 to 150 to 400</i>	√
C30	J-mach/J-motor: Ratio of the inertia of load to motor. This factor is effective for all control modes and is important for optimization between inverter and motor (i.e., dynamics). Entry is not mandatory. Remarks: In winding mode, the effective inertia torque is calculated for C30 ≥ 1.5 to the fourth power with the winding diameter for compensation of the acceleration torque. The following applies: J(D-Min) = 1.5 * J-motor, J(D-Max)= C30 * J-motor. The torque supplied by the drive is increased so that tension remains constant and extra torque is available for acceleration. <i>Value range: 0 to 1000</i>	√
C31	n-controller Kp: Proportional gain of the speed controller. Remarks: In winding mode (G10 >0), the Kp gain with the winding diameter is quadratically reduced from C31 for D-Max down to C31 * C35 for D-Min. <i>Value range in %: 0 to 60 to 400</i>	√
C32	n-controller Ki: Integral gain of the speed controller. Reduce C32 when overshwing occurs in the target position. Remarks: In winding mode (G10 >0), the Ki gain with the winding diameter is quadratically reduced from C32 * C31 for D-Max down to C32 * C31 * C35 for D-Min. <i>Value range in %: 0 to 30 to 400</i>	√
C33	n-RefVal low pass: Reference value smoothing. C33 should be increased for reference value noise, physical oscillation or large foreign masses. <i>Value range in msec: 0 to 2 to 3276.7</i>	√
C34	n-motor low pass: Smoothing of the motor speed. <i>Value range in msec: 0.5 to (depends on type) to 3276.7</i>	√
C35	n-control. Kp standstill: Without winders: C31 and C32 are multiplied by C35 as soon as the motor speed drops below C40 . With winders: The formulas described under C31 and C32 apply. <i>Value range in %: 5 to 100</i>	√
C40	n-window: If F00 =3 (BA 2 as signal relay for "3:reference value-reached") or F00 =2 (BA 2 as signal contact for speed "2:standstill"), the reference value is considered achieved in a window of reference value ± C40 . Also applies to the other binary inputs. A halting brake is not activated as long as [n] > C40 . <i>Value range in rpm: 0 to 3 to 300</i>	√
C41	Operating range n-Min: Parameters C41 to C46 can be used to specify an operating area. An output (F00 =6) can be used to signal that these values have been exceeded. All area monitoring procedures are performed at the same time. If area monitoring is not required, the minimum parameters must be set to the lower-limit values, and the maximum parameters must be set to the upper-limit values. Cf. chapter 9.3. When C49 =0, operating-range monitoring is suppressed when the motor is not powered and during acceleration/braking procedures. When C48 =1, amount generation is activated. <i>Value range in rpm: 0 to C42</i>	√
C42	Operating range n-Max: See C41 . <i>Value range in rpm: C41 to 6000</i>	√

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90**=1
- Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:extended or **A10**=2:service.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

D.. Reference Value		Group D is not shown in run mode C60=2:position.	E																								
Para. No.	Description																										
D01	<p>Reference value decel: Deceleration ramp for analog reference value inputs. Is only used for specification of reference value via terminal strip X1 and motor potentiometer.</p> <ul style="list-style-type: none"> – Voltage, current via analog input 1 (X1.2 to 4) – Frequency via binary input BE5 (X1.8 to 14) – Motor potentiometer via the binary inputs (D90=1) <p>Value range in msec/3000 rpm: 0 to 30000</p>		√																								
D02 ²⁾	<p>Speed (max. ref. value): Parameters D02 to D05 can be used to specify as desired the relationship between analog reference value and speed with a reference value characteristic curve.</p> <p>D02: Speed achieved with the maximum reference value (D03)</p> <p>Value range in rpm: 0 to 3000 to 6000</p>		√																								
D03 ²⁾	<p>Reference value-Max.: Reference value to which the speed (max. RV - D02) is assigned. Percentage of the analog reference value (10 V = 100%) at which the maximum speed (D02) is achieved.</p> <p>Value range in %: D05 to 100</p>		√																								
D04 ²⁾	<p>n speed (min. ref. value): Speed achieved with minimum reference value (D05).</p> <p>Value range in rpm: 0 to 6000</p>		√																								
D05 ²⁾	<p>Reference value-Min.: Reference value to which the speed (min. RV - D04) is assigned. Percentage of the analog reference value (10 V = 100%) at which the minimum speed (D04) is achieved.</p> <p>Value range in %: 0 to 1 to D03</p>		√																								
D06 ²⁾	<p>Reference value offset: Corrects an offset on analog input 1 (X1.2 to 4). When the ref. value is 0, the motor may not be permitted to rotate. If a revolution occurs anyway, this value must be entered with reversed sign as the offset (e.g., if param. E10 shows 1.3%, D06 must be parameterized to -1.3%). The value range is ±100%. While the ref. value offset is being entered, the current value of the analog input is shown at the same time.</p> <p>Value range in %: -100 to 0 to 100</p>		√																								
D07 ²⁾	<p>Reference value enable: When the minimum reference value (D05) is set to a value greater than 1%, an enable can be derived from the reference value output.</p> <p>0: inactive; 1: active; An additional enable is derived from the reference value on analog input 1. If the reference value enable is high, the output is greater than or equal to the minimum reference value (D05). If the reference value enable is low, the output is less than the minimum reference value (D05).</p>	<p>Inactive for A50=1 or serial interface or fixed reference value or fieldbus</p>	√																								
D08 ²⁾	<p>Monitor reference value. Monitors reference value output. Monitors for wire break. Ref. value monitoring will only function if the minimum reference value specified in D05 is greater than or equal to 5% (D05 ≥ 5%).</p> <p>0: inactive; 1: active; If the reference value output is 5% less than the minimum permissible reference value (D05), the inverter shows "43:RV wire brk."</p>		√																								
D09	<p>Fix reference value no.: Selection of a fixed reference value</p> <p>0: external selection via binary inputs and BE functions RV-select 0 to 2</p> <p>1 to 7: fixed selection of fixed reference value. BE inputs are ignored.</p>		√																								
D10 ²⁾	<p>Accel 1: Up to 7 fixed reference values/ramp records can be defined per parameter record. Selection is made via the binary inputs. At least one binary input must be programmed to reference value selector (e.g., F31=1:RV-select0). The reference value selector is used to assign the fixed reference values or ramp records to the signals of the binary inputs. The result of the binary coding is shown in E60 (0 to 7). The ramp records (accel 1 to 7 / decel 1 to 7) are only active in connection with the assigned fixed reference values 1 to 7.</p> <p>Accel 1: Acceleration time for ramp record 1 as related to 150 Hz.</p> <p>Value range in msec/3000 rpm: 0 to 60 to 30000</p>		√																								
D11 ²⁾	<p>Decel 1: Deceleration time for ramp record 1 as related to 150 Hz.</p> <p>Value range in msec/3000 rpm: 0 to 60 to 30000</p>		√																								
D12 ²⁾	<p>Fix reference value 1: Selection is made parallel to ramp record 1 (accel 1 / decel 1) via the binary inputs.</p> <p>Value range in rpm: -6000 to 750 to 6000</p>		√																								
D20 ²⁾	<p>Accel 2: Acceleration time for ramp rec. 2 as related to 150 Hz.</p> <p>Value range in msec/3000 rpm: 0 to 90 to 30000</p>	<table border="1"> <thead> <tr> <th>No.</th> <th>Accel</th> <th>Decel</th> <th>Reference Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>D00</td> <td>D01</td> <td>Analog, freq...</td> </tr> <tr> <td>1</td> <td>D10</td> <td>D02</td> <td>Fixed RV 1</td> </tr> <tr> <td>2</td> <td>D20</td> <td>D03</td> <td>Fixed RV 2</td> </tr> <tr> <td>⋮</td> <td>⋮</td> <td>⋮</td> <td>⋮</td> </tr> <tr> <td>7</td> <td>D70</td> <td>D71</td> <td>Fixed RV 7</td> </tr> </tbody> </table>	No.	Accel	Decel	Reference Value	0	D00	D01	Analog, freq...	1	D10	D02	Fixed RV 1	2	D20	D03	Fixed RV 2	⋮	⋮	⋮	⋮	7	D70	D71	Fixed RV 7	√
No.	Accel	Decel	Reference Value																								
0	D00	D01	Analog, freq...																								
1	D10	D02	Fixed RV 1																								
2	D20	D03	Fixed RV 2																								
⋮	⋮	⋮	⋮																								
7	D70	D71	Fixed RV 7																								

- The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15. 2) Only available when D90≠1

Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:extended or A10=2:service.

Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

D.. Reference Value		Group D is not shown in run mode C60=2:position.	E															
Para. No.	Description																	
D2 ^{1,2}	Decel 2: Deceleration time for ramp rec. 2 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>90</u> to 30000		√															
D22 ²	Fix reference value 2: Selection is made parallel to ramp rec. 2 (accel 2/decel 2) via the binary inputs. <i>Value range in rpm:</i> -6000 to <u>1500</u> to 6000		√															
D30 ²	Accel 3: Acceleration time for ramp rec. 3 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>120</u> to 30000		√															
D31 ²	Decel 3: Deceleration time for ramp rec. 3 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>120</u> to 30000		√															
D32 ²	Fix reference value 3: See D12. <i>Value range in rpm:</i> -6000 to <u>3000</u> to 6000		√															
D40 ²	Accel 4: Acceleration time for ramp record 4 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>5</u> to 30000		√															
D41 ²	Decel 4: Deceleration time for ramp record 4 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>5</u> to 30000		√															
D42 ²	Fix reference value 4: See D12. <i>Value range in rpm:</i> -6000 to <u>500</u> to 6000		√															
D50 ²	Accel 5: Acceleration time for ramp record 5 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>10</u> to 30000		√															
D51 ²	Decel 5: Deceleration time for ramp record 5 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>10</u> to 30000		√															
D52 ²	Fix reference value 5: See D12. <i>Value range in rpm:</i> -6000 to <u>1000</u> to 6000		√															
D60 ²	Accel 6: Acceleration time for ramp record 6 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>20</u> to 30000		√															
D61 ²	Decel 6: Deceleration time for ramp record 6 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>20</u> to 30000		√															
D62 ²	Fix reference value 5: See D12. <i>Value range in rpm:</i> -6000 to <u>2000</u> to 6000		√															
D70 ²	Accel 7: Acceleration time for ramp record 7 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>25</u> to 30000		√															
D71 ²	Decel 7: Deceleration time for ramp record 7 as related to 150 Hz. <i>Value range in msec/3000 rpm:</i> 0 to <u>25</u> to 30000		√															
D72 ²	Fix reference value 7: See D12. <i>Value range in rpm:</i> -6000 to <u>2500</u> to 6000		√															
D81	Decel-quick: Quick stop ramp. Effective if a binary input is programmed to quick stop (F3..=9) or parameter F38>0. When a quick stop is triggered by the binary inputs, the drive is decelerated with the deceleration ramp set here. In position mode (C60=2), quick stop is performed on ramp I11. <i>Value range in msec/3000 rpm:</i> 0 to <u>2</u> to 30000		√															
D90 [*]	Reference value source: See block circuit diagram in chap. 19. <i>Q: standard reference value;</i> 1: motor potentiometer; Two binary inputs can be used to simulate a "motor potentiometer." This requires that one binary input be programmed to "4: motorpoti up" and another binary input to "5: motorpoti dwn" (e.g., F34=4 and F35=5). Only ramps D00 and D01 can change the speed. 2: motor potentiometer+reference value; The ref. value for speed of the motor potentiometer function is added to the "standard" ref. value (i.e., analog input, fixed reference values). When D90=1, only the motor potentiometer ref. value is used. The ramps selected with the binary inputs are used, and the motor potentiometer ref. value changes with RV-accel/RV-decel (i.e., D00 and D01).	<table border="1"> <thead> <tr> <th>BE4</th> <th>BE5</th> <th>Motor Poti RV</th> </tr> </thead> <tbody> <tr> <td>L</td> <td>L</td> <td>Constant</td> </tr> <tr> <td>H</td> <td>L</td> <td>Larger</td> </tr> <tr> <td>L</td> <td>H</td> <td>Smaller</td> </tr> <tr> <td>H</td> <td>H</td> <td>0</td> </tr> </tbody> </table>	BE4	BE5	Motor Poti RV	L	L	Constant	H	L	Larger	L	H	Smaller	H	H	0	√
BE4	BE5	Motor Poti RV																
L	L	Constant																
H	L	Larger																
L	H	Smaller																
H	H	0																
D91	Motorpoti function: Only if D90≠0 (reference value source ≠ standard RV) <i>Q: non-volatile;</i> The reference value which was approached is retained both when the enable is removed and when the power is turned off/on. <i>1: volatile;</i> The reference value is set to 0 when the enable becomes low or the power for the drive is turned off.		√															
D92	Negate reference value: See block circuit diagram in chap. 19. <i>Q: inactive;</i> <i>1: active;</i> The reference value channel is negated. Corresponds to a reverse in direction of rotation. Not related to the selected reference value.		√															

• The power pack must be turned off before these parameters can be changed.
Italics These parameters are sometimes not shown depending on which parameters are set.
 1) See result table in chap 15. 2) Only available when D90≠1
 Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:extended or A10=2:service.
 E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

D.. Reference Value		Group D is not shown in run mode C60=2:position.	E
Para. No.	Description		
D93	RV-generator: For commissioning and optimizing the speed controller. <i>0: inactive;</i> Normal reference value selection. <i>1: active;</i> ±A51 is specified cyclically as reference value. The time can be set in D94.		
D94	Ref. val. generator time: After this period of time, the sign of the reference value changes when D93=1:active. Value range in msec: 0 to 500 to 32767		√
D99	Fast reference value: Activates the speed-optimized speed specification via the analog input (use with a host position controller). <i>0:inactive;</i> Reference value processing compatible with FDS 4000 with various functions such as fixed reference values, additional reference value, motor potentiometer and many others. Reference value processing is performed with 4 msec, and speed control with 0.5 msec. <i>1:active;</i> The analog reference value (only of AE1) is forwarded with 1 msec to the speed controller. The speed controller uses 0.5 msec. The spec. manipulations along the reference-value path (offset reference value, technology function) have no effect.		√
E.. Display Values			E
Para. No.	Description		
E00	I-motor: Indicates the active motor current in amperes.		
E01	P-motor: Indicates the current power of the motor in kW and as a relative percentage in relation to nominal motor power.		
E02	M-motor: Indicates the current motor torque in Nm and as a relative percentage in relation to the motor zero torque M0.		
E03	DC-link-voltage: Indicates the current DC-link voltage. Value range for single-phase inverters: 0 to 500 V. Value range for three-phase inverters: 0 to 800 V.		
E06	n-reference value: Only if C60=1 (speed). Indicates the current reference value for speed in relation to the motor shaft.		
E07	n-post-ramp: Indicates the current speed in relation to the motor shaft after the ramp generator. In position mode (C60=2), the sum of "output controller position" + "n-speed feed forward" = "speed controller reference value" is indicated. Cf. chap. 10.7.		
E08	n-motor: Indicates the current motor speed.		
E09	Rotor position: Position of the motor shaft. With absolute-value encoders, the encoder position read from the encoder is entered when the device starts up. This position is available in all modes. The display shows whole motor revolutions with 3 positions after the decimal point. The full resolution of 20 bit/R is supplied via fieldbus.		
E10	AE1-level: Level of the signal present on analog input 1 (X1.2 to 4). ±10 V is 100%.		
E11	AE2-level: Level of the signal present on analog input 2 (X1.6 to X1.7). ±10 V is 100%.		
E16	Analog-output1-level: Indicates the level on the analog output (X1.5 to 6). ±10 V corresponds to ±100%.		
E17	Relay 1: Status of relay 1 (ready for operation). <i>0: open;</i> For meaning, see parameter F10. <i>1: closed;</i> Ready for operation.		
E18	Relay 2: Status of BA 2. The function of BA 2 is specified with parameter F00. <i>0: inactive;</i> <i>1: active;</i>		
E19	BE15...BE1 & enable: The status of the binary inputs including the option board is shown as a binary word.		
E20	Device utilization: Indicates the current load of the inverter in %. 100% corresponds to the nominal capacity of the inverter.		
E21	Motor utilization: Indicates the current load of the motor in %. Reference value is the nominal motor current specified under B12.		
E22	i2t-device: Level of the thermal device model (i.e., i ² t model). If utilization is 100%, the fault message "39:tempDev.i2t" appears.		
E23	i2t-motor: Level of the thermal motor model (i.e., i ² t model). 100% corresponds to full utilization. The thermal model is based on the design data specified under group B (motor) (e.g., continuous operation (S1 operation)).		
E24	i2t-braking resistor: Level of the thermal braking resistor model (i.e., i ² t model). 100% corresponds to full utilization. The data of the braking resistor are specified with A20 to A23.		
E25	Device temperature: Current device temperature in °C.		

- The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when D90≠1

Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:extended or A10=2:service.

Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.


13. Parameter Description

E.. Display Values		E																																																									
Para. No.	Description																																																										
E60	<p>Reference value selector: Indicates the result of the binary coding of the fixed reference values with specification via binary inputs. At least one binary input must be parameterized for the reference value selector (F3..=1 to 3). The result of the binary coding is indicated with the digits 0 to 7. A fixed reference value/ramp record is assigned to this result.</p> <p>A fixed reference value can also be specified directly with D09. However, E60 is not affected by D09. In position mode (C60=2), E60 indicates the result of process block specification with binary inputs (E60=0 → proc. block1).</p>	<table border="1"> <thead> <tr> <th colspan="3">RV select</th> <th rowspan="2">E60</th> <th rowspan="2">Reference Value</th> <th rowspan="2">Proc. Block</th> </tr> <tr> <th>2</th> <th>1</th> <th>0</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Analog, freq,..</td> <td>1</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Fix. ref. val. 1</td> <td>2</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>2</td> <td>Fix. ref. val. 2</td> <td>3</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>3</td> <td>Fix. ref. val. 3</td> <td>4</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>4</td> <td>Fix. ref. val. 4</td> <td>5</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>5</td> <td>Fix. ref. val. 5</td> <td>6</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>6</td> <td>Fix. ref. val.t 6</td> <td>7</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>7</td> <td>Fix. ref. val. 7</td> <td>8</td> </tr> </tbody> </table>	RV select			E60	Reference Value	Proc. Block	2	1	0	0	0	0	0	Analog, freq,..	1	0	0	1	1	Fix. ref. val. 1	2	0	1	0	2	Fix. ref. val. 2	3	0	1	1	3	Fix. ref. val. 3	4	1	0	0	4	Fix. ref. val. 4	5	1	0	1	5	Fix. ref. val. 5	6	1	1	0	6	Fix. ref. val.t 6	7	1	1	1	7	Fix. ref. val. 7	8
RV select			E60	Reference Value	Proc. Block																																																						
2	1	0																																																									
0	0	0	0	Analog, freq,..	1																																																						
0	0	1	1	Fix. ref. val. 1	2																																																						
0	1	0	2	Fix. ref. val. 2	3																																																						
0	1	1	3	Fix. ref. val. 3	4																																																						
1	0	0	4	Fix. ref. val. 4	5																																																						
1	0	1	5	Fix. ref. val. 5	6																																																						
1	1	0	6	Fix. ref. val.t 6	7																																																						
1	1	1	7	Fix. ref. val. 7	8																																																						
E61	Additional ref. value: Current additional reference value to be added to the reference value being used. Can come from AE2 (F20 =1) or the fieldbus. See block circuit diagram in chap. 19.																																																										
E62	Actual M-max: Currently effective M-Max as a minimum from M-Max 1 (C03), M-Max 2 (C04), and the torque resulting from the level on AE2, if the AE2 function is parameterized for torque limit (F20 =2) or power limit (F20 =3) or is from the fieldbus.																																																										
E63	PID-controller limit: Only if G00 =1 (i.e., PID controller is active). 0: inactive; 1: active; The PID controller output is limited to G04 or G05 .																																																										
E64	Brake: 24 V voltage to brake control is output on plug connector X13. See also F08 (brake). 0: closed; 1: open;																																																										
E65	PID control deviation: Difference of analog input 2 signal after smoothing, offset and factor and E121 PID reference.																																																										
E71	AE1 scaled: AE1 signal after offset and factor. E71 = (E10 + F26) * F27. Cf. block circuit diagram in chap. 19.																																																										
E72	AE2 scaled: AE2 signal after smoothing, offset and factor. E72 = (E11 + F21) * F22.																																																										
E73	AE2 scaled 2: AE2 signal after smoothing, offset and factor as well as PID controller and offset 2. E72 = (PID ((E11 + F21) * F22)) + F24. Cf. block circuit diagram in chap. 19.																																																										
E80	Operating condition: Indicates the current operating state as shown by the operational display. Cf. chapter 16 (Operating States). Useful for fieldbus polling or serial remote control.																																																										
E81	Event level: Indicates whether a current event is present. The type of event is indicated in E82 . Useful for fieldbus polling or serial remote control. 0: inactive; No event is present. 1: message; 2: warning; 3: fault;																																																										
E82	Event name: Indicates the current event/fault. Cf. table in chapter 17. Useful for fieldbus polling or serial remote control.																																																										
E83	Warning time: The time remaining until the fault is triggered is indicated for the active warnings. This time can be changed via FDS Tool. Useful for fieldbus polling or serial remote control.																																																										
E84	Active parameter set: Indicates the current parameter record. Cf. chapter 9.4. Useful for fieldbus polling or serial remote control. 1: parameter set 1; 2: parameter set 2;																																																										
E100...	Parameters E100 and above are used to control and parameterize the inverters by fieldbus. For details, see the documentation of your fieldbus system.																																																										

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90**≠1
- Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:*extended* or **A10**=2:*service*.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

F.. Control Interface		E
Para. No.	Description	
F00	<p>BA2-function: Functions of binary output 2 (X1.17). <i>1: inactive;</i> 2: standstill; Output active when speed 0 rpm \pmC40 is reached. 3: reference value-reached; When C60=1 (speed mode): output is active when speed reference value is within \pmC40. When C60=2 (position mode), <i>refVal-reached</i> means "in position." The signal appears when reference value specification is concluded (i.e., end of ramp) and the actual position is located within target window \pmI22. The signal is not withdrawn until the next start command. When enable-off occurs, "RefVal-reached" is reset when window I22 is exited or I21 (following error) is exceeded. "RefVal-reached" then remains low. This function cannot be used with process block changes via chaining "no stop" (J17=2). 4: torque-limit; Output active when the active torque limit is reached. See E62. 5: warning; Output active when a warning occurs. 6: operation range; Output active when the defined operational range (C41 to C46) is exited. 7: active parameter set; Only works when F00=7 is parameterized in both parameter records. BA2 inactive = parameter record 1, BA2 active = parameter record 2. The signal arrives <u>before</u> the new parameter record takes effect and can be used, for example, for contactor control with a two-motor drive. Cf. chap. 9.4. 8: electronic cam 1; Only applicable when C60=2 (position mode). Signal appears when the actual position is located between the limits I60 and I61. Useful for starting actions on other drives or modules. 9: following error; Only applicable when C60=2. Maximum following error I21 was exceeded. The reaction to a following error (e.g., fault, warning, and so on) can be parameterized via FDS Tool. 10: posi.active; Only applicable when C60=2. Signal only appears when positioning control is in the basic status "17:posi.active" (i.e., no process block and no chaining being processed). This can be used to signal the end of a chaining sequence, for example. 11: PID-controller limit; Signals restriction of the output of the PID controller to the value G04. 12: synchron difference; Signals that the maximum synchronous angle difference G24 has been exceeded. 13: referenced; Only if C60=2 (position control). Output is high while the drive is being referenced (i.e., reference point traversing has been successfully concluded). 14: clockwise; Speed n>0. For zero crossing, hysteresis with C40. 15: fault; A fault has occurred. 16: inhibited; See "12:inhibited" mode in chap. 16. 17: BE1; Route binary input to binary output. In addition to galvanic isolation, also used to read binary inputs via ASi bus. 18: BE2; Cf. selection "17:BE1." 19: Switch-memory 1; Output switch memory S1. Each of the "posi switching points" defined in Group N.. can be used to control 3 switch memories (S1, S2 and S3) simultaneously. 20: Switch-memory 2; Output switch memory S2. 21: Switch-memory 3; Output switch memory S3. 22: ready for reference value; The drive is powered. Magnetization is established. Reference value can be specified. 23: reference value-ackn.0; In position rmode: When no <i>posi.start</i>, <i>posi.step</i> or <i>posi.next</i> signal is queued, the <i>RV-select</i> signals are output inverted (monitoring with wire break detection). Otherwise active process block I82 is output. See time diagram in chap. 10.3. 24: reference value-ackn.1; See "23:reference value-ackn.0." 25: reference value-ackn.2; See "23:reference value-ackn.0." 26: reference value-ackn.3; See "23:reference value-ackn.0." 27: reference value-ackn.4; See "23:reference value-ackn.0." 28: BE3; Cf. selection "17:BE1." 29: BE4; 30: BE5; 31: BE6; 32: parameters active; Low signal means internal parameter conversions not completed. Useful for the handshake with a higher level controller when converting parameter records, and similar.</p>	√
F03	<p>BA2 t-on: Causes a delay in switch-on of BA2. Can be combined with all functions of BA2. The related function must be present for at least t-on so that the BA 2 becomes active. <i>Value range in sec: 0 to 5.024</i></p>	√
F04	<p>BA2 t-off: Causes a delay in switch-off of BA2. Can be combined with all functions of BA2. <i>Value range in sec: 0 to 5.024</i></p>	√



- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when D90≠1
- Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:extended or A10=2:service.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

F.. Control Interface		E
Para. No.	Description	
F05	BA2 invert: Only if F00 >0. Permits the BA2 output to be inverted. Inversion occurs after the function switch-on/switch-off delay (F04/F03). Can be combined with all functions of BA2. <i>Value range:</i> 0 to 1	√
F06	t-brake release: Only if F08 =1 (brake). Defines the amount of time the brake is released. F06 must be selected approximately 30 msec greater than the time t_1 in section M of the STÖBER SMS catalog. When the enable is granted or the halt/quick stop signal is removed, startup is delayed by the time F06 . <i>Value range in sec.:</i> 0 to 0.1 to 5.024	√
F07	t-brake set: Only if F08 =1 (brake). Defines the time the brake is applied. F07 must be selected approximately 30 msec greater than the time t_2 (SMS catalog). When the enable and halt/quick stop are removed, the drive still remains under control for the time F07 . <i>Value range in sec.:</i> 0 to 0.052 to 5.024	√
F08	Brake: Activates the controller of the 24 V brake by the inverter (B+ and B- terminals on the motor plug connector). <i>Q: inactive;</i> The brake is always open (24 V on X13) and is <u>not</u> controlled by the inverter. <i>1: active;</i> The brake is controlled by the inverter. After brake application time F07 expires, the motor is automatically depowered. For example, the brake is applied after the halt or quick-stop signal and when the enable is removed.	√
F10	Relay 1-function: Relay 1 is closed when the inverter is ready for operation (i.e., no malfunction and power-on). The opening of the relay can be controlled by scanning the status of relay 1 via parameter E17 . <i>Q: fault;</i> Relay is open when a fault is queued. <i>1: fault and warning;</i> Relay open when a fault or warning is queued. <i>2: fault and warning and message;</i> Relay open when a fault, warning or message is queued. If auto-reset (A32 =1) is active, the switching of the relay is suppressed until all auto-acknowledgment attempts have been exhausted.	√
F20•	AE2-function: Function of analog input 2 (X1.6 - X1.7). Caution: F20 ≠ F25 must be true. <i>Q: inactive;</i> <i>1: additional reference value;</i> Additional reference value input. Takes effect regardless of which operation input is selected. Is added to the running reference value (A30). 100% control of AE2 is 100 Hz (3000 rpm for 4-pole motor). Can be scaled with F21 and F22 . <i>2: torque-limit;</i> Additional torque limit. 10 V=nominal motor torque. Active torque limit is the minimum from M-Max 1 (C03), M-Max 2 (C04) and the level on analog input 2. <i>3: inactive;</i> <i>4: reference value-factor;</i> The main reference value on AE1 is multiplied by the RV-factor (10 V=100%). Also applicable to relative movements in C60 =2:Position mode. <i>5: override;</i> In positioning mode (C60 =2), the current positioning speed is changed via AE2 during traversing. 0 V = standstill! 10 V = programmed speed if F22 = 100%. During synchronous running (G20 >0), the speed ratio is changed via override. <i>6: posi.offset;</i> Only effective in positioning mode (C60 =2). An offset based on the voltage on AE2 is overlaid on the current reference value position. The ratio of path/voltage is specified with I70 . <i>7: winding diameter;</i> Only effective if G10 =1 (winding operation active). <i>8: inactive;</i> <i>9: n-Max;</i> Limitation of the maximum speed via external voltage. <i>10: reference value;</i> Reference value for speed or torque (AE1 is typically parameterized to "10:reference value"). <i>11: PID-reference;</i> Second input of the PID controller. This can be used to generate the standard deviation from two analog inputs. Cf. block circuit diagram in chap. 11.1. <i>12: winder roller;</i> Only effective for winder software (G10 >0) when the diameter is calculated by integration of the roller deviation (G11 =2). <i>13: synchron offset;</i> Only effective for synchronous running (G20 >0). The current slave position is overlaid with an angle offset corresponding to the voltage on the analog input. The angle/voltage ratio is specified in G38 . Cf. block circuit diagram in chap. 18. <i>14: synchron reference value;</i> Speed precontrol during angle synchronous running (G20 >0) via external analog voltage. The slave can be supplied with the same speed reference value as the master. This minimizes dynamic angle deviation. Cf. block circuit diagram in chap. 18.	√
F21	AE2-offset: An offset on analog input 2 (X1.6 - X1.7) can be corrected. To do this, jumper terminals X1.6 and X1.7. Then observe the AE2 level in parameter E11 , and enter it with the reverse sign in parameter F21 . For example, if parameter E11 indicates 1.3%, F21 must be parameterized to -1.3%. <i>Value range in %:</i> -100 to 0 to 100	√
F22	AE2-gain: The signal present on analog input 2 is added to the AE2 offset (F21) and then multiplied by this factor. Depending on F20 , F22 is scaled as shown below.	√

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90**≠1
- Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:extended or **A10**=2:service.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

F.. Control Interface		E
Para. No.	Description	
	<p>F20= 1 ⇒ 10 V = F22 x C01 n-Max F20= 2 ⇒ 10 V = F22 x nominal motor torque F20= 3 ⇒ 10 V = F22 x nominal motor power F20= 4 ⇒ 10 V = F22 x multiplication with 1.0 F20= 5 ⇒ 10 V = F22 x programmed positioning speed F20= 6 ⇒ 10 V = F22 x path in I70 F20= 7 ⇒ 10 V = F22 x (D-Max – D-Min). See chapter 12.2.1. F20= 8 ⇒ 10 V = F22 x nominal motor voltage F20= 9 ⇒ 10 V = F22 x 100 Hz (3000 rpm)* F20=10 ⇒ 10 V = F22 x 100% input of ref. val. curve F20=11 ⇒ 10 V = F22 x 100% F20=12 ⇒ 10 V = F22 x 100% for G11=2 F20=13 ⇒ 10 V = F22 x G38 F20=14 ⇒ 10 V = F22 x C01 n-Max Example: If F20=1 and F22=50%, the offset is 1500 rpm with 10 V and AE2. Note: Even higher gains can be obtained by connecting the PID controller (G00=1). Value range in %: -400 to 100 to 400</p>	
F23	<p>AE2-lowpass: Smoothing time constant. Useful for setting up control loops via AE2 (with or without a PID controller) to avoid high-frequency oscillation. Caution: High time constants will make the control loop unstable. Value range in msec: 0 to 10000</p>	√
F24	<p>AE2-offset2: An additional offset after multiplication by F22. Used when the reference value is to be multiplied between 95% and 105% via AE2, for example. Value range in %: -400 to 0 to 400</p>	√
F25	<p>AE1-function: See F20 AE2 function. Caution: Parameters F25 and F20 may not be equal! F25≠F20. Value range: 0 to 10 to 14</p>	√
F26	<p>AE1-offset: Cf. F21. Value range in %: -400 to 0 to 400</p>	√
F27	<p>AE1-gain: Cf. F22. Value range in %: -400 to 100 to 400</p>	√
F30	<p>BE-logic: Logical link when several BEs are programmed for the same function. 0: OR; 1: AND;</p>	√
F31•	<p>BE1-function: All binary inputs can be programmed as desired. Selection points 0 to 13 and those greater than 16 are identical for all binary inputs. If the same function is used by several BEs, F30 can be used to program a logical link. Inversion can be performed with F51 to F55 and F70 to F74. 0: inactive; 1: reference value-select 0; Binary coded selection of fixed reference values or process blocks. The result of the reference value selection is indicated in E60. 2: reference value-select 1; See above. 3: reference value-select 2; See above. 4: motorpoti up; If D90=1, two binary inputs can be used to simulate a motor potentiometer. One BE must be programmed as "4:Motorpoti up," and another BE must be programmed as "5:Motorpoti dwn." See also D90. 5: motorpoti down; Same as "4:Motorpoti up." 6: direction of rotation; Negation of the current reference value. 7: additional enable; BE provides the function of an additional enable (i.e., a fault can also be acknowledged via this additional enable). The drive is not enabled unless a high signal is present on the "enable" input (X1.15) and the binary input. 8: halt; With high signal, drive is slowed with the selected deceleration ramp. If F08=1, the brake is then applied. Ramps: Analog RV specification/motor potentiometer: D01; fixed reference values: D12 to D72; Positioning: process block ramp. 9: quick stop; When a rising edge occurs, the drive is slowed with the selected decel-quick ramp (D81). The brake is then applied if F08=1. A brief high pulse (≥4 msec) on the binary input is sufficient to trigger the quick stop. The quick stop cannot be terminated until speed C40 is passed below. Cf. also F38. Caution: Torque limit C04 is always active for quick stop. 10: torque select; Switches between the torque limits M-Max 1 (C03) and M-Max 2 (C04). Low signal = M-Max 1. High signal = M-Max 2.</p>	√

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90=1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

F.. Control Interface		E															
Para. No.	Description																
F31•	<p>11: parameter set-select; A parameter record can only be selected via BE if A41=0. This means that this binary input must be set to 11 in both parameter records. A low signal means that parameter record 1 is selected. A high signal means that parameter record 2 is selected. If A34=0 (autostart = inactive), the selected parameter record is not switched until the enable is removed. Cf. chap. 9.4.</p> <p>12: extern fault; Permits fault messages of the periphery to be evaluated. The inverter evaluates a rising edge on the binary input and assumes "<i>44:ext.fault.</i>" If several binary inputs are programmed for external fault, the rising edge can only be evaluated when a low signal is present on the other binary inputs programmed for "<i>12:ext.fault.</i>"</p> <p>13: fault reset; A fault which is no longer queued can be acknowledged with a rising edge. If several binary inputs are programmed for acknowledgment, the rising edge can only be evaluated when a low signal is present on the other binary inputs programmed with "<i>13:faultReset.</i>"</p> <p>14: Encoder signal B; Signal B of the incremental encoder (HTL) connected to BE1. This incremental encoder can be used as the master for the "electronic gear" function, for example.</p> <p>15: stepMot.sign; Sign (direction) for a stepper motor simulation. The direction and frequency are specified on BE1 and BE2. The "electr. gear" function ensures that pulse processing is synchronous with speed or angle.</p> <p>16: posi.step; Starts a movement without interrupting the positioning procedure in progress. (-> I40) Primarily used for manual next-block procedures with process-block chaining. Cf. J17=0 and J01.</p> <p>17: tip +; Manual traversing in the positive direction (tipping). HALT (selection 8) must be active. For manual speed with <i>posi</i>, see I12. When synchronous running is active (G20>0), TIP+ or TIP- is used to add the current speed RV to the movement of the slave (angle offset). Otherwise no meaning in speed mode.</p> <p>18: tip -; Manual traversing in the negative direction.</p> <p>19: posi.start; Starts a movement. Terminates any positioning procedure in progress, and proceeds to the new destination (i.e., changing destination on the fly). Process block selection via BEs (RV-select) or J02.</p> <p>20: posi.next; If the process blocks are chained, the running block is interrupted, and a jump is made to the next block. <i>Important:</i> A braking path may be defined there, for example. Evaluation of <i>posi.next</i> must be programmed specifically to the process blocks. Cf. J17=3:posi.next. Otherwise the drive will not react to <i>posi.next</i>! If <i>posi.next</i> is parameterized to BE1, the signal is recorded without a time delay (i.e., extremely high repetition accuracy).</p> <p>21: stop +; Limit switch at the positive end of the traversing area. In position mode, the limit switch causes a fault.</p> <p>22: stop -; Limit switch at the negative end of the traversing area. In speed mode, the direction of rotation is disabled.</p> <p>23: reference input; Input for reference switch (I30=0).</p> <p>24: start reference; Change in edge from low to high starts reference point traversing. See also I37=0.</p> <p>25: teach-in; With a rising edge, the target position of the currently selected process block is overwritten with the present actual position and stored in non-volatile memory. See also J04.</p> <p>26: disable PID-controller; PID controller on AE2 is disabled and the integrator is reset. Cf. chap. 12.1.</p> <p>27: synchron free-run; The reference value for synchronous running is disconnected. The drive can be moved as desired via analog input AE1, for example. Speed adjustment is performed on the current reference value ramp (e.g., D00).</p> <p>28: synchron reset; The angle deviation of synchronous-run control is reset. Cf. chap. 18.</p> <p>29: set initial winding diameter;</p> <p>30: RV-select 3; Binary-coded process block selection (5 bits = 1 to 32). Only for Posi. See also 1:RV-select0 to 3:RV-select2.</p> <p>31: RV-select 4; Same as 30 but for Posi.</p> <p>32: brake release; Manual brake control via a BE (higher priority than the internal brake function).</p>																
F32•	<p>BE2-function: 0 to 13 and greater than 16. See F31.</p> <p>14: StepMot.sign; Frequency (impulses) for a stepper motor simulation. See also F31=15.</p> <p>15: Encoder signal A: Signal A of the incremental encoder (HTL) connected to BE2. <i>Value range:</i> 0 to 6 to 32</p>	√															
F33•	<p>BE3-function: 0 to 13 and greater than 16. See F31. <i>15:inactive</i></p> <p>14:ccw V3.2; By programming F33=14 and F34=14, the direction of rotation of inverters can be simulated with software 3.2.</p> <table border="1"> <thead> <tr> <th>BE3</th> <th>BE4</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Quick stop (if F38 not 0) or halt (F38=0).</td> </tr> <tr> <td>0</td> <td>1</td> <td>Clockwise direction of rotation</td> </tr> <tr> <td>1</td> <td>0</td> <td>Counter-clockwise direction of rotation</td> </tr> <tr> <td>1</td> <td>1</td> <td>Halt</td> </tr> </tbody> </table> <p><i>Value range:</i> 0 to 9 to 32</p>	BE3	BE4	Command	0	0	Quick stop (if F38 not 0) or halt (F38=0).	0	1	Clockwise direction of rotation	1	0	Counter-clockwise direction of rotation	1	1	Halt	√
BE3	BE4	Command															
0	0	Quick stop (if F38 not 0) or halt (F38=0).															
0	1	Clockwise direction of rotation															
1	0	Counter-clockwise direction of rotation															
1	1	Halt															

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15. 2) Only available when **D90=1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

F.. Control Interface		E
Para. No.	Description	
F34•	BE4-function: 0 to 13 and greater than 16. See F31 , 14:cw V3.2 (see F33), 15:inactive. Value range: 0 to 32	√
F35•	BE5-function: Additional input only available with option board <i>SEA-4000</i> . Selection via F31 : BE1 function (exception: selection values 14 and 15 are not available here). Value range: 0 to 32	√
F36•	BE-increments: When an incremental encoder is used on BE1 and BE2, the number of increments per revolution must be entered here. When external encoders (i.e., not on the motor) are used, remember F49 . Value range in I/R: 30 to 1024 to 4096	√
F38	Quick stop: Only if C60 ≠2 (mode ≠ position). F38 controls the automatic triggering of quick stop under certain operating conditions (brake on quick stop ramp D81). <i>0: inactive;</i> Quick stop can only be triggered by the BE function "9:Quick stop." 1: enable and clockwise/counter-clockwise; Important for use of two direction-of-rotation inputs (i.e., clockwise and counterclockwise) on BE1 and BE2. Quick stop is triggered when BE1 is low and BE2 is low or when the enable is removed (also reference value enable D07 or additional enable via BE). 2: fault and enable; In addition to the BE function "9:Quick stop," removal of the enable and "non-dangerous" faults (e.g., "46:Low voltage") causes the quick stop. During positioning (C60 =2), quick stop is always triggered with F38 =2.	√
F40	Analog-output1-function: Functions of analog output X1.8. A voltage of ±10 V is available on the terminals. The resolution is 19.5 mV, and the scanning time is 4 msec. <i>0: inactive;</i> 1: <i>E00 I-motor;</i> Indication of motor vector current, 10 V = nominal inverter current, unipolar. 2: <i>E01 P-motor;</i> Indication of motor active power, 10 V = nominal motor power (B11), bipolar. 3: <i>E02 M-motor;</i> Indication of motor torque, 10 V = nominal motor torque, bipolar. 4: <i>E08 n-motor;</i> Indication of motor speed, 10 V = n-max (C01), bipolar. 5: <i>G19 D-actual;</i> Indication of the diameter (winder), 10 V = Dmax (G13). 6: <i>winder actual tension;</i> Output of current winder tension. F-tension = (M-act./M0 x (D-max/D-act.) 100%. 7: +10V; Fixed value (e.g., for powering a potentiometer). 8: -10V; Fixed value (e.g., for powering a potentiometer). 9: <i>winder tension setpoint;</i> Tension reference value for winding at torque limit (G10 =2). 10: <i>motor potent. value;</i> 10 V = n-Max (C01), unipolar. 11: <i>E07 n-post-ramp;</i> 10 V = n-Max (C01), bipolar.	√
F41	Analog-output1-offset: Offset of analog output X1.8. Value range in %: -400 to 0 to 400	√
F42	Analog-output1-gain: The raw value specified via F40 is offset with F41 and multiplied by factor F42 . Example: If F40 =1 and F42 =50%, then 5 V on the analog output = nominal inverter current. Value range in %: -400 to 100 to 400	√
F43	Analog-output1-absolute: An absolute value (amount) is generated for the output signal. <i>0: inactive;</i> 1: <i>active;</i>	√
F45	Analog-output2-function: Function of analog output X1.9. For selection, see F40 . Value range: 0 to 1 to 11	√
F46	Analog-output2-offset: Offset for output X1.9. Cf. F41 . Value range in %: -400 to 0 to 400	√
F47	Analog-output2-gain: Gain for output X1.9. Cf. F42 . Value range in %: -400 to 50 to 400	√
F49	BE-gear ratio: Conversion of an external incremental encoder to the motor shaft. The following must apply: F49 = number of motor revolutions/number of encoder revolutions. If this formula results in values over 32.767, the number of encoder increments in F36 must be divided by a suitable factor (e.g., 2). The result of the above formula is then also divided and entered in F49 . See also chapter 10.11.2. Value range: 0 to 1 to 32.767	√
F51 ... F55•	BE1-invert to BE5-invert <i>0: inactive;</i> No inversion. 1: <i>active;</i> Input is inverted. Useful for the HALT signal or limit switch, for example.	√
F60•	BE6-function: Additional inputs only available with option board <i>SEA-4000</i> . Selection via F31 : BE1 function (exception: selection values 14 and 15 are not available here). Value range: 0 to 32	√
F61•	BE7-function: See F60 . Value range: 0 to 32	√

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90**≠1

Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:*extended* or **A10**=2:*service*.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

F.. Control Interface		E
<i>Para. No.</i>	<i>Description</i>	
F62•	BE8-function: See F60. <i>Value range:</i> 0 to 32	√
F63•	BE9-function: See F60. <i>Value range:</i> 0 to 32	√
F64•	BE10-function: See F60. <i>Value range:</i> 0 to 32	√
F65•	BE11-function: See F60. <i>Value range:</i> 0 to 32	√
F66•	BE12-function: See F60. <i>Value range:</i> 0 to 32	√
F67•	BE13-function: See F60. <i>Value range:</i> 0 to 32	√
F68•	BE14-function: See F60. <i>Value range:</i> 0 to 32	√
F70... F78•	BE6-invert to BE14-invert: Cf. F51 to F55 (only available with option boards). <i>0:</i> inactive; no inversion. <i>1:</i> active; Input is inverted.	√
F80	BA1-function: Function of binary output 1. <i>1:</i> inactive; <i>2 to 32:</i> Selection values in acc. w. parameter F00 (BA2-function).	√
F81	BA2-function: Selection values in acc. w. parameter F00. <i>Value range:</i> 0 to to 1 to 32	√
F82	BA3-function: Selection values in acc. w. parameter F00. Only available with option boards. <i>Value range:</i> 1 to 32	√
F83	BA4-function: Selection values in acc. w. parameter F00. <i>Value range:</i> 1 to 32	√
F84	BA5-function: Selection values in acc. w. parameter F00. <i>Value range:</i> 1 to 32	√
F85	BA6-function: Selection values in acc. w. parameter F00. <i>Value range:</i> 1 to 32	√
F86	BA7-function: Selection values in acc. w. parameter F00. <i>Value range:</i> 1 to 32	√
G.. Technology		E
<i>Para. No.</i>	<i>Description</i>	
G00•	PID-controller: Activates the PID controller on input AE2. Cf. chapter 12.1. <i>0:</i> inactive; <i>1:</i> active;	√
G01	PID-controller Kp: Only if G00=1 (i.e., PID controller active). Loop gain. The total gain of the control loop is also affected by F22 (AE2 gain) in addition to G01. Cf. block circuit diagram in chap. 12.1. <i>Value range:</i> 0 to 0.3 to 100	√
G02	PID-controller Ki: Only if G00=1 (i.e., PID controller active). Gain of I share in 1/sec. Example: If G02=0.2 x 1/sec, then a 20% higher constant input signal is integrated within one second. <i>Value range in 1/sec:</i> 0 to 10	√
G03	PID-controller Kd: Only if G00=1 (i.e., PID controller active). Gain of D share in msec. <i>Value range in msec:</i> 0 to 1000	√
G04	PID-controller limit: Only if G00=1 (i.e., PID controller active). Adjuster-variable limit. For scaling, see F22. Asymmetric limits can be specified with G04 and G05 (e.g., from -10% to +30%). Upper and lower limit values are automatically (internally) sorted correctly. <i>Value range in %:</i> -400 to 400	√
G05	PID-controller limit2: See G04. <i>Value range in %:</i> -400 to 400	√
G06	PID-controller Kp2: Pure proportional gain of the PID controller. Effective parallel to I and D portion. <i>Value range:</i> 0 to 1 to 10	√
G10•	Winding operation: Activates the winding functions (speed reduction based on diameter). <i>0:</i> inactive; <i>1:</i> n mode; Speed adjustment in accordance with n~1/D. No effect on torque limit M-Max. <i>2:</i> M-Max mode; Maximum torque is reduced based on D-Act/D-Max.	√

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when D90≠1
- Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:extended or A10=2:service.
- E** Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

G.. Technology		E
Para. No.	Description	
G11	Diameter: Only if G10 ≠0 (winding operation active). Specifies the type of diameter definition. <i>Q:</i> <i>AE-measurement</i> ; Diameter sensor 0 to 10 V is connected to AE2. <i>1:</i> <i>n-line/n-motor</i> ; For traction or compensating roller controllers. The diameter is calculated from the ratio of control speed to motor speed. The control speed (i.e., speed reference value) always refers to an empty reel (i.e., the smallest diameter). <i>2:</i> <i>roller</i> ; The diameter is calculated with an overtravel ramp based on E122 (from fieldbus or via analog input function "12:winder roller"). If E122 > 5%, G19 is increased by ramp G16 . If E122 < -5%, G19 is decreased by ramp G16 . Otherwise G19 remains constant.	√
G12	Min. winding diameter: Only if G10 ≠0 (winding operation active). Diameter of an empty reel. <i>Value range in mm:</i> 10 to 3000	√
G13	Max. winding diameter: Only if G10 ≠0 (winding operation active). Diameter of a full reel. <i>Value range in mm:</i> 10 to 100 to 3000	√
G14	Begin. winding diameter: Only if G10 ≠0 (winding operation active). Initial diameter. Must be set via a binary input with the function "29:winder.setD-ini" (F31 to F35). <i>Value range in mm:</i> 10 to 3000	√
G15	Overdrive ref. value: Only if G10 ≠0 (winding operation active). G15 is added to the control reference value while winding at the torque limit (G10 =2) so that M-limit is triggered and the winding material remains taunt. <i>Value range in rpm:</i> -6000 to 0 to 6000	√
G16	Diam.calculator ramp: Only when G10 >0. Integration speed of the diameter calculation. G11 =0: no function G11 =1: limitation of the integration speed for G19 G11 =2: ramp with which the diameter is changed when -5% < E122 < +5%. <i>Value range in mm/sec:</i> 0 to 10 to 100	√
G17	Tension reduction: Only when G10 >0. Reduction of tension as diameter increases. If min. diameter D-Min: winding with 100% tension. Up to D-Max: tension reduced linearly up to (100% - G17). <i>Value range in %:</i> 0 to 100	√
G19	Actual. winding diameter: Only if G10 ≠0 (winding operation active). Indication of the current diameter.	
G20•	Electronic gear: Only when C60 =1: <i>speed</i> . Activates the "electronic gear/synchronous running" function (chap. 11). See block circuit diagram in chap. 18. <i>Q:</i> <i>inactive</i> ; <i>1:</i> <i>speed synchron run</i> ; G24 limits the effect of the angle controllers. Cf. chap. 11.6. <i>2:</i> <i>angle synchron run</i> <i>3:</i> <i>angle + save</i> ; Same as G20 =2. However, each time enable-off occurs, the angle deviation is stored non-volatily and thus remains available after power off and on. See also G25 .	√
G21	Speed master: Only if G20 >0 (electronic gear active). The slave speed is calculated from nSlave= G22 / G21 x nMaster. The increments of the incremental encoders are specified with F36 and H22 . If G21 =1 and G22 =2, the slave is twice as fast as the master. We recommend selecting the number of increments for the master encoder (in acc. w. G27) as a power of 2 (e.g., 1024). <i>Value range:</i> 1 to 2147483647	√
G22	Speed slave: Only if G20 >0 (electronic gear active). See G21 . At a speed ratio of 1:1, G21 = G22 =1 must be parameterized. The direction of rotation of the slave can be changed with D92 . <i>Value range:</i> 1 to 2147483647	√
G23	Kp synchron: Only if G20 >0 (electronic gear active). Gain of the angle controller in 1/sec. Typical values are 10 to 60. G23 =0 activates speed synchronous running. The slave then no longer attempts to catch up with the master (e.g., after a blockage). Instead, the mathematically precise speed ratio is only ensured within the window ± G24 . When G23 =0 and G24 =0, the master encoder is only used as a speed reference value, and the ratio set in G22 / G21 is not precisely maintained mathematically. Cf. chapter 11.6. <i>Value range in 1/sec:</i> 0 to 30 to 100	√
G24	Max. synchron. difference: Only if G20 >0 (electronic gear active). Maximum angle of deviation between master and slave (following error). When this value is exceeded, a signal is generated on the output (cf. F00 or F80 =12: <i>synch.diff.</i>), but no fault is triggered. This can be performed with external wiring and the input function "12:ext.fault" (F31 to F35). In G20 =1: <i>speed sync.</i> mode, G24 limits the effect of the angle controller. This smooths the transition between pure speed synchronous and angle synchronous running. <i>Value range in °:</i> 0 to 3600 to 30000	√

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.


1) See result table in chap 15.

2) Only available when **D90**≠1

Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1: *extended* or **A10**=2: *service*.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

G.. Technology		E	
Para. No.	Description		
G25	<p>Synchron reset: Only if G20>0. Defines conditions for resetting the current synchronous deviation.</p> <p>0: with BE; Reset only possible with BE function "28:SyncReset" (always possible).</p> <p>1: enable & BE; Reset also with removal of the enable as well as with halt and quick stop.</p> <p>2: free run & BE; Reset only with BE functions "27:syncFreeRun" and "28:SyncReset."</p> <p>3: enable & free run & BE; All methods above will cause a reset.</p> <p>The synchronous deviation is always set to zero when the device is turned on. (Exception: G20=3. Reset is only performed when the stored deviation exceeds 5°).</p>	√	
G26	<p>n-correction-Max: Only if G20>0 (electronic gear active). G26 limits the output of the angle controller. Important when large angle deviations must be reduced (e.g., when the free-run function is used).</p> <p>Value range in rpm: 0 to 3000 to 6000</p>	√	
G27	<p>Synchron encoder: Only when G20>0. Signals of the master arrive over this interface.</p> <p>0: BE-encoder; Master signals are connected to binary inputs.</p> <p>1: X20; Master signals arrive over plug connector X20.</p> <p>2: X41;</p>	√	
G28	<p>n-Master: Only when G20>0. For monitoring during commissioning. Speed of reference value encoder as per G27.</p> <p>Value range in rpm: ± 6000</p>		
G29	<p>Synchron difference: Only if G20>0 (electronic gear active). Indication of the current synchronous deviation in degrees as related to the slave motor. n-controller $K_i > 0$ is required for a synchronous deviation near 0.</p>		
G30	<p>Speed feed forward: Speed precontrol for synchronous running. When G30=100%, no following error is used when speed is constant (synchronous deviation is zero). With dynamic movements, G30 must be reduced (50 to 80%). Otherwise the slave will overswing.</p> <p>Value range in %: 0 to 80 to 100</p>	√	
G31	<p>Reference direction: Only if G20>0. Starting direction to look for the reference point. Referencing searches for a reference cam. Cf. I30=0:Ref.input in positioning mode and the examples in chap. 10.6. Synchronous deviation is reset at the reference position. Other ways of resetting the synchronous deviation include the BE signal "28:Syncron Reset" or automatically with parameter G25.</p> <p>0: positive;</p> <p>1: negative;</p>	√	
G32	<p>Reference speed fast: Only if G20>0. Speed for first phase of referencing (rough traversing).</p> <p>Value range in rpm: 0 to 1000 to 6000</p>	√	
G33	<p>Reference speed slow: Only if G20>0. Speed for final phase of referencing.</p> <p>Value range in rpm: 0 to 300 to 6000</p>	√	
G35	<p>Ref.encoder signal 0: Only if G20>0. Referencing to zero pulse of the motor encoder. Do not use for continuous mode with an odd-number gear ratio.</p> <p>0: inactive;</p> <p>1: Motor-encoder;</p>	√	
G38	<p>Synchronous offset: Only if G20>0. An offset distance based on the voltage on an analog input can be added to the current slave position. 10 V corresponds to the angle entered in G38.</p> <p>Value range in °: -214748364.8 to 0 to 214748364.7</p>	√	
G40	<p>Static friction torque: Only if G10>0. Offset of the static friction (i.e., the friction (coulomb) independent of the speed). Value is converted to the motor shaft.</p> <p>Value range in Nm: 0 to 327.67</p>	√	
G41	<p>Dynamic friction torque: Only if G10>0. Offset of the speed-proportional friction. Value converted to the motor shaft at 1000 rpm.</p> <p>Value range in Nm/1000 rpm: 0 to 327.67</p>		√
G42	<p>T-dyn lowpass: Only if G10>0. Torque for acceleration/deceleration can be offset dynamically. The load/motor inertia ratio with a full reel (D-Max) must be entered for this in parameter C30. The acceleration portion to be offset is obtained by differentiation of the speed. G42 specifies the related smoothing time constant.</p> <p>Value range in msec: 0 to 50 to 10000</p>	√	

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90**≠1
- Parameters which are included in the *normal* menu scope (**A10**=0). For other parameters, select **A10**=1:extended or **A10**=2:service.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

H.. Encoder		E
Para. No.	Description	
H20•	X20-function: See also description in chap. 5.4. <i>0: inactive;</i> <i>1: encoder simulation;</i> Encoder simulation (TTL) output for a host controller. H21 specifies the number of pulses. <i>2: encoder In;</i> Connection of an incremental encoder with ROD signals. Wire-break monitoring active. <i>3: stepmotor In;</i> Stepper motor input function. Track A is the sign (low = positive, high = negative). Track B is the counting frequency (chapters 11.2 and 14.1). <i>4: SSI simulation;</i> Simulation of a multi-turn SSI encoder. Useful for an absolute-value encoder on X41 for motor control. The host controller can scan the absolute position in SSI format on X20. <i>5: SSI master;</i> Connection of an SSI encoder (absolute value encoder). Note: SSI encoders can be used as external encoders for POSI. The absolute position for POSI can only be read from the encoder when the device starts up. If H20 is reparameterized and H20 was or is now H20=5 , this triggers fault "37:n-feedback" which cannot be acknowledged. Save values with A00 , and turn basic device off/on.	√
H21	Encodersim. increments: Only if H20=1 . Specifies the number of pulses per motor revolution. <i>0: 256;</i> <i>1: 512;</i> <i>2: 1024;</i> <i>3: 2048;</i> <i>4: 4096;</i>	√
H22	X20-increments: Number of increments for incremental encoders. With SSI encoders, the range of H23 (X20 gear ratio) can be expanded with H22 . See chap. 10.11. H22=1024 is the neutral setting. <i>Value range in I/R: 30 to 1024 to 4096</i>	√
H23	X20-gear ratio: Conversion of an external incremental encoder to the motor shaft. The following must be true: H23 = number of motor revolutions / number of encoder revolutions. If this formula results in values greater than 32.767, the number of encoder increments in H22 must be divided by a suitable factor (e.g., 2). The result of the above formula is then also divided and entered in H23 . See also chapters 9.6 and 10.11.2. With SSI encoders, the gear ratio is expanded by setting H22 to a value other than 1024. <i>Value range: 0 to 1 to 32.767</i>	√
H24	X20-zero-Pos.: Zero pulse shift during encoder simulation. <i>Value range in °: 0 to 360</i>	√
H31	Resolver poles: Number of poles of the connected resolver. Typical values are 2 (standard for STÖBER) and 6. <i>Value range: 2 to 16</i>	√
H32	Commutation-offset: Shifts the resolver zero position in comparison to the motor. Since STÖBER motors are set to H32=0 at the plant and tested, it is usually never necessary to change H32 . If the B40 phase test results in an H32 value > 0, this probably indicates a problem with the plug connectors or wiring. <i>Value range in °: 0 to 360</i>	√
H40	X41-function: See description in chapters 5.5 and 5.6. <i>0: inactive;</i> <i>1: SinCos in;</i> <i>2: encoder in;</i> <i>3: stepMot in;</i>	√
H41	X41-increments: The value is automatically determined with sin/cos encoders with EnDat® or Hiperface® interface. <i>Value range in I/R: 30 to 1024 to 4096</i>	√
H42	X41-gear ratio: See H23 . <i>Value range: 0 to 1 to 32.767</i>	√
H60	SSI-invert: Reverse sign for external SSI encoders. Wrong sign → unstable control loops. <i>0: inactive;</i> Clockwise revolution of motor shaft while facing the shaft (A side) counts as positive. <i>1: active;</i> Clockwise revolution of motor shaft counts as negative.	√
H61	SSI-coding: Entry as per encoder data sheet. <i>0: gray;</i> <i>1: binary;</i>	√
H62	SSI-data bits: Entry as per encoder data sheet. <i>Value range: 24 to 25</i>	√

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90=1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

I.. Posi. Machine		E
Para. No.	Description	
I09	Measurement unit: Only if I05=0 (user unit). Indication of the unit of measure defined by the user with FDS Tool. Up to 4 characters can be used.	
I10	Max. speed: Unit/sec. Works simultaneously with the maximum motor speed in C01 . The actual speed limit corresponds to the lower of the two parameters. When a higher feed speed is specified, the value is limited to I10 or C01 without causing the following error. <i>Value range in I05/sec: 0 to 10 to 31 bits</i>	
I11	Max. acceleration: Units/sec ² . With quick stop, the drive decelerates with I11 . The acceleration for manual (I12) and reference point traversing (I33 , chap. 10.6) is also derived from I11 (i.e., each is ½ of I11). <i>Value range in I05/sec²: 0 to 10 to 31 bits</i>	
I12	Tip speed: Units/sec. Speed during manual operation (J03). As with all speeds, it can be changed via analog input (F20=5:Override). Acceleration during manual operation is ½ of I11 . <i>Value range in I05/sec: 0 to 180 to 31 bits</i>	
I15	Accel-override: Permits modification of the set ramps via AE2 (F20=5:Override). <i>0: inactive;</i> Ramps are not changed by override. Standard setting. <i>1: active;</i> Ramps are changed by override. Only recommended in exceptional cases (e.g., process block chaining without stop to generate simple n(x) speed profiles. Caution: The override value affects acceleration to the power of two. Danger of overload when override > 100%. During ramps, changes in accel-override are only adjusted slowly in a background task.	
I16	S-ramp: Reverse limitation through square sinus ramp. The generated acceleration profile is smoothed with the specified time constant. Positioning takes a little longer. <i>Value range in msec: 0 to 32767</i>	
I19	ENA-interrupting: In the default setting, removal of the enable causes the position controller to be reset (status "17:posi.active"). Particularly during continuous positioning, it is important that interrupted process blocks can be concluded after emergency off or similar. I19=1 offers particularly simple process block interruption. See also chap. 10.10. <i>0: inactive;</i> Enable-off resets the positioning controller. <i>1: active;</i> Enable-off while process block is running causes status "23:interrupted." The interrupted process block is completed with <i>Posi.step</i> .	
I20	Kv-factor: Gain of position controller (only P characteristic) with unit of 1/sec. The Kv factor is also known as the speed gain. In actual practice, the Kv factor is sometimes specified with the unit m/min/mm which is exactly 0.06 x I20 . See also block circuit diagram in chap. 10.7. <i>Value range in 1/sec: 0 to 30 to 100</i>	
I21	Max. following error: The output function (F00=9:follow.error) is activated when the following error defined in I21 is exceeded. FDS Tool can then be used to specify the desired reaction to the exceeded following error as a fault (default setting), warning or message. <i>Value range in I05: 0 to 90 to 31 bits</i>	
I22	Target window: Window for the output signal "reference value reached" (F00=3:RefVal-reached). I22 must be greater than I23! . <i>Value range in I05: 0 to 5 to 31 bits</i>	
I23	Dead band pos. control. "Dead zone" of the position controller. Useful to prevent idle-state oscillation particularly when an external position encoder is used and there is reversal play in the mechanics. Cf. chap. 10.7. Caution: I23 Dead band must be smaller than target window I22! <i>Value range in I05: 0 to 31 bits</i>	
I25	Speed feed forward: Switches the calculated speed profile to the output of the position controller (chap. 10.7). If there is overswinging in the destination position, I25 and C32 must be reduced. <i>Value range in %: 0 to 80 to 100</i>	
I30	Reference mode: For details on reference point traversing, see chapter 10.6. 0: reference input; When searching for the reference point, the reference input is the determining factor (i.e., the BE function "23:Reference input" must be parameterized). 1: stop input; The function of the reference input is fully covered by the stop switch (i.e., BE function "21:Stop +" or "22:Stop -" must be parameterized). When the starting direction is positive (I31=0), positive "Stop +" is required. Triggering the wrong stop switch causes a fault. 2: encoder signal 0; Only of interest for drives without a gearbox. Used to align the motor shaft to a defined position. 3: define home; BE function "24:Start ref." or J05 → 1 immediately sets the actual position to I34 without performing an additional movement. For example, this can be used to set the actual position to zero at all times (enable must be active).	

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when **D90≠1**

Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

I.. Posi. Machine		E
Para. No.	Description	
	4: posi.start; Each <i>posi.start</i> signal causes reference position I34 to be set. This can be used, for example, to indicate the actual distance as the current position with relative positioning and offset of the traversing path via analog signal (" <i>1:additional reference value</i> " and " <i>4:reference value-factor</i> ").	
I31	Reference direction: Initial direction to take when searching for the reference point. Cf. chapter 10.6. <i>0: positive;</i> <i>1: negative;</i>	
I32	Reference speed fast: Speed for the first phase of reference point traversing (i.e., determining the rough area). Omitted when only one direction of rotation (I04) is permitted. Only the slow speed (I33) is then used for this type of reference point traversing. <i>Value range in I05/sec: 0 to 90 to 31 bits</i>	
I33	Reference speed slow: Speed for the final phase of reference point traversing. Switching between I32 and I33 is automatic. Cf. figures in chapter 10.6. The acceleration during reference point traversing is I11/2 . <i>Value range in I05/sec: 0 to 4,5 to 31 bits</i>	
I34	Reference position: Value which is loaded to the reference point (e.g., provided by the reference switch or the stop switch) as the actual position. The drive stops after reference point traversing. The position is determined by brake ramp I11/2 . Cf. chapter 10.6. <i>Value range in I05: -31 bits to 0 to 31 bits</i>	
I35	Ref.encoder signal 0: Only if I36=0 and I30≠2 . Referencing to zero pulse of an incremental encoder. <i>0: inactive;</i> Zero pulse is not evaluated. Referencing to the edge of the stop or reference switch. Important for continuous axes with transmissions, for example. Also useful when there are not enough binary inputs and demands on accuracy are not high. <i>1: motor encoder;</i> <i>2:posi encoder;</i> In acc. w. parameter I02 (under preparation).	
I36	Continuous reference: Only for continuous axes (I30=0). Used for fully automatic compensation of slip or inexact gear ratio. After the reference points are traversed for the first time, actual position I80 is always overwritten with reference position I34 each time the reference switch is passed over in direction I31 (but only in this direction!). Since the path which is still to be traversed is corrected, the axis is able to perform any number of relative movements in one direction without drifting, even when drives have slip. If the reference switch is connected to BE3, the signal is processed immediately. Remember: When I36=1 , the other edge of the reference switch is evaluated than the one for I36=0 during reference point traversing. Circular length I01 must be as close as possible to the path between two reference signals (e.g., after one belt rotation, the same position must be indicated). Check actual position I80 during a rotation with I36=0 , and adjust I07 if necessary. The distance per rotation I07 must always be rounded to the next higher number to prevent undesired counterclockwise offsets. The reference switch should not be triggered during a deceleration ramp since a negative offset would cause a counterclockwise movement. Important: Target window I22 must be greater than the maximum physical inaccuracy! <i>0: inactive;</i> <i>1: active</i>	
I37	Power-on reference: Automatic reference point traversing after power-on. <i>0: inactive;</i> <i>1: posi.start;</i> After power-on, the inverter assumes operating mode " <i>24:ref.wait.</i> " The first <i>posi.start</i> or <i>posi.step</i> signal starts the reference point traversing procedure. <i>2: automatic;</i> Reference point traversing is started automatically as soon as the enable appears.	
I38	Reference block: Number of the process block (i.e., 1 to 32) which is to be automatically started at the end of reference point traversing. This can be used to put the drive into a defined position after the reference points have been traversed. <i>0: standstill. No automatic start.</i> <i>1 to 32: Number of the process block to be executed.</i>	
I40	Posi.-step memory: Helpful during relative positioning of continuous axes. <i>0: inactive;</i> <i>Posi.step</i> signals during a movement are ignored. <i>1: no stop;</i> <i>Posi.step</i> signals which arrive during a movement cause the current destination position to be changed immediately. The process block specified by the reference block or, if no reference block is defined, the currently selected process block takes over. Example: Two additional <i>posi.step</i> signals arrive during a relative movement of 100 mm. The drive then moves precisely 300 mm without stopping.	
I50	Software-stop -: Only if I00=0 (limited position range). Effective only when axis is referenced. Positioning control rejects traversing jobs outside the software limit switches (message " <i>51:Refused</i> "). Manual-traversing and continuous process blocks are stopped at the software stops. Caution: Software stops do nothing to compensate when the permissible position range is exceeded due to a change on the fly to a process block with slower ramps! <i>Value range in I05: -31 bits to 10000000 to 31 bits</i>	

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90=1**
- Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

I.. Posi. Machine		E
Para. No.	Description	
I51	Software-stop +: Only if I00=0 (limited position range). Effective only when axis is referenced. <i>Value range in I05:</i> -31 bits to 10000000 to 31 bits	
I60	Electronic cam 1 begin: In the positioning area between I60 and I61, the <i>el.cam</i> signal (F00=8) becomes high. "Electronic cam" only functions in the referenced state. Cf. also the related function "operating range" in chapter 9.3. <i>Value range in I05:</i> -31 bits to 0 to 31 bits	
I61	Electronic cam 1 end: See I60. <i>Value range in I05:</i> -31 bits to 100 to 31 bits	
I70	Position-offset: A correction path corresponding to the voltage on AE2 can be added to the current reference value position (F20=6). 10 V corresponds to the path specified in I70. Useful, for example, for creating complicated x(t) profiles which are generated by a PC as voltage. After activation of the inverter (i.e., enable), the current offset value is approached at the manual speed I12. The reference value from AE2 is then supplied without restrictions, and the AE2 low pass can be used for smoothing. <i>Value range in I05:</i> 0 to 31 bits	
I80	Actual position: Read only. Indication of the actual position. <i>Value range in I05:</i> ±31 bits	
I81	Target position: Read only. Indication of the current reference value position. <i>Value range in I05:</i> ±31 bits	
I82	Active process block: Read only. Indication of the currently active block during block processing (traverse, wait) and during standstill at a process block position. The approached process block is indicated in I82 as long as the "RV reached" signal (i.e., in position) is present. When the drive is not in a process block position (e.g., after power on, manual traversing or termination of a movement), I82=0 applies. When I82>0, the signals "23: reference value-ackn.0" to "27: reference value-ackn.4" can indicate the active process block in binary coded format ("000" for process block 1 - i.e., I82=1). Cf. chap. 10.3.	
I83	Selected process block: Read only. Indication of the block selected via binary inputs or J02. This process block would be executed with the <i>posi.start</i> signal. Cf. also chap. 10.3 and F00=23.	
I84	Following error: Read only. Indication of the current position deviation. Cf. I21 and F00=9. <i>Value range in I05:</i> ±31 bits	
I85	In position: Read only. Indication of output signal F00=3: <i>refVal-reached</i> . 0: inactive; Drive moving or destination position not reached. 1: active; See output signal F00=3: <i>refVal-reached</i> and I22 target window.	
I86	Referenced: Read only. Indication of output signal "13: <i>referenced</i> ." For reference point traversing, see chap. 10.6. 0: inactive; Drive not referenced. No absolute positioning possible. 1: active; Drive referenced.	
I87	Electronic cam 1: Read only. Indication of output signal "8: <i>electronic cam 1</i> ." 0: inactive; Current position is outside I60 and I61. 1: active; Current position is within I60 and I61.	
I88	Speed: Read only. Indication of the current reference value of the positioning speed with unit. Cf. chap. 10.7. <i>Value range in I05/sec:</i> ±31 bits	
J.. Posi. Command (Process Blocks)		E
Para. No.	Description	
J00	Posi.start: 0→1. Starts the currently selected process block. The block is selected via binary inputs (<i>RV-select</i> 0 to 2) or J02. Since <i>posi.start</i> interrupts positioning procedures in progress, it has the highest priority. The J00 parameter corresponds to the BE function "19: <i>posi.start</i> ."	
J01	Posi.step: 0→1. With process block chaining, <i>posi.step</i> is used to start the next programmed block if this is not started automatically (e.g., via J17=1: <i>with delay</i>). This is done without regard to the <i>RV-select</i> inputs, for example. In operating state "17: <i>posi.active</i> ," (standstill, no process block being processed), <i>posi.step</i> starts the currently selected process block the same as <i>posi.start</i> (see above). <i>Posi.step</i> never interrupts a running movement (exception: I40=1). Delays between process blocks (J18) are prematurely concluded by <i>posi.step</i> . If a movement is interrupted (operating state "23: <i>interrupt</i> ."), <i>posi.step</i> completes the interrupted process block.	
J02	Process block number: Selection of the process block which can be started at all times with <i>posi.start</i> . 0: external selection via binary inputs and the BE functions F31= <i>RV-select</i> 0 to 4. See also I83. 1 to 32: fixed selection of the process block. <i>RV-select</i> signals are ignored.	
J03	Tip-mode: Manual operation via the device keyboard. See also F31=17 and F31=18. 0: inactive; 1: active; The drive can be positioned with the ◀ and ▶ keys.	

• The power pack must be turned off before these parameters can be changed.

Italics These parameters are sometimes not shown depending on which parameters are set.

1) See result table in chap 15.

2) Only available when D90≠1

Parameters which are included in the *normal* menu scope (A10=0). For other parameters, select A10=1:*extended* or A10=2:*service*.

E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

J.. Posi. Command (Process Blocks)		E
Para. No.	Description	
J04	Teach-in: 0→1 starts the action (i.e., triggered manually). The current actual position is used as the destination of the currently selected process block and stored non-volatilely. Example: Normally, the desired position is approached manually and then accepted with teach-in. See also F31=25 .	
J05	Start reference: 0→1 starts the action (i.e., triggered manually). Reference point traversing can also be started via a binary input or automatically after power-on. See I37 and chapter 10.6 and F31=24 .	
J10	Position: Position specification. The value can also be changed during traversing, but the change does not take effect until the next <i>posi.start</i> command (if internal conversion has been concluded). Cf. F00=32 . <i>Value range in I05:</i> -31 bits to 0 to 31 bits (=2 ³¹ encoder increments after quadruple evaluation)	
J11	Position mode: There are 4 modes. Cf. chapter 10.4. <i>0: relative;</i> <i>1: absolute;</i> <i>2: endless positive;</i> With "continuous" position modes, destination position J10 can be disregarded. <i>3: endless negative;</i>	
J12	Speed: Unit/sec. Caution: If you enter a value greater than the maximum speed I10 in J12 , the actual traveling speed is limited to I10 . <i>Value range in I05/sec:</i> 0 to 1000 to 31 bits	
J13	Accel: Acceleration, unit/sec ² . Caution: If the values J13 and J14 exceed the maximum acceleration I11 , acceleration during movement is limited to I11 . Up to software version 4.5: If the direction of rotation must be changed during a change in process blocks on the fly, the entire reversal procedure is performed with the Accel ramp (J13). <i>Value range in I05/sec²:</i> 0 to 1000 to 31 bits	
J14	Decel: Deceleration, unit/sec ² . <i>Value range in I05/sec²:</i> 0 to 1000 to 31 bits	
J15	Repeat number: Only available if J11=0:relative . If necessary, a relative movement can be repeated several times based on the value J15 . With J17=0 , <i>posi.step</i> is waited for after each partial movement. With J17=1 , the partial movements are run through automatically. Delay J18 is inserted between the movements. J15=0 means no repetition (i.e., one single movement). <i>Value range:</i> 0 to 254	
J16	Next block: Chaining of process blocks. Specification of a process block to which a jump is to be made at the end of the movement or after a <i>posi.next</i> signal. <i>0:</i> stop; No process block chaining. <i>1 to 32:</i> Number of the next process block. Cf. chapter 10.8.	
J17	Next start: Only if J15≠0 or J16≠0 . J17 defines when and how the branch is made to next block J16 . <i>0: posi.step;</i> Continued movement via <i>posi.step</i> function (rising edge). Cf. J01 . <i>1: with delay;</i> Automatic continued movement after delay J18 expires. In contrast to J17=2 , an intermediate stop is also always performed with J18=0 sec. <i>2: no stop;</i> When destination position J10 is reached, the speed is adjusted without stopping (i.e., change in block on the fly without intermediate stop). Drive travels to J10 <u>without braking</u> and then changes to process block J16 . Also useful for generating n(x) speed profiles with support points in up to 8 positions. Cf. I15 , chapter 10.8, example 4. <i>3: Posi.next;</i> The block change is performed on the fly with the <i>posi.next</i> function. If J17≠3 , <i>posi.next</i> has no effect. See also example 3 in chap. 10.8. <i>4: Operation range;</i> The block change is performed on the fly when the operating range (C41 to C46) is exited. Compare example 7 (press/screw) in chapter 10.9. When a block change is performed on the fly without intermediate stop (J17=2, 3, 4), no refVal-reached signal (in position) is generated.	
J18	Delay: Parameter only effective if J15≠0 or J16≠0 and J17=1 . Otherwise not shown. Delay before the repetition of relative movements (J15≠0) or before automatic change to the next record (J17=1:with delay). After expiration of the delay time, movement is automatically resumed. A delay can be terminated (i.e., shortened) with the <i>posi.step</i> signal (rising edge). <i>Value range in sec:</i> 0 to 65.535	

☞ The layout of process block nos. 2 to 8 is identical. Process block no. 2 is located in **J20 - J28**, process block no. 3 in **J30 - J38**, etc.

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90=1**
- Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.
- Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

13. Parameter Description

L.. Posi. Command 2 (Extended Process Block Parameters)		E
Para. No.	Description	
L10	Brake: Definition for process block no. 1. Only if F08=1 . Process block-related brake control (e.g., for lifting systems). After reaching destination position J10 , you can apply the brake. <i>0: inactive;</i> Destination position is held by the motor (i.e., position control). Brake is only applied when enable, halt, quick stop or fault is missing. <i>1: active;</i> After the destination position is reached, the brake is automatically applied. The next start command is delayed by the time F06 (brake release).	
L11	Switch A: Selection of the first switching point for process block no. 1. Up to two switching points ("switch A" and "switch B") can be used in each process block. Each of the four switching points defined in group N.. can be used in various process blocks. Cf. chap. 10.12. <i>0: inactive;</i> <i>1: switch S1;</i> <i>2: switch S2;</i> <i>3: switch S3;</i> <i>4: switch S4;</i>	
L12	Switch B: Selection of the second switching point for process block no. 1. Cf. L11 . <i>Value range: 0 to 4</i>	

☞ The layout of extended process block parameters is identical for all process blocks. Process block no. 1 is located in **L10** to **L12**, process block no. 2 in **L20** to **L22**, and so on.

N.. Posi. Switches		See chap. 10.12 for description.	E
Para. No.	Description		
N10	S1-position: Position of switching point S1. With relative specifications (N11>0), the absolute value is generated internally. <i>Value range in I05: -31 bits to 0 to 31 bits</i>		
N11	S1-method: Reference of position N10 <i>0: absolute;</i> Switching point is triggered when position N10 is traveled over. <i>1: rel.to start;</i> Switching point is triggered after a distance of N10 (absolute value) after the starting point. <i>2: rel.to endpos;</i> Switching point is triggered at a distance of N10 before the destination position.		
N12	S1-memory1: When switch S1 is approached, switch memory 1 can be affected. <i>0: inactive;</i> <i>1: set;</i> Switch memory 1 is set to high. <i>2: clear;</i> Switch memory 1 is set to low. <i>3: toggle;</i> Switch memory 1 is inverted (low → high → low → ...).		
N13	S1-memory2: Behavior of switch memory 2. Cf. N12 .		
N14	S1-memory3: Behavior of switch memory 3. Cf. N12 .		



☞ Posi switching points S2 to S4 are set up identically. Switching point S2 is located in **N20** to **N24**, and so on.

- The power pack must be turned off before these parameters can be changed.
- Italics* These parameters are sometimes not shown depending on which parameters are set.
- 1) See result table in chap 15. 2) Only available when **D90≠1**
- Parameters which are included in the *normal* menu scope (**A10=0**). For other parameters, select **A10=1:extended** or **A10=2:service**.
- E Parameters marked with a "√" can be parameterized separately from each other in parameter record 1 and 2.

POSIDRIVE® SDS 4000

14. Option Boards

14.1 Option Board SEA 4000






Purpose:

- Expansion of the digital inputs/outputs of a **POSIDYN®** SDS 4000 servo inverter
- 10 additional binary inputs (BE5 to BE14), galvanically isolated
 - 5 additional binary outputs (BA3 to BA7), galvanically isolated
 - Inputs/outputs identical to those of option boards SEA + DP4000

Installation:

- ① Remove the cover from the top of the housing with a suitable tool (side cutting pliers). Do not saw. Do not allow metal shavings to penetrate the device.
- ② Install board vertically in the housing, and secure with two screws.

	Ter- minal	Function	Parameter	Circuiting
Terminal strip X21	1	Input BE5	F35	L - level: 0 to 7 V / 0 mA H - level: +12 to 30 V / 7 mA, Ri = 3.3 kΩ
	2	Input BE6	F60	
	3	Input BE7	F61	
	4	Input BE8	F62	
	5	Input BE9	F63	
	6	Input BE10	F64	
	7	Input BE11	F65	
	8	Input BE12	F66	
	9	Input BE13	F67	
	10	Input BE14	F68	
	11	Output BA3	F82	<ul style="list-style-type: none"> • External power must be available on terminal X21.17 and be between 15 and 29 V. • Maximum output current 50 mA with load against ground • Maximum output current 200 mA with load against 24 V
	12	Output BA4	F83	
	13	Output BA5	F84	
	14	Output BA6	F85	
	15	Output BA7	F86	
	16	GND		Reference ground galvanically isolated from inverter
	17	+24 V		Voltage for the output drivers (BA3 to BA7)



15. Result Table

Result Table	
The result of actions (e.g., save parameter (A00=1)) is indicated on the display. Possible results are listed below.	
0: Error free	The data were transferred correctly.
1: Error!	General error
2: Wrong box	Controlbox's data memory has incompatible data structure (e.g., formatting for another memory size).
3: Invalid data	Controlbox's data memory contains invalid data. Write Controlbox again, and repeat the procedure.
5: OK (adjusted)	Software version of Controlbox data (or similar) and controller differ in several parameters. Confirm with the [#] key. Message does not affect functionality of the controller.
6: OK (adjusted)	Software version of Controlbox data (or similar) and controller differ in several parameters. Confirm with the [#] key. Message does not affect functionality of the controller.
9: BE encoder signal	<ul style="list-style-type: none"> If synchronous reference value G27=0:BE encoder or posi encoder I02=0:BE encoder, the following must apply: F31=14(15), F32=15(14). If G27=1 (synchronous reference value = X20) or I02=1 (posi encoder = X20), the following must apply: F31≠14(15), F32≠15(14). Values in parentheses: Encoder (signal A, B) and stepper motor connection (frequency + sign) access the same counter.
10: Limit value	Value outside the value range
12: BE/X20/X41	Conflict while accessing the encoder pulse counter (there is only one) or error in parameterization of the sin/cos encoder <ul style="list-style-type: none"> X20 may not be simultaneously programmed as the pulse input with BE1/BE2 or X40 (F31, F31≠14, 15 and H40≠2:encoder In when H20=2, 3 and vice versa). When motor encoder B26=3:SinCos, H40=1:SinCos must be programmed. When motor encoder B26=3:SinCos, neither X20 nor BE1/BE2 may be programmed as the pulse input (encoder or stepper motor).
13: BE cw/ccw	Programming F31=14 and F32=14 can be used to simulate the direction of rotation of inverters with software SDS 3.2. The functions "direction of rotation," "halt," and "quick stop" may not be assigned to other BEs.
14: Canceled	<ul style="list-style-type: none"> The B40/B41 actions could not be executed correctly. Action canceled (e.g., due to removal of enable). The current exceeded the permissible maximum value (e.g., short circuit or ground fault) during "autotuning" or "phase test" (B40, B41).
15: R1 too high	A stator resistance measured during "autotuning" (B41) was too high. Motor is circuited incorrectly. Motor cable is defective.
16: Phase fault U	Error in phase U
17: Phase fault V	Error in phase V
18: Phase fault W	Error in phase W
19: Symmetry	Error in symmetry of phases U, V and W. Deviation of a winding resistor by $\pm 10\%$.
20: Motor connection	Resolver or motor pole number is not correct.
21: Enable ?	The enable must be present for actions J00/J01/J05 .
22: F20=F25 ??	Both analog inputs (AE1 and AE2) are programmed for the same function. F20≠F25 must apply.
25: Phase order	Error in motor wiring (order of the phases, U, V, W incorrect). Is reported as the result of the B40 phase test. <ul style="list-style-type: none"> Check motor wiring and, if necessary, resolver cable too.
26: Encoder offset	The zero offset of the motor encoder (resolver) is not correct. Is reported as the result of the B40 phase test. With STÖBER ES motors, the error is usually to be found in the wiring or in the plug connector. <ul style="list-style-type: none"> Check motor and resolver wiring. Then start phase test (B40) again. If no wiring error can be found, the measured offset is stored (non-volatile) via A00=1 in H32 with all other parameters.

16. Operating States

Operating States

The operating state is indicated in the display of Controlbox with number and name and can be queried under **E80** during fieldbus access. An abbreviation appears in the LED status display of the device.

0: Ready	rdy	Inverter is ready. Voltage is available.
1: Clockwise	run	Fixed positive speed
2: Counter-clockwise	run	Fixed negative speed
3: Acceleration	run	Acceleration procedure in progress (Accel)
4: Deceleration	run	Deceleration procedure in progress (Decel)
5: Halt	HLt	Halt command present
7: n > n-Max	run	Reference value is greater than minimum of C01 and E126 (via analog input or fieldbus).
8: Illegal direction	dir	Specified direction of rotation is not the permissible direction of rotation (C02).
11: Quick stop	HLt	Quick stop is being performed.
12: Inhibited	inh	This state prevents an undesired startup of the drive. Effective for: <ul style="list-style-type: none"> • Drive is turned on (power on) with enable = high (only if A34=0). • A fault is acknowledged with a low-high change in enable. • Opened load relay (no power or no phase) • If A30=3:SDP 4000 or A30=4:CAN-bus and the fieldbus sends a "disable voltage" control command, or the enable terminal becomes low, or a quick stop is completed.
13: Serial (X3)	run Not al- ways	Parameter A30=1 parameterized. Inverter is controlled by the PC via serial interface.
14: Enabled	EnA	Only available with <i>Drivecom</i> profile. Bus connection.
15: Self test	tst	Self-test is being performed on inverter.
16: Fault	Exy	Inverter's power pack is disabled. "xy" is the fault code (see chap. 17).
17: Positioning-active	pos	Position control is active. Waiting for a start command. Basic state of positioning control.
18: Moving	run	Processing a traversing job. Drive is moving. Indicated instead of the states of the speed mode (i.e. <i>accelerate, brake, left and right</i>).
19: Delay	pos	For process block chaining with defined delay or for repetition of relative movements. During a stop between two sequential jobs, the signal "in position" is generated, but the display shows "delay."
20: Wait	pos	For process block chaining with defined manual start (i.e., wait for <i>posi.step</i> signal)
21: Referencing	rEF	During reference point traversing with <i>posi</i> or synchronous running
22: Tip	run	During manual traversing
23: Interrupted	pos	After an interrupted process block (i.e., halt or quick stop) with the option of continuing with the <i>posi.step</i> signal. <i>Posi.step</i> is then used to move to the original destination position regardless of whether the drive has been moved in the meantime. The "23:Interrupted" state is retained when the enable is turned off and on while the halt signal is active. A change in enable without the halt signal and manual traversing cause the basic state "17:Posi.active."
24: Reference wait	rEF	Wait for <i>posi.start</i> or <i>posi.step</i> signal to trigger reference point traversing after power on (I37=1).
25: Stop input	StP	Drive is positioned on stop input and can only be moved out of this position with manual or reference point traversing.
26: Parameter inhibit	OFF	Enable was deactivated from the PC with software while data was being transferred from the PC to the inverter.

17. Faults/Events

Faults / Events
 When faults occur, the inverter is no longer able to control the drive and is disabled. An entry is made in the fault memory (E40/E41), and relay 1 (ready for operation) releases. If installed when the fault occurs, the Parabox is written automatically. Certain events (cf. last column of the table below) can be declared via FDS Tool as faults, messages, warnings or not effective.

		Auto Reset	FDS Tool*
31: Short/ground	The hardware overcurrent switch-off is active. <ul style="list-style-type: none"> Motor requires too much current from the inverter (e.g., interwinding fault or overload). 	√	
34: Hardw. fault	The non-volatile data memory is defective or software version is time-limited.		
35: Watchdog	Monitors the load and functions of the microprocessor	√	
36: High voltage	DC-link voltage too high <ul style="list-style-type: none"> Power too high Reverse powering of the drive while braking (no brake resistor connected, brake chopper defective, brake chopper deactivated with A20). See chap. 4.6. 	√	
37: n-feedback	Resolver: Wire break or signal level too low Fault can only be acknowledged by turning 24 V off and on! Sin/cos absolute-value encoder: <ul style="list-style-type: none"> During device startup <ul style="list-style-type: none"> Communication to the device is faulty. Absolute-value encoder unknown Communication protocol unknown (neither EnDat nor HiperFace) During operation <ul style="list-style-type: none"> Wire break or signal level too low Change in B26 		
38: tempDev.sens	The heat dissipater temperature is over the limit value. Cf. E25 . <ul style="list-style-type: none"> Temperature of environment/switching cabinet is too high. 		
39: TempDev.i2t	The inverter limits the output current to 99% of the nominal current. The i ² t model calculated for the inverter has reached 100% of the thermal load. <ul style="list-style-type: none"> Inverter is overloaded. (inverter too small). Temperature of the environment/switching cabinet is too high. Closed brake Motor connected incorrectly Resolver connected incorrectly 		
40: Invalid data	The data in non-volatile memory are incomplete. Reset non-volatile memory with " A00 save values." This loads the default values.		
41: Temp.motorTMP	Excessive temperature indicated by the motor temperature sensor. <ul style="list-style-type: none"> Motor is overloaded. Use external ventilation. Temperature sensor not connected (X40.2 to X40.6) 		
42: Temp.brakeRes	The i ² t model calculated for the brake resistor has reached 100% of the thermal load. <ul style="list-style-type: none"> A20 programmed incorrectly Permissible power loss of brake resistance is too high. With internal brake resistance: No jumper on X12. → chap. 5.2. With external brake resistance: Brake resistor not connected. 		
44: Ext.fault	Fault triggered by BE		
45: OTempMot.i ² t	<ul style="list-style-type: none"> Motor overloaded Cooling insufficient 		√
46: Low voltage	DC-link voltage is below the limit value set in A35 . <ul style="list-style-type: none"> Drops in the power supply Acceleration times are too short (ramps, D ..). 	√	√

* Events can be programmed with FDS Tool as messages, warnings or faults, or can be completely deactivated.

17. Faults/Events

Faults / Events

When faults occur, the inverter is no longer able to control the drive and is disabled. An entry is made in the fault memory (**E40/E41**), and relay 1 (ready for operation) releases. Certain events (cf. last column of the table below) can be declared via FDS Tool as faults, messages, warnings or not effective.

		Auto Reset	FDS Tool*
47: Device overl.	The maximum torque has been exceeded. The permissible torque is limited by parameters C03 and C04 and the possible torque limitation via analog input. See chap. 9.2.	√	√
48: Accel.overl.	Same as "47:Device overload" except for an acceleration procedure. M-Max 2 (C04) is permitted for the acceleration procedure with "cycle characteristic" startup (C20=2).	√	√
49: Decel.overl.	Same as "47:Device overload" except for a deceleration procedure	√	√
50: Operat.area	The operating area defined under C41 to C46 has been exited. See also chap. 9.3.	√	√
51: Refused	Only for positioning (C60=2). <i>Posi.start</i> or <i>posi.step</i> was not accepted. <ul style="list-style-type: none"> • Destination position is located outside software limit switches I50 and I51. • In non-referenced status (I86=0), no absolute positions (e.g., J11=1) are traveled to. • The direction of rotation in the current process block is not the same as the permissible direction I04. 	√	√
52: Communication	<ul style="list-style-type: none"> • Fault during communication between inverter and FDS Tool during remote control via PC • Communication fault during fieldbus operation 	√	
53: Stop input	A limit switch connected via a BE input or monitored via fieldbus has been triggered. During referencing at the limit switch (I30=1), a reversal of the limit switches will cause a fault.	√	
54: Follow. error	The maximum following error (i.e., deviation between actual position and reference value position) permitted by I21 has been exceeded. <ul style="list-style-type: none"> • Motor overload, too much acceleration or blockage • Kv-factor I20 too small, speed feed forward I25 too small 	√	√
55: OptionBoard	<ul style="list-style-type: none"> • When option board <i>SEA-4000</i> is used, the external 24 V voltage is not present or the card is defective. No fault if enable is deactivated. • No option card found 		
56: Overspeed	Actual speed exceeds n-Max by more than 15%.		

* The events checked in the "FDS Tool" column can be parameterized with FDS Tool as messages, warnings or faults in the group **U..** protective functions.

Acknowledgment of faults:

- **Enable:** Change from low to high level on the enable input.

Always available:

-  -key (only if **A31=1**).
- **Auto-reset** (only if **A32=1**).
- **Binary input** (**F31** to **F34=13**).


Caution!
 Drive starts up immediately!

Parameters **E40** and **E41** can be used to scan the last 10 faults (i.e., value 1 is the last fault). FDS Tool can then be used to assign the inverter's reaction (fault, warning, message or nothing) to certain events.

STÖBER ANTRIEBSTECHNIK - Deutschland



STÖBER ANTRIEBSTECHNIK

Hauptverwaltung:

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Postfach 910103
75091 Pforzheim

Kieselbronner Straße 12
75177 Pforzheim

Telefon (0 72 31) 58 20
Telefax (0 72 31) 58 21 97
eMail sales@stoeber.de

24-Stunden-Service-Nr.
17:30 - 7:30: (0 18 05) 78 63 23
Vanity-No:
17:30 - 7:30: (0 18 05) STOEBER

Vertriebsgebiet Nordwest:

Zentrale

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Klaus Sirrenberg
Friedrich-Ebert-Str. 85
58454 Witten

Telefon (0 23 02) 98 49 4-0
Telefax (0 23 02) 98 49 4-50
eMail TB_DO@stoeber.de

Zugehörige Technische Büros:

Norddeutschland

20000 - 23919
24000 - 29999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Stefan Hildebrandt
Hellwege Allee 9b
21698 Harsefeld

Telefon (0 41 64) 81 19 04
Telefax (0 41 64) 81 19 05
eMail TB_ND@stoeber.de

Münster

33000 - 33599
33900 - 33999
48000 - 49999
59200 - 59329
59470 - 59699

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Markus Merker
Grottenkamp 28
48565 Steinfurt

Telefon (0 25 52) 61 02 71
Telefax (0 25 52) 61 02 72
eMail TB_MS@stoeber.de

Dortmund Nordwest

40000 - 47999
59330 - 59399

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Thomas Nickisch
Friedrich-Ebert-Str. 85
58454 Witten

Telefon (0 23 02) 98 49 4-0
Telefax (0 23 02) 98 49 4-50
eMail TB_DO@stoeber.de

Dortmund Südost

50000 - 53999
57000 - 59199
59400 - 59469
59700 - 59999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Michael Ritter
Friedrich-Ebert-Str. 85
58454 Witten

Telefon (0 23 02) 98 49 4-0
Telefax (0 23 02) 98 49 4-50
eMail TB_DO@stoeber.de

Hannover

30000 - 32999
33600 - 33899
34330 - 34549
37000 - 37199
37400 - 38799

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Alexander Helmes
Birkenweg 6
32839 Steinheim

Telefon (0 52 33) 99 77 65
Telefax (0 52 33) 99 77 67
eMail TB_H@stoeber.de

Vertriebsgebiet Mitte:

Zentrale

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Postfach 910103, 75091 Pforzheim
Kieselbronner Straße 12, 75177 Pforzheim

Telefon (0 72 31) 58 20
Telefax (0 72 31) 58 21 97
eMail sales@stoeber.de

Zugehörige Technische Büros:

Saar-Pfalz

54000 - 56999
65000 - 66919
67200 - 67319
67500 - 67999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Roland Dillmann
Black & Decker-Str. 1
65510 Idstein

Telefon (0 61 26) 98 94 06
Telefax (0 61 26) 5 54 99
eMail TB_ID@stoeber.de

Wiesbaden

34000 - 34329
34550 - 36399
37200 - 37299
60000 - 64999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Jens Thomas
Black & Decker-Str. 1
65510 Idstein

Telefon (0 61 26) 98 94 05
Telefax (0 61 26) 5 54 99
eMail TB_ID@stoeber.de

Vertriebsgebiet Süd:

Zentrale

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Postfach 910103, 75091 Pforzheim
Kieselbronner Straße 12, 75177 Pforzheim

Telefon (0 72 31) 58 20
Telefax (0 72 31) 58 21 97
eMail sales@stoeber.de

STÖBER ANTRIEBSTECHNIK - Deutschland



STÖBER ANTRIEBSTECHNIK

Zugehörige Technische Büros:

Pforzheim

70000 - 71499
71600 - 71999
72190 - 72299
74000 - 74399
74600 - 74699
75100 - 75999

Gerd Braun GmbH Ingenieurbüro für Antriebstechnik

Gerd Braun, Dirk Petersen
Adolf-Sautter-Str. 30
75181 Pforzheim (Würm)
eMail mail@braun-antriebstechnik.de

Telefon (0 72 31) 97 99 0
Telefax (0 72 31) 97 99 10

Nordbaden

66920 - 67199
67320 - 67499
68000 - 69999
74700 - 75099
76600 - 76999
97860 - 97999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Stefan Rotterdam
Postfach 910103, 75091 Pforzheim
Kieselbronner Straße 12, 75177 Pforzheim

Telefon (0 72 31) 58 21 49
Telefax (0 72 31) 58 23 49
eMail TB_NB@stoeber.de

Südbaden

76000 - 76599
77000 - 77999
78090 - 78149
79000 - 79999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Daniel Lohse
Postfach 910103, 75091 Pforzheim
Kieselbronner Straße 12, 75177 Pforzheim

Telefon (0 72 31) 58 21 14
Telefax (0 72 31) 58 23 49
eMail TB_SB@stoeber.de

Reutlingen

72000 - 72189
72300 - 72999
78000 - 78089
78150 - 78999
88000 - 89299
89570 - 89999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Wilhelm Haydt
Gerh.-Hauptmann-Str. 53
72793 Pfullingen

Telefon (0 71 21) 99 40 35
Telefax (0 71 21) 99 40 36
eMail TB_RT@stoeber.de

Göppingen

71500 - 71599
73000 - 73999
74400 - 74599
89500 - 89569

Rolf P. Ulrich Ingenieurbüro für Antriebstechnik

Rolf P. Ulrich
Eichendorffstraße 19
73072 Donzdorf

Telefon (0 71 62) 2 12 74
Telefax (0 71 62) 2 40 61
eMail TB_GP@stoeber.de

München

80000 - 84999
85200 - 87999
89300 - 89499
94000 - 94999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Rupert Schweiger
Feuerreit 1
85625 Baiern

Telefon (0 80 65) 18 02 32
Telefax (0 80 65) 18 02 33
eMail TB_M@stoeber.de

Nürnberg

85000 - 85199
90000 - 93999
95000 - 96499
97000 - 97859

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Wolfgang Lukas
Industriestraße 20 a
91353 Hausen

Telefon (0 91 91) 73 45 37
Telefax (0 91 91) 73 45 38
eMail TB_N@stoeber.de

Vertriebsgebiet Ost:

Zentrale

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Postfach 910103, 75091 Pforzheim
Kieselbronner Straße 12, 75177 Pforzheim

Telefon (0 72 31) 58 20
Telefax (0 72 31) 58 21 97
eMail sales@stoeber.de

Zugehörige Technische Büros:

Berlin / Brandenburg

06000 - 06599
06730 - 07299
10000 - 19999
23920 - 23999
38800 - 39999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Bernd Weise
Werneuchener Weg 9
15345 Altlandsberg

Telefon (03 34 38) 57 31
Telefax (03 34 38) 57 32
eMail TB_BR@stoeber.de

Lichtenstein

00000 - 05999
06600 - 06729
07300 - 09999
36400 - 36999
37300 - 37399
96500 - 96999
98000 - 99999

STÖBER ANTRIEBSTECHNIK GmbH & Co.

Jürgen Stolper
Günsbacher Straße 4
09350 Lichtenstein

Telefon (03 72 04) 29 85
Telefax (03 72 04) 29 86
eMail TB_LI@stoeber.de

STÖBER ANTRIEBSTECHNIK - International



STÖBER ANTRIEBSTECHNIK

Austria	STÖBER ANTRIEBSTECHNIK GmbH Fabriksplatz 1 4662 Steyrermühl	Phone +43 (0) 76 13 / 7 60 00 Fax +43 (0) 76 13 / 7 60 09 eMail office@stoeber.at
France	STÖBER S.a.r.l. 47, rue Maurice Flandin 69003 Lyon	Phone +33 (0) 4 / 72 13 24 38 Fax +33 (0) 4 / 72 13 24 57 eMail stoeber@wanadoo.fr
Great Britain	STOBER DRIVES LTD. Unit 9, Abbeymead Industrial Park Brooker Road, Waltham Abbey Essex EN9 1HU	Phone +44 (0) 19 92 / 70 97 10 Fax +44 (0) 19 92 / 71 41 11 eMail mail@stober.co.uk
Italy	STÖBER TRASMISSIONI S. r. l. Via Risorgimento, 8 20017 Mazzo di Rho (Milano)	Phone +39 02 / 93 90 95 70 Fax +39 02 / 93 90 93 25 eMail info@stoeber.it
Korea	DAE KWANG STOEBER CO. LTD. 441-10 Sangdewon-dong, Joongwon-ku, Sungnam-city, Kyuunggi-do, Postcode 462-120	Phone +82 (0)31 / 7 35 02 93 Fax +82 (0)31 / 7 36 02 81 eMail dkstoeber@netsgo.com
Poland	STOEBER POLSKA ul.H.Kamienskiego 201-219 51-126 Wroclaw	Phone +48 (0) 71 / 3 20 74 17 Fax +48 (0) 71 / 3 20 74 17 eMail biuro@stoeber.pi.pl
USA	STOBER DRIVES INC. 1781 Downing Drive Maysville, KY 41056	Phone +1 6 06 / 7 59 50 90 Fax +1 6 06 / 7 59 50 45 eMail sales@stober.com
Belgium	VAN DOREN - PILLE N. V. Industrieterrein De Prijkels Venecoweg 25 9810 Nazareth	Phone +32 9 / 2 52 13 09 Fax +32 9 / 2 52 23 74 eMail info@vandorenpille.be
Brasil	FRAPHE COMERCIAL Ltda. Rua Jaragua, 340 Bom Retiro 01129-000 Sao Paulo, SP	Phone +55 (0) 11 / 33 37 57 87 Fax +55 (0) 11 / 33 33 42 00 eMail fraphe@fraphe.com.br
Bulgaria	Z & M PRIVATE COMPANY 5, Angel Kantchev Str. 1000 Sofia	Phone +359 2 / 9 86 58 55 Fax +359 2 / 9 86 59 16 eMail zandm@techno-link.com
China	WK-INTERSALES BEIJING German Centre Unit 0525-0530, Landmark Tower 2 8 North Dongsanhuan Road Chaoyang District Beijing 100004	Phone +86 (0) 10 / 65 90 64 25 + 26 Fax +86 (0) 10 / 65 90 67 85 eMail intersal@public.east.net.cn
Colombia	SOCOMEX LTDA. Apdo. Aereo 11606 Santafe de Bogota D. C.	Phone +57 2 85 61 05 / +57 2 85 64 96 +57 2 85 63 36 Fax +57 13 35 04 87

STÖBER ANTRIEBSTECHNIK - International




STÖBER ANTRIEBSTECHNIK


Denmark	EEGHOLM A/S Grundtvigs Allé 165-169 P. O. Box 190 6400 Sønderborg	Phone +45 / 73 12 12 12 Fax +45 / 73 12 12 13 eMail eegholm@eegholm.dk
Finland	EIE MASKIN OY PL 80 10600 Tammisaari	Phone +358 (0) 19 / 2 46 16 42 Fax +358 (0) 19 / 2 46 16 43 eMail eie@eie.fi
Hungary	BDI Hungary Ltd. Fóti Street 141, Bldg 37. 1046 Budapest	Phone +36 (0) 1 / 2 31 10 10 Fax +36 (0) 1 / 2 31 10 30 eMail bdi-hun@elender.hu
the Netherlands	MIJNSBERGEN B. V. Postbus 166 3640 AD Mijdrecht	Phone +31 (0) 2 97 / 28 58 21 Fax +31 (0) 2 97 / 27 23 26 eMail mijnsbergen@mijnsbergen.nl
Norway	ELMEKO AS Postbox 80 1306 Baerum Postterminal	Phone +47 / 67 57 22 70 Fax +47 / 67 57 22 80 eMail elmeko@elmeko.no
Peru	POWERMATIC S. A. Av. Los Ingenieros 333 Lima 03	Phone +51 (0) 1 / 3 49 01 84 / 3 49 40 11 Fax +51 (0) 1 / 4 37 00 73 eMail powermatic@terra.com.pe
Philippines	LEELENG COMMERCIAL, INC. 387 - 393 Dasmariñas St. P. O. Box 480 Manila	Phone +63 2 / 2 41 89 01 to 05 Fax +63 2 / 2 41 40 60 eMail leeleng@manila.vasia.com
South Africa	BEARING MAN LTD. P. O. Box 33431 Jeppestown 2043	Phone +27 (0) 11 / 6 20 15 00 Fax +27 (0) 11 / 6 20 17 75 eMail sales@bearing_man.co.za
Spain	TAHFER COMERCIAL, S. A. Jesus, 27 28917 - LA FORTUNA	Phone +34 91 / 6 19 34 24 Fax +34 91 / 6 19 77 92 eMail tahfercom@tahfer.com
Sweden	EIE MASKIN AB Postfach 7 12421 Bandhagen	Phone +46 (0) 8 / 7 27 88 00 Fax +46 (0) 8 / 7 27 88 99 eMail eie@eie.se
Switzerland	INDUR ANTRIEBSTECHNIK AG Margarethenstraße 87 4008 Basel	Phone +41 (0) 61 / 2 79 29 00 Fax +41 (0) 61 / 2 79 29 10 eMail info@indur.ch
Thailand	GERMAN ENGINEERING & MACHINERY CO., LTD. 947/161 Bangna Complex Moo 12 Bangna Trad Rd. Km 3 Bangkok 10260	Phone +66 2 / 3 61 90 82-8 Fax +66 2 / 3 61 90 89
Turkey	YÜRE MAKINA SAN. ve TIC. LTD. STI. Fevzi Çakmak Mah. 5. Cad. 19. Sok. No: 13 34200 ESENLER-ISTANBUL	Phone +90 2 12 / 6 28 55 73 Fax +90 2 12 / 6 28 55 73

18. Block Circuit Diagram Synchronous Running


19.1 Fast Reference Value active (D99=1)



19.1 BLOCK CIRCUIT DIAGRAM: FAST REFERENCE VALUE ACTIVE (D99=1)



19. Block Circuit Diagram Reference Value Processing



20. Parameter Table

Parameter	DS	Inpt.
A.. INVERTER		
A00 Save parameter [%]		
A01 Read parabox & save [%]		
A02 Check parameter [%]		
A03 Write to parabox [%]		
A04 Default settings [%]		
A10 Menu level	0	
A11 Parameter set edit		
A12 Language	0	
A13 Set password		
A14 Edit password		
A15 Auto-return	1	
A20 Braking resistor type	20	
A21 Brak. resistor resist. [Ω]	Varies	
A22 Brak. resistor rating [kW]	Varies	
A23 Brak. resistor therm [sec]	40	
A30 Operation input	0	
A31 Esc-reset	1	
A32 Auto-reset	0	
A33 Time auto-reset [min]	15	
A34 Auto-start	0	
A35 Low voltage limit [V]	350	
A36 Mains voltage [V]	400	
A37 Reset memorized values		
A38 DC power-input	0	
A40 Read parabox [%]		
A41 Select parameter set		
A42 Copy para set 1>2 [%]		
A43 Copy para set 2>1 [%]		
A50 Tip		
A51 Tip ref. value [rpm]	300	
A55 Key hand function	1	
A82 CAN-baudrate	1	
A83 Busaddress	0	
A84 Profibus baudrate		
B.. MOTOR		
B00 Motor-type		
B02 EMC-constant [V]	110	
B03 Motor fan	0	
B10 Poles	6	
B11 P-nominal [kW]	Varies	
B12 I-nominal [A]	Varies	
B13 n-nominal [rpm]	Varies	
B17 M0 (standstill) [Nm]	Varies	
B26 Motor-encoder	0	
B40 Phase test [%]		
B41 Autotuning [%]		
B53 R1-motor [Ω]	Varies	
B64 Ki-IQ (moment) [%]	Varies	
B65 Kp-IQ (moment) [%]	Varies	
C.. MACHINE		
C00 n-Min [rpm]	0	
C01 n-Max [rpm]	3000	
C02 Perm. dir. of rotation	0	
C03 M-Max 1 [%]	150	
C04 M-Max 2 [%]	150	
C30 J-mach/J-motor	0	
C31 n-controller Kp [%]	60	
C32 n-controller Ki [%]	30	

Parameter	DS	Inpt.
C33 n-RefVal low pass [msec]	2	
C34 n-motor low pass [msec]	Bem.	
C35 n-control. Kp standstill [%]	100	
C40 n-window [rpm]	3	
C41 Oper. range n-Min [rpm]	0	
C42 Oper. range n-Max [rpm]	6000	
C43 Operat. range M-Min [%]	0	
C44 Operat. range M-Max [%]	400	
C45 Operat. range x-Min [%]	0	
C46 Operat. range x-Max [%]	400	
C47 Operat. range C45/C46	0	
C48 Operat. range C47 abs	0	
C49 Operat. range accel&ena	0	
C50 Display function	0	
C51 Display factor	1	
C52 Display decimals	0	
C53 Display text		
C60 Run mode	1	
D.. REFERENCE VALUE		
D00 RV accel [msec/3000rpm]	0	
D01 RV decel [msec/3000rpm]	0	
D02 Speed (max. ref. value)[rpm]	3000	
D03 Reference value -Max [%]	100	
D04 Speed (min. ref. value) [rpm]	0	
D05 Ref. value-Min [%]	1	
D06 Ref. value offset [%]	0	
D07 Ref. value enable	0	
D08 Monitor ref. value	0	
D09 Fix reference value no.	0	
D10 Accel 1 [msec/3000rpm]	60	
D11 Decel 1 [msec/3000rpm]	60	
D12 Fix ref. value 1 [rpm]	750	
D20 Accel 2 [msec/3000rpm]	90	
D21 Decel 2 [msec/3000rpm]	90	
D22 Fix ref. value 2 [rpm]	1500	
D30 Accel 3 [msec/3000rpm]	120	
D31 Decel 3 [msec/3000rpm]	120	
D32 Fix ref. value 3 [rpm]	3000	
D40 Accel 4 [msec/3000rpm]	5	
D41 Decel 4 [msec/3000rpm]	5	
D42 Fix ref. value 4 [rpm]	500	
D50 Accel 5 [msec/3000rpm]	10	
D51 Decel 5 [msec/3000rpm]	10	
D52 Fix ref. value 5 [rpm]	1000	
D60 Accel 6 [msec/3000rpm]	20	
D61 Decel 6 [msec/3000rpm]	20	
D62 Fix ref. value 6 [rpm]	2000	
D70 Accel 7 [msec/3000rpm]	25	
D71 Decel 7 [msec/3000rpm]	25	
D72 Fix ref. value 7 [rpm]	2500	
D81 Decel-quick [msec/3000rpm]	2	
D90 Reference value source	0	
D91 Motorpoti function	0	
D92 Negate reference value	0	
D93 RV-generator		
D94 Ref. val. generator time [msec]	500	
D99 Fast reference value	1	
E.. DISPLAY VALUES		
E00 I-motor [A]		

Parameter	DS	Inpt.
E01 P-motor [kW]		
E02 M-motor [Nm]		
E03 DC-link-voltage [V]		
E06 n-reference value [rpm]		
E07 n-post-ramp [rpm]		
E08 n-motor [rpm]		
E09 Rotor position		
E10 AE1-level [%]		
E11 AE2-level [%]		
E16 Analog-output1-level [%]		
E17 Relay 1		
E18 BA 2		
E19 BE15...BE1 & enable		
E20 Device utilization [%]		
E21 Motor utilization [%]		
E22 i2t-device [%]		
E23 i2t-motor [%]		
E24 i2t-braking resistor [%]		
E25 Device temperature [$^{\circ}$ C]		
E26 Binary output 1		
E27 BA15...BA1 & Relay 1		
E28 Analog-output2-level [%]		
E29 n-ref. value raw [rpm]		
E30 Run time [h,m,sec]		
E31 Enable time [h,m,sec]		
E32 Energy counter [kW]		
E33 Vi-max-memo value [V]		
E34 I-max-memo value [A]		
E35 Tmin-memo value [$^{\circ}$ C]		
E36 Tmax-memo value [$^{\circ}$ C]		
E37 Pmin-memo value [kW]		
E38 Pmax-memo value [kW]		
E40 Fault type		
E41 Fault time		
E42 Fault count		
E45 Control word		
E46 Status word		
E47 n-field-bus [rpm]		
E50 Device		
E51 Software-version		
E52 Device-number		
E53 Variant-number		
E54 Option-board		
E55 Identity-number		
E56 Parameter set ident. 1		
E57 Parameter set ident. 2		
E58 Kommubox		
E60 Reference value selector		
E61 Additional ref. value [rpm]		
E62 Actual M-max [%]		
E63 PID-controller limit		
E64 Brake		
E65 PID-error [%]		
E71 AE1 scaled [%]		
E72 AE2 scaled [%]		
E73 AE2 scaled 2 [%]		
E80 Operating condition		
E81 Event level		
E82 Event name		

20. Parameter Table

Parameter	DS	Inpt.
E83	Warning time	
E84	Active parameter set	
F.. CONTROL INTERFACE		
F00	BA2-function	1
F03	Relay2 t-on [sec]	0
F04	Relay2 t-off [sec]	0
F05	Relay2 invert	0
F06	t-brake release [sec]	0,1
F07	t-brake set [sec]	0,052
F08	Brake	0
F10	Relay1-function	0
F20	AE2-function	0
F21	AE2-offset [%]	0
F22	AE2-gain [%]	100
F23	AE2-lowpass [msec]	0
F24	AE2-offset2 [%]	0
F25	AE1-function	10
F26	AE1-offset [%]	0
F27	AE1-gain [%]	100
F30	BE-logic	0
F31	BE1-function	8
F32	BE2-function	6
F33	BE3-function	9
F34	BE4-function	0
F35	BE5-function	0
F36	BE increment [I/R]	1024
F38	Quick stop	0
F40	Analog-output1-function	4
F41	Analog-output1-offset [%]	0
F42	Analog-output1-gain [%]	100
F43	Analog-output1-absolut	0
F45	Analog-output2-function	1
F46	Analog-output2-offset [%]	0
F47	Analog-output2-gain [%]	50
F49	BE-gear ratio	1
F51	BE1-invert	0
F52	BE2-invert	0
F53	BE3-invert	0
F54	BE4-invert	0
F55	BE5-invert	0
F60	BE6-function	0
F61	BE7-function	0
F62	BE8-function	0
F63	BE9-function	0
F64	BE10-function	0
F65	BE11-function	0
F66	BE12-function	0
F67	BE13-function	0
F68	BE14-function	0
F70	BE6-invert	0
F71	BE7-invert	0
F72	BE8-invert	0
F73	BE9-invert	0
F74	BE10-invert	0
F75	BE11-invert	0
F76	BE12-invert	0
F77	BE13-invert	0
F78	BE14-invert	0
F80	BA1-function	1

Parameter	DS	Inpt.
F81	BA2-function	0
F82	BA3-function	1
F83	BA4-function	1
F84	BA5-function	1
F85	BA6-function	1
F86	BA7-function	1
G.. TECHNOLOGY		
G00	PID-controller	0
G01	PID-controller Kp	0,3
G02	PID-controller Ki [1/sec]	0
G03	PID-controller Kd [msec]	0
G04	PID-controller limit [%]	400
G05	PID-controller limit2 [%]	-400
G06	PID-controller Kp2	1
G10	Winding operation	0
G11	Diameter	0
G12	Min. winding diam. [mm]	10
G13	Max. winding diam. [mm]	100
G14	Beg. winding diam. [mm]	10
G15	Overdrive ref. value [rpm]	0
G16	Diam.calculator ramp [mm/s]	10
G17	Tension reduction [%]	0
G19	Winding act. diam. [mm]	
G20	Electronic gear	0
G21	Speed master	1
G22	speed slave	1
G23	Kp synchron [1/sec]	30
G24	Max. sync. difference [°]	3600
G25	Synchron reset	3
G26	n-correction-Max. [rpm]	3000
G27	Synchronous encoder	0
G28	n-Master [rpm]	
G29	Synchron difference [°]	
G30	Speed feed forward [%]	80
G31	Reference direction	0
G32	Reference speed fast [rpm]	1000
G33	Reference speed slow [rpm]	300
G35	Ref.encoder signal 0	0
G38	Synchronous offset [°]	0
G40	Static friction torque [Nm]	0
G41	Dyn. friction torque [Nm/100rpm]	0
G42	T-dyn lowpass [msec]	50
H.. ENCODER		
H20	X20-function	1
H21	Encodersim. increments	2
H22	X20-increments [I/R]	1024
H23	X20-gear ratio	1
H24	X20-zeroPos. [°]	0
H31	Resolver poles	2
H32	Commutation-offset [°]	0
H40	X41-function	0
H41	X41-increments [I/U]	1024
H42	X41-gear-ratio	1
H60	SSI-invert	0
H61	SSI-Code	0
H62	SSI-databits	25
I.. POSI MACHINE		
I00	Position range	1
I01	Circular length [I05]	360

Parameter	DS	Inpt.
I02	Posi-encoder	2
I03	Direction optimization	1
I04	Move direction	0
I05	Measure unit selection	2
I06	Decimal digits	2
I07	Way/rev. numerator [I05]	360
I08	Way/rev. denomin. [R]	1
I09	Measurement unit	
I10	Max. speed [I05/sec]	10
I11	Max. accel. [I05/sec²]	10
I12	Tip speed [I05/sec]	180
I15	Accel-override	0
I16	S-ramp [msec]	0
I19	ENA-interrupting	0
I20	Kv-factor [1/sec]	30
I21	Max. following error [I05]	90
I22	Target window [I05]	5
I23	Dead band pos. control [I05]	0
I25	Speed feed forward [%]	80
I30	Reference mode	0
I31	Reference direction	0
I32	Ref. speed fast [I05/sec]	90
I33	Ref. speed slow [I05/sec]	4,5
I34	Reference position [I05]	0
I35	Ref. encoder signal 0	0
I36	Continuous reference	0
I37	Power-on reference	0
I38	Reference block	0
I40	Posi.-step memory	0
I50	Software-stop - [I05]	-10000000
I51	Software-stop + [I05]	10000000
I60	Electr. cam1 begin [I05]	0
I61	Electronic cam1 end [I05]	100
I70	Position-offset [I05]	0
I80	Actual position [I05]	
I81	Target position [I05]	
I82	Active process block	
I83	Selected process block	
I84	Following error [I05]	
I85	In position	
I86	Referenced	
I87	Electronic cam 1	
I88	Speed [I05/sec]	
J.. POSI COMMAND		
J00	Posi.start	
J01	Posi.step	
J02	Process block number	0
J03	Tip-mode	
J04	Teach-in	
J05	Start reference	

 = Normal menu. Cf. par. A10.
Access to extended menu A10=1

DS = Default setting

POSIDYN® SDS 4000


20. Parameter Table

21. Accessories

Parameter		DS	Entry of Process Blocks 1 to 8 (Process blocks 9 to 32 can only be programmed with FDS Tool!)							
			Block 1	Block 2	Block 3	Block 4	Block 5	Block 6	Block 7	Block 8
			J10 to J18	J20 to J28	J30 to J38	J40 to J48	J50 to J58	J60 to J68	J70 to J78	J80 to J88
J..0	Position [I05]	0								
J..1	Position mode	0								
J..2	Speed [I05/sec]	1000								
J..3	Accel [I05/sec ²]	1000								
J..4	Decel [I05/sec ²]	1000								
J..5	Repeat number	0								
J..6	Next block	0								
J..7	Next start	0								
J..8	Delay [sec]	0								
			L10 to L12	L20 to L22	L30 to L32	L40 to L42	L50 to L52	L60 to L62	L70 to L72	L80 to L82
L..0	Brake	0								
L..1	Switch A	0								
L..2	Switch B	0								
			Switch S1 N10 to N14		Switch S2 N20 to N24		Switch S3 N30 to N34		Switch S4 N40 to N44	
N..0	S..-position [I05]	0								
N..1	S..-method	0								
N..2	S..-memory1	0								
N..3	S..-memory 2	0								
N..4	S..-memory 3	0								

21. Accessories

Type	ID No.	Input Filter for Interference Immunity "B"	Output Derating for Motor Lines ≥ 25 m
SDS 4011	42.227	FS 4834-10-29 10 A _{eff} ID no. 28.203	RU 775 5 A _{eff} ID no. 28.206
SDS 4021	42.228		RU 774 13 A _{eff} ID no. 28.207
SDS4041	42.229		
SDS 4071	42.230		
SDS 4141	42.231	FS 4835-25-29 25 A _{eff} ID no. 28.204	RU 778 25 A _{eff} ID no. 28.208



Filter	RU 774 13 A	RU 775 5 A	RU 778 25 A
W x H x D (in mm)	105 x 240 x 80	70 x 160 x 55	90 x 350 x 90
Max. line cross section	6 mm ² (rigid) or 4 mm ² (flexible)		

Designation	ID No.	Remarks
Controlbox (incl. connection cable - FDS/SDS - 2 m)	42.224	Controlbox documentation, no. 441 445
Manual control	42.225	
PC adapter for Controlbox (incl. power pack)	42.558	Page 10
Connection cable G3 PC <-> SDS with 9-pin subminiature D connector	41.488	Chap. 9.9
Option board SEA4000 (EA expansion)	42.604	Chap. 14.1
Option board SDP 4000 (PROFIBUS-DP, 12 Mbaud)	42.605	PROFIBUS documentation, no. 441 525 (SV 4.5)
Option board PROFIBUS+EA (combi board SEA+SDP 4000)	42.559	Chap. 14.1 + PROFIBUS documentation, no. 441525 (SV 4.5)
Master-slave connection (prefabricated)	42.940	Page 22
FDS Tool software for Windows (3½" floppy disk)	41.499	Download from http://www.stoeber.de
Brake resistor, FZT 300 x 45 with thermal monitoring, 300 W, 80 Ω	41.730	
Brake resistor, FZT 400 x 65 with thermal monitoring, 600 W, 80 Ω	41.729	
Brake resistor, FZT 400 x 65 with thermal monitoring, 600 W, 30 Ω	41.641	
Brake resistor, FZT 600 x 65 with thermal monitoring, 1000 W, 30 Ω	41.728	
Brake resistor, FZT 400 x 45 with thermal monitoring, 1200 W, 30 Ω	41.643	

⇒ ⇒ Visit the STÖBER homepage

<http://www.stoeber.de>

Always up-to-date with the latest information on:

- **FDS Tool**
- **Catalogs, documentation, installation instructions and much more**
- **Sample applications**



NEW ... NEW ... NEW ...

- Motor encoder with sin/cos track for maximum dynamics and smooth running
→ Chap. 5.6
- Multi-turn absolute value encoder (SSI, EnDat[®], Hiperface[®]), for continuous axes too
→ Chap. 5.4 and 5.6
- Higher limit frequencies for external HTL incremental encoders
→ Chap. 5
- New **handshake signals** for easy communication with the host controller
- **Process block switching points**
- **Version 4.5** is software-compatible with the **POSIDRIVE[®]** FDS 4000 STÖBER frequency inverter.



STÖBER ANTRIEBSTECHNIK
GmbH + Co.

GERMANY
Kieselbronner Strasse 12 · 75177 Pforzheim
Postfach 910103 · 75091 Pforzheim
Telephone 0 72 31 - 58 20, Telefax 0 72 31 - 58 21 97
Internet: <http://www.stoeber.de> / eMail: mail@stoeber.de

Presented by: