



# GSD file information for

## MOVITRAC 31 with PROFIBUS

- Size 1-4 with PROFIBUS p.c.b. FFP31



- Size 0 with integrated PROFIBUS interface



## Contents

1 Revision status GSD file .....	2
2 How to install the GSD file .....	3
2.1 How to install a new GSD file with STEP 7 .....	3
3 Project planning for the DP master .....	4
4 PROFIBUS DP Configurations .....	5
4.1 Data consistency .....	6
4.2 External Diagnosis .....	6
4.2.1 Recommendation .....	6
4.2.2 Note regarding Simatic S7 DP-Masters .....	6
4.2.3 External diagnosis with MOVITRAC 31 size 0 .....	6
5 Sample program for STEP 5 .....	8
6 Sample program for STEP 7 .....	9
7 PROFIBUS DP fault diagnosis .....	10
7.1 Inverter does not work on PROFIBUS DP .....	11
7.2 Inverter cannot be controlled via DP master .....	12

# 1 Revision status GSD file

The syntax of this GSD file was checked with the GSD-Editor V2.1 and GSD-Checker V2.2 of the Profibus Usergroup.

For the different sizes of the frequency inverter family MOVITRAC 31C use the following files:

**MOVITRAC 31C (size 1-4) with p.c.b. FFP31:**

<b>SEW_3100.GSD</b>	- GSD file
<b>SEW3100N.BMP</b>	- Bitmap file with inverter icon
<b>SEW3100S.BMP</b>	- Bitmap file with inverter icon

**MOVITRAC 31C size 0 with integrated PROFIBUS interface:**

<b>SEW_3111.GSD</b>	- GSD file
<b>SEW3111N.BMP</b>	- Bitmap file with inverter icon
<b>SEW3111S.BMP</b>	- Bitmap file with inverter icon

**Version 1.31 of 24. March 2000**

Changes V1.20 to V1.31 in **SEW 3100.GSD** and **SEW 3111.GSD**:

- All texts are in english now
- Additionally predefined configuration of 6 and 10 process data
- The frequency inverter „**MOVITRAC 31+FFP31**“ and „**MOVITRAC Size 0**“ are assigned to the slave family „Drives“ now and no longer assigned to the group „General“ (as in GSD version 1.20).
- The GSD file uses additional bitmap files to specify the symbolic representation of the drives in the project planning software of the DP master.

Changes V1.20 to V1.31 only in **SEW 3111.GSD**:

Only MOVITRAC 31C size 0 offers the possibility to enable/disable the generation of external diagnosis alarms due to malfunction of the inverter.

- The factory setting in the GSD file for external diagnosis alarms is changed to DISABLED:  
→ Inverter fault doesn't generate external diagnosis alarm, normal DP diagnosis is still active! The external diagnosis can be enabled in the project planning software of the DP master.

**Version 1.20 of 24. June 1997**

1<sup>st</sup> release

**Note:**

The latest version of the GSD files for SEW inverters can be downloaded from the SEW homepage, URL <http://www.SEW-EURODRIVE.de>.

## 2 How to install the GSD file

The GSD file is supplied for project planning for the DP master. The GSD file must be copied into a special folder for your project planning software. Please refer to the manuals of your project planning software for information about the precise procedures.

The standardized GSD file can be read from all DP master systems.

### 2.1 How to install a new GSD file with STEP 7

1. Start the Simatic Manager program.
2. Open an existing project and start the hardware configuration tool (HW-Config).
3. Please close the Configuration window in between the HW-Config, otherwise you cannot install the new version of the GSD file.
4. Use the menu "Options / Install new GSE..." to select the new GSD files "**SEW\_3100.GSD**" and "**SEW\_3111.GSD**".
5. Click OK to open the new GSD file. The Message box asks, if you really want to exchange the current GSD file with the revision 1. Choose YES to overwrite the old file. Now the new GSD and bitmap files will be loaded into the STEP7 system. The contents of the hardware catalog will be automatically updated.

**IMPORTANT:** The current GSD file bases on GSD revision 1. This number is not the version number of the GSD file. Open the files sew\_3100.gsd or sew\_3111.gsd (e.g. with notepad.exe) to check the version number of the GSD file.

6. You'll find the SEW inverter in the Hardware catalog in the section:

```

PROFIBUS DP
  +---Additional Field Devices
    +---Drives
      +---MOVITRAC 31+FFP31
      +---MOVITRAC 31 Size 0

```

→ The new GSD file is successfully installed now.

### 3 Project planning for the DP master

The following section describes the scenario for the project planning for the DP master:

- 1) Install (copy) the GSD file in accordance with the requirements of your project planning software. Once the installation has been completed correctly, the inverter appears in the slave family „**Drives**“ with the designation „**MOVITRAC 31+FFP31**“ or „**MOVITRAC 31 Size 0**“.
  - 2) For project planning purposes, add the interface module „**MOVITRAC 31+FFP31**“ for size 1-4 or „**MOVITRAC31 Size 0**“ into the PROFIBUS structure and assign the station address.
  - 3) Select the process data configuration for your application (see chapter „PROFIBUS DP Configuration“).
  - 4) Specify the I/O addresses for the configured process data configuration.
- Startup PROFIBUS DP following the project planning steps. The red „BUS FAULT“ LED signals the status of the project planning process (OFF = project planning OK).

## 4 PROFIBUS DP Configurations

It is necessary for the DP master to send the frequency inverter a certain DP configuration in

order to be able to define the type and number of input and output data used for transfer. In doing this, you have the opportunity to

- control the drive using process data
- read and write all drive parameters using the parameter channel

The “Process data configuration” column lists the names of the configurations. These texts also appear as a selection list in your project planning software for the DP master. The DP configurations column shows which configuration data are sent to the inverter when the PROFIBUS-DP connection is being established.

Process data configuration	Meaning / information	DP configurations	
		0	1
1 PD	Control by 1 process data word	240 <sub>dec</sub>	-
2 PD	Control by 2 process data words	241 <sub>dec</sub>	-
3 PD	Control by 3 process data words	242 <sub>dec</sub>	-
Param + 1 PD	Control by 1 process data word Parameter setting using 8-byte parameter channel	243 <sub>dec</sub>	240 <sub>dec</sub>
Param + 2 PD	Control by 2 process data words Parameter setting using 8-byte parameter channel	243 <sub>dec</sub>	241 <sub>dec</sub>
Param + 3 PD	Control by 3 process data words Parameter setting using 8-byte parameter channel	243 <sub>dec</sub>	242 <sub>dec</sub>
Universal Configuration	Reserved for special configurations	0 <sub>dec</sub>	

**Tabelle 1: DP-Configurations of MOVITRAC 31**

**Note:**

“Special identifier formats” coding is not supported! Only use the “Total length consistency” setting for data transmission!

## 4.1 Data consistency

Consistent data are data which have to be transmitted between the programmable controller and the frequency inverter as one block at all times and are never allowed to be transmitted separately from one another.

Data consistency is very important for transmitted position values or complete positioning tasks. This is because data which is not transmitted consistently could be from different program cycles of the programmable controller, which would lead to undefined values being transmitted to the frequency inverter.

With PROFIBUS-DP, data communication always takes place between the programmable controller and drives using the "Data consistency = total length" setting.

## 4.2 External Diagnosis

The frequency inverter MOVITRAC with option p.c.b. FFP31 for PROFIBUS supports the external diagnosis of PROFIBUS DP. MOVITRAC sends an external diagnosis signal to the DP master every time a malfunction occurs. It is then necessary to program corresponding algorithms in the program of the DP master system in order to evaluate the diagnosis information.

### 4.2.1 Recommendation

It is basically not necessary to activate the external diagnosis function because the inverter transmits the current drive status in status word 1 during every PROFIBUS-DP cycle.

### 4.2.2 Note regarding Simatic S7 DP-Masters

Diagnostic alarms may be triggered by the PROFIBUS-DP system in the DP master at any time even when external diagnosis signal generation is inactive. This means the corresponding operation blocks (e.g. OB84 for S7-400 or OB82 for S7-300) should always be created in the controller.

### 4.2.3 External diagnosis with MOVITRAC 31 size 0

For the frequency inverter MOVITRAC 31 size 0, it is possible to activate automatic generation of external diagnosis alarms via PROFIBUS-DP during the project planning in the DP master. If this function has been activated, MOVITRAC 31 size 0 sends an external diagnosis signal to the DP master every time a malfunction occurs. It is then necessary to program corresponding algorithms in the program of the DP master system in order to evaluate the diagnosis information.

Additional application-specific parameters can be defined in every DP master during the configuration of a DP slave. These parameters are transferred to the slave when the PROFIBUS-DP starts up. Ten application-specific parameter data items are provided for MOVITRAC 31 size 0. Their functions are as follows:


Byte :	Permitted value	Function
0	00 hex	reserved
1	00 hex 01 hex	Inverter generates external diagnosis alarm due to malfunction Inverter <u>does not</u> generate external diagnosis alarm due to malfunction ( <b>factory setting in GSD file</b> )
2-9	00 hex	reserved

### Tabelle 2: User-specific parameter data

No unlisted values are permitted. They can lead to malfunctions!

#### 4.2.3.1 Activating the external diagnosis in STEP 7

The project planning programs of the DP master systems either offer the option of activating the external diagnosis in plain text format, such as with STEP7, or of stating the information directly in hex code.



#### Bild 4-1: Aktivating external diagnosis with STEP7

Parameter data (hex)	Function
00,00,00,00,00,00,00,00,00,00,00,	External diagnosis alarms are also generated if there is an inverter malfunction (enabled = on)
00, <b>01</b> ,00,00,00,00,00,00,00,00,00,	External diagnosis alarms are not generated if there is an inverter malfunction (disabled = off, factory setting in GSD file)

### Tabelle 4-3: Hex code for activating external diagnosis generation

## 5 Sample program for STEP 5

### Hardware configuration:

In this example, the project planning for the inverter defines the process data configuration “3 PD” on input addresses PW156, PW158, PW160 and output addresses PW156, PW158, PW160. In this case, for example, consistent access takes place in the “last word first” sequence.

### **Note:**

In the Simatic S5, data consistency is principally determined by the CPU type. Please refer to the manuals for the CPU or the DP master module of the Simatic S5 for further information about correct programming with data consistency.

```
//Read in actual values consistently

L PW 160      //Load PI3 (no function)
L PW 158      //Load PI2 (actual speed value)
L PW 156      //Load PI1 (status word 1)

//Output setpoints consistently

L KH 0
T PW 160 //Write 0hex on PO3 (no function, however)

L KF +1500
T PW 158 //Write 1500dec on PO2 (speed setpoint = 300 rpm)

L KH 0006
T PW 156 //Write 6hex on PO1 (control word = enable)
```



## 6 Sample program for STEP 7

The inverter is controlled using Simatic S7 in accordance with the selected process data configuration either directly using load and transfer commands or by means of special system functions, SFC 14 DPRD\_DAT and SFC15 DPWR\_DAT.

In principle with S7, data lengths of 3 bytes or more than 4 bytes have to be transferred with the S7 system functions SFC14 and SFC15. The following table therefore applies:

Process data configuration	STEP7 program access via	
1 PD	Load/transfer commands	
2 PD	Load/transfer commands	
3 PD	System functions SFC14/15 (length 6 Byte)	
Param + 1 PD	Parameter channel:	System functions SFC14/15 (length 8 Byte)
	Process data:	Load/transfer commands
Param + 2 PD	Parameter channel:	System functions SFC14/15 (length 8 Byte)
	Process data:	Load/transfer commands
Param + 3 PD	Parameter channel:	System functions SFC14/15 (length 8 Byte)
	Process data:	System functions SFC14/15 (length 6 Byte)

### Hardware configuration:

In this example, the project planning for the inverter defines the process data configuration "3 PD" on input addresses PIW576, PIW 578, PIW 560 (PIW = Process In Words) and output addresses POW576, POW 578, POW 560 (POW = Process Out Words). A data block DB3 is created with about 50 data words.

When SFC14 is called, the process input data are copied into data block DB3, data words 0, 2 and 4. When SFC15 is called after the control program has been processed, the process output data are copied from data words 20, 22 and 24 into the output addresses.

Note the length information in bytes in the case of the RECORD parameter. This must correspond to the configured length. The function parameter LADDR has to be an hex coded value.

Please refer to the online help for STEP7 for further information about the system functions.

```

//Start of cyclical program processing in OB1
BEGIN
NETWORK
TITLE = Copy PI data from inverter to DB3, word 0/2/4
CALL SFC 14 (DPRD_DAT)           //Read DP slave record
    LADDR := W#16#240             //Input address 576
    RET_VAL:= MW 30               //Result in flag word 30
    RECORD := P#DB3.DBX 0.0 BYTE 6 //Pointer

NETWORK
TITLE = PLC program with drive application
// PLC program uses the process data in DB3 for
// controlling the drive
L DB3.DBW 0                      //LOAD PI1 (status word 1)
L DB3.DBW 2                      //Load PI2 (actual speed value)
L DB3.DBW 4                      //Load PI3 (no function)

L W#16#0006                      //Write 6hex on PO1
T DB3.DBW 20                     //(control word = enable)

L 1500                          //Write 1500dec on PO2
T DB3.DBW 22                     //(speed setpoint = 300 rpm)

L W#16#0000                      //Write 0hex on PO3
T DB3.DBW 24                     //(no function, however)
//End of cyclical program processing in OB1

NETWORK
TITLE = Copy PO data from DB3, word 20/22/24 to inverter
CALL SFC 15 (DPWR_DAT)          //Write DP slave record
    LADDR := W#16#240           //Output address 576 = 240hex
    RECORD := P#DB3.DBX 20.0 BYTE 6 //Pointer to DB/DW
    RET_VAL:= MW 32             //Result in flag word 32


```

Please refer to the Fieldbus Unit Profile manual (publication number 0919 1607) for more detailed information and sample applications for control via the process data channel, in particular concerning the coding of the control and status word.

## 7 PROFIBUS DP fault diagnosis

The following diagnostic procedures indicate the troubleshooting methods for the most frequent problems.

## 7.1 Inverter does not work on PROFIBUS DP



## 7.2 Inverter cannot be controlled via DP master

